



OPERATIONS & MAINTENANCE MANUAL

ESI DESIGNED AND BUILT

Isuzu 3CE1UGZG1 Diesel Engine
Staforf S0L2-F1 Gen End

APPLICABLE MODELS

IPG-13-3CE-SRL2



WWW.ESIALASKA.COM



ESlaska.com

THIS PAGE INTENTIONALLY LEFT BLANK

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312

Equipment Source, Inc.



ESlAlaska.com

General Information & Warranty

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312

Equipment Source, Inc.



THIS PAGE INTENTIONALLY LEFT BLANK



www.esialaska.com

For Parts & Service:

Fairbanks, Alaska

907.458.9049

FAI-Parts@ESlaska.com

Anchorage, Alaska

907.341.2250

ANC-Parts@ESlaska.com

Seattle, Washington

425.251.6119

FAI-Parts@ESlaska.com

Williston, North Dakota

701.774.5312

Williston-Sales@ESlaska.com

OPERATORS MANUAL

ESI Generator

Kubota & Isuzu Powered Generators
by ESI

SPECIFICATIONS

See product specification sheet for product specifications



Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312

1 Introduction

⚠ WARNING Read and understand this manual before operating the machine to avoid serious injury or death.

1.1 General Description

ESI built generators come in a variety of configurations and sizes. Refer to unit specifications and manual components for specific details. General operation and maintenance remains the same for all of these units.

1.2 Manual Applicability

This manual is applicable to the following Equipment Source Incorporated (ESI) machine models:

Model	Description
KPG & IPG Series	Skid mounted ESI Generators
KPG & IPG Series Enclosure Series	ESI Generators with Enclosures

This manual should be kept with the machine at all times. Immediately contact Equipment Source Incorporated (manufacturer) or an authorized dealer to obtain a copy of this manual if missing or damaged. Refer to www.equipmentsourceinc.com for current contact information.

1.3 Manual Scope

This manual contains basic operating and maintenance instructions for the above listed product. For detailed service instructions concerning specific electrical or mechanical components, refer to the operation and maintenance manual provided by the manufacture of the specific component or contact an authorized service provider. Operation and Maintenance instructions for the generator controller can be found in the separate controller manual included with the generator.

1.4 Warranty

Review the warranty before operating or working on the unit. The warranty contains important safety and operational requirements. Contact ESI for the latest warranty information.

1.5 Installation

Review the installation requirements before installing, operating or working on the unit. The installation requirements contain important information and must be adhered to in order to maintain warranty. Contact ESI for the latest installation requirements.

2 IMPORTANT SAFETY INSTRUCTIONS

WARNING

- SAVE THESE INSTRUCTIONS. This manual contains important instructions that should be followed during the operation and maintenance of the generator, battery and heater.

2.1 Training

- Never allow untrained personnel to operate or service the machine. Take time to read the manual and discuss safe practices with jobsite personnel.
- Read and understand the operating section of this manual.
- Take time to familiarize yourself with the controls and instructional placards before operating or servicing.
- Contact your dealer or service provider if additional training is necessary.

2.2 Operating

- Some components are hot while in operation. Keep clothing and combustibles away.
- Wear protective clothing, such as gloves, appropriate to the jobsite.
- Observe changes in the operating environment and respond accordingly.
- Generators vibrate in normal use. During and after the use of the generator, inspect the generator as well as extension cords and power supply cords connected to it for damage resulting from vibration. Have damaged items repaired or replaced as necessary. Do not use plugs or cords that show signs of damage such as broken or cracked insulation or damaged blades.

2.3 Service

- Only trained service technicians should attempt to service the machine.
- Properly shutdown the machine and let cool completely before attempting to service any component.
- Never defeat the safety devices
- Never modify the machine

3 Transporting

3.1 Lifting

CAUTION

- Ensure that any equipment used to lift the unit is rated for the weight of the unit.

3.2 Transporting

1. Lift the machine following the guidelines presented below.
2. If applicable: ensure all doors are closed and latched.
3. Remove any hoods in the way before lifting.
4. Lift the unit using ONLY designated lifting points or fork pockets.

3.3 Storage

Units placed in storage must be stored out of the elements and protected from rain, snow and sunlight. The warranty will be voided for units left exposed to the elements during storage. ESI built unit enclosures provide sufficient protection when properly closed.

3.3.1 Short-Term Storage (less than 90 days)

1. Shutdown the machine
2. Close all doors (if applicable)

3.3.2 Long-Term Storage (greater than 90 days)

1. Shutdown the machine
2. Verify that the main breaker and control switches are in the off position
3. Disconnect the battery
4. Drain water from fuel filters.
5. Secure/Close vents and openings (if applicable).

4 Operation

4.1 System Operation

Refer to individual component manuals for operation of those components. This unit should only be operated by trained personnel familiar with the operation of the entire system. Refer to the PRE-OPERATION CHECK portion of the Engine Manual

4.2 Recommended Fuels and Fueling Instructions

⚠ CAUTION Do not overfill tank. Tank should be filled to only 90% of the full volume to allow thermal expansion.

Use ULSD No.1 or ULSD No.2. For continuous duty operation, a refilling schedule should be established.

4.3 Engine Heat - 120V Power Input

If a cold start is required, use the 120V engine pre-heat circuit to warm the engine block and engine oil prior to starting. The engine should be pre-heated for approximately 4-hours if the ambient temperature is below -7°C (20°F). Longer preheat cycles may become necessary in extremely cold conditions.

Use a grounded flexible extension cord rated at 15A minimum to connect the machine to a 120V power supply. There is an orange, three-prong “Y” located on each of the generators.

4.4 Monitoring and Operation

4.4.1 Minimum Loading of Diesel Engines

Diesel generator engines require that a minimum average load be maintained. An average load of 75% of the rated output of the generator must be maintained to avoid damaging the unit (often referred to as “Wet-Stacking”). Prolonged use of the generator at loads less than 75% of rated output will void the warranty, reduce the life span of the engine and cause damage to the unit. Refer to the ESI Warranty Summary for further details. Consider using a load bank to maintain minimum loading on the engine.

4.4.2 Daily Inspection & Startup Inspection (required)

- Conduct general inspection of the unit
- Listen for abnormal sounds
- Check fluid levels
- Check all hoses for damage (including but not limited to fuel lines and coolant lines)
- Check engine temperature
- Check containment for accumulation of liquids.
- Check vents for icing or other obstructions (if applicable)
- Observe recommended maintenance schedule
- Check for error codes on control units for KPG and any other equipment associated with the unit.

4.5 Long Run Oil Tank (LRT)

- An LRT equipped ESI generator has increased service intervals up to 3000 hours
 - Oil change intervals should be determined using an oil sample analysis at regular intervals to determine maximum service interval.
 - Operating conditions may affect the service interval of the LRT.
- The service interval of the LRT may change if operating conditions change
- Prefill oil filters with oil when completing an oil change on a LRT equipped unit. This reduces the likelihood of damaging air bubbles in the oil system.
- Users can expect some oil seeping between engine base and long run oil pan on LRT installations. This is a normal condition for operating the LRT and is not warrantable.
- Great care should be taken to limit vibration of the generator. Excessive vibration will cause premature failure of LRT seals and is not warrantable. See warranty and installation instructions for further details.

5 Maintenance

⚠ CAUTION Some of the following maintenance operations should only be completed by a trained technician. Do not attempt to open electrical panels unless you are a trained technician. Maintenance schedule must be adhered to and documented in order to maintain warranty. Maintenance programs should be tailored to the specific generator, environment and operating conditions.

5.1 Maintenance Schedule

Table 1. Maintenance Schedule

Interval	Maintenance Instruction	Notes
Daily	<ul style="list-style-type: none"> ▪ See section 4.4.2 of this manual for additional requirements 	Complete at every inspection
Every 50 hours	<ul style="list-style-type: none"> ▪ Check of fuel pipes and clamp bands ▪ Check radiator hoses and clamp bands ▪ Drain water separator 	
Varies by model	<p>Engine Oil Change and Oil Replacement Intervals</p> <ul style="list-style-type: none"> ▪ Standard Oil Pan (Kubota Recommendation) <ul style="list-style-type: none"> ○ Initial Oil Change: 50 hours ○ Interval: <ul style="list-style-type: none"> ▪ KPG-05: 100 hours ▪ KPG-06 to KPG-24: 200 hours ▪ IPG-08 & IPG-13: 250 hours ▪ KPG-28 & KPG-36: 250 hours ▪ KPG-45: 500 hours ▪ Long Run Oil Pan (LRT) Option <ul style="list-style-type: none"> ○ Interval: 3,000 hours 	<p>Engine oil must meet API Spec: CF, CF-4, CG-4, CH-4 or CI-4</p> <p>See section 4.5 for additional notes on LRT oil changes.</p>
Every 200 hours (KPG-05 to KPG-24) OR Every 250 hours (IPG-08, IPG-13, KPG-28 & KPG-45)	<ul style="list-style-type: none"> ▪ Clean air cleaner element ▪ Change Engine Oil and Oil Filter (KPG-06 to KPG-36) ▪ Check and clean fuel filter ▪ Check battery electrolyte level ▪ Check fan belt tightness ▪ Check intake air line ▪ Inspect generator (see generator section of this manual) 	
Every 500 hours	<ul style="list-style-type: none"> ▪ Change Engine Oil and Oil Filter Cartridge (KPG-45, standard oil pan) ▪ Replace fuel filter cartridge ▪ Remove sediment in fuel tank ▪ Clean water jacket (radiator interior) ▪ Replace fan belt ▪ Clean water separator 	
Every one or two months	<ul style="list-style-type: none"> ▪ Charge battery as needed 	

Every Year	<ul style="list-style-type: none"> ▪ Replace air cleaner element ▪ Clean Generator (blow out with air) and inspect ▪ Change Engine Oil and Oil Filter 	Air filter element may need cleaning more frequently depending on environmental conditions
Every 800 hours	<ul style="list-style-type: none"> ▪ Check valve clearance 	
Every 1500 hours	<ul style="list-style-type: none"> ▪ Check fuel injectors 	
Every 3000 hours	<ul style="list-style-type: none"> ▪ Change Engine Oil and Oil Filter Cartridge (units equipped with LRT) ▪ Check turbo charge (if unit is equipped with a turbo) ▪ Check supply pump 	
Every Two Years	<ul style="list-style-type: none"> ▪ Change radiator coolant ▪ Replace battery ▪ Replace radiator hoses and clamp bands ▪ Replace fuel pipes and clamp bands ▪ Replace intake air line ▪ Replace fan belt (or every 500 hours, whichever occurs first) 	
Every 10,000 hours / 2 years	<ul style="list-style-type: none"> ▪ Inspect Generator sealed bearings 	
At 30,000 hours	<ul style="list-style-type: none"> ▪ Replace Generator sealed bearings 	

5.2 Engine Service

Use engine operator’s or service manual provided for further instruction on how to complete routine service or trouble shooting.

5.3 Battery Service

The engine starting circuit is supplied by a single 12V battery. No maintenance is required other than normal charging and occasional replacement.

To replace the battery, sequentially remove the negative ground lead, positive power lead and the bracket holding the battery in the tray. Replace the battery by securing in the tray, connecting the positive lead and then connecting the ground lead.



6 Maintenance Records

Table 2. Machine Data

Machine Serial Number	
Engine Serial Number	
Generator Serial Number	

Table 3. Maintenance Records

<ul style="list-style-type: none"> ▪ Date ▪ Engine Hours ▪ Service Personnel ▪ Service Location 	Description of work completed











Commonly Replaced ESI Generator Parts

See next page for LRT options and remote fuel filters when applicable

Engine Series	Model	Kubota Engine	Oil Filter	Air Filter	Fuel Filter	Oil Capacity
Engine Series	KPG-05-Z48	Z482	15426-32430	K1211-82320	12581-43012	2.6 Liters / 0.69 Gal
	KPG-06-NG	DG972	HH150-32430	1G659-11222	N/A	3.4 Liters / 0.90 Gal
	KPG-06-LP	WG972				3.4 Liters / 0.90 Gal
05 Series	KPG-06-MQ	D1005	HH160-32093	15741-11083	15221-43170	5.1 Liter / 1.35 Gal
	KPG-06-D10	D1005				5.1 Liter / 1.35 Gal
	KPG-08-D11	D1105				5.1 Liters / 1.35 Gal
	KPG-10-D13	D1305				5.7 Liters / 1.50 Gal
	KPG-12-V15	V1505				5.7 Liters / 1.50 Gal
03 Series	KPG-14-D15	D1503	HH164-32430	70000-11081	HH166-43560	7.0 Liters / 1.85 Gal
	KPG-15-V17	D1703				7.0 Liters / 1.85 Gal
	KPG-18-V20	V2003				9.5 Liters / 2.50 Gal
	KPG-20-V22	V2203				9.5 Liters / 2.50 Gal
	KPG-23-V20T	V2003-T				9.5 Liters / 2.50 Gal
	KPG-24-V24	V2403				9.5 Liters / 2.50 Gal
V3 Series	KPG-28-V33	V3300	HH1C0-32430	3A111-19130 (inner) 59800-26110 (outer)	HH166-43560 & R60S	13.2 Liters / 3.50 Gal
	KPG-36-V36	V3600		R2401-42280 (inner) 59700-26112 (outer)		13.2 Liters / 3.50 Gal
	KPG-36-V38D	V3800-derated				
	KPG-45-V38	V3800				13.2 Liters / 3.50 Gal
	Model	Isuzu Engine	Oil Filter	Air Filter	Fuel Filter	Oil Capacity
3C	IPG-08-3CH	3CH1NGZG1	5-8640-0632-0	K1211-82320	5-8640-0778-0 & R12s	3.4 Liters / 3.6 Qt
	IPG-13-3CE	3CE1UGZG1	5-8640-1515-0	K1211-82320	5-8640-1510-0 & R12s	6.7 Liters / 7.1 Qt

Service Intervals: Air Filters: Yearly or 500 hours (more frequently may be needed) | Fuel Filters: 500 hours

Clean Water Separator: ALL: 500 hours

Oil & Oil Filter Service Intervals: ALL: Initial @ 50hrs

KPG-05: 100 hrs | 05 & 03 Series: 200 hrs | IPG-08, IPG-13, KPG-28 & KPG-36: 250 hrs

KPG-45: 500 hrs | All LRT Models: 3,000 hrs

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312

Long Run Oil Option (LRT)

Replaces standard oil filter and oil capacity from chart above for units with LRT installed

Model	LRT Model	LRT Size	Oil Filter (2ea.)	Oil Capacity
KPG-06 to KPG-12	05SMLRT	9 Gallon	16121-32430	32 Quarts / 8 Gal
KPG-06 to KPG-12	05LRT	19 Gallon		48 Quarts / 12 Gal
KPG-15 to KPG-24	03LRT	19 Gallon		48 Quarts / 12 Gal
KPG-28 to KPG-45	V3LRT	26 Gallon		64 Quarts 16 Gal
IPG-08	3CH1LRT	19 Gallon		48 Quarts / 12 Gal
IPG-13	3CE1LRT	19 Gallon		48 Quarts / 12 Gal

Remote Racor Fuel Filter

In addition to fuel filters from above chart for units with auxiliary Racor Fuel filter installed.


Model	Filter Part Number
120AS Racor Fuel Filter	R12S
660R2 Racor Fuel Filter	R60T (10 micron)

Part numbers may vary for non-standard products. Always have unit Stock # available when calling for parts. Consult the O&M Manual for additional details.

KPG Model Breakdown

ESI Generators

KPG - 18 - V20 - MR8S - AR2



WARRANTY**EQUIPMENT SOURCE INC.
LIMITED WARRANTY****INFORMATION**

Equipment Source Inc. (ESI) warrant to you, the original purchaser, that all parts (except those 3rd party components listed below) of your new ESI product purchased from an Authorized ESI Distributer or from ESI directly will be free from defects in materials or workmanship for 1 (one) year/2,000 hours (whichever occurs first) from invoice date. Additional component warranties are listed below.

Summary of major component warranties (see component sections of this manual for further details and additional warranties). Warranty periods are from invoice date. Not all of the following components are applicable to every product. All warranty time periods begin at invoice date:

1. Engine – 2 (two) years / 2,000 hours, whichever occurs first (please refer to the Isuzu or Kubota Engine Warranty sheet enclosed in this manual for details).
2. Generator and Controls – Free from defects in materials or workmanship for 1 (one) year / 2,000 hours.
3. Flagro Heater / Fire Box - 1 (one) year / 2,000 hours
4. ESI Manufactured Firebox– free from defects in materials or workmanship for 3 (three).
5. Pump – 1 (one) year (please refer to the pump warranty sheet enclosed in this manual), wear parts are not covered under warranty.
6. Buderus Boiler – 2 (two) years limited warranty, please refer to Buderus warranty sheet enclosed in this manual.

In order to obtain warranty repairs, you must deliver the product, at your expense, together with proof of purchase to 1919 Van Horn Road, Fairbanks, AK 99701 (907.458.9049) or 7780 Old Seward Highway, Anchorage, AK 99518 (907.341.2250). Call 907.458.9049 from outside Alaska. Offsite warranty may be performed if customer pays all travel and shipping expenses.

No person, agent or dealer is authorized to give any warranties on the behalf of ESI, nor is to assume for this company any other liability in connection with any of ESI's products unless made in writing and signed by an officer of ESI. This warranty supersedes and is in leu of all other warranties, expressed or implied including terms and

conditions of Purchase Orders. The company must be notified within 5 (five) business days, in writing of any product failure and warranty claim.

WHAT THE WARRANTY DOES NOT COVER

This warranty **does not** cover:

1. Damage, malfunction or failures resulting from accidents, abuse, misuse, modifications, alteration, improper servicing or lack of performance of required maintenance service voids the warranty including but not limited to regularly scheduled oil changes and filter changes.
2. Damage, malfunction or failures resulting from underloading of the engine (also known as wet stacking) voids the warranty. Refer to the Operations and Maintenance manual for proper engine loading requirements.
3. Normal maintenance services or replacement of maintenance items such as light bulbs, preheater plugs, heater nozzles, filter elements, lubricants, oils, coolant, belts, tires, or other wear items.
4. This warranty does not cover cosmetic damage.
5. 3rd party parts installed on ESI products. Unauthorized modifications to the unit will void the warranty and may impair function.
6. Failure of or damage caused by ancillary systems. These include but are not limited to failures of the fuel or oil system (not provided by ESI), HVAC system, building / structure or other systems.
7. Units placed in storage must be stored out of the elements and protected from rain, snow and sunlight. The warranty will be voided for units left exposed to the elements during storage. ESI built unit enclosures provide sufficient protection when properly closed.
8. Improperly installed products. Operating the unit on or in the packing pallet or crate or improperly mounted skid generator (including installation of isolators between the skid and mounting surface) voids the warranty. Consult the product operator's manual for required installation procedures.
9. Installation of electrical components by anyone other than a licensed electrician voids the warranty.

10. Use of the unit for application other than what the product was meant for voids the warranty.
11. Warranty coverage expires whenever the client, for whatever reason, is late in payment.
12. The warranty does not cover repairs or modifications for small oil weeps on Long Run Oil Tanks (if installed). A small amounting of weeping during break in and use is expected and does not warrant repairs.

LIMITATION ON ESI's RESPONSIBILITY

Our responsibility for any and all losses and damages resulting from any cause whatsoever, including our negligence, alleged damage or defective goods, whether such defects are discoverable or latent, shall be limited to the repair or replacement of defective parts. IN NO EVENT WILL ESI BE LIABLE FOR LOSS OF USE, LOSS OF PROFITS, LOSS OF OR DAMAGE TO OTHER PROPERTY, INCONVENIENCE, COMMERCIAL LOSS, ENVIRONMENTAL CLEANUP OR OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER. ESI will in no event be liable for fuel, oil, coolant or other spills or cleanup regardless of cause or fault. Proper containment and monitoring is the sole responsibility of the end user. In no event shall ESI's liability ever exceed the purchase price of the specific unit in questions.

MONITORING REQUIREMENTS

Frequent monitoring of equipment is vital for proper operation and maintenance of the equipment. All equipment must be monitored daily by trained technicians (or more frequently if indicated in the Operation Manual). Monitoring can be achieved via electronic monitoring systems for remote installations (unless otherwise noted in the Operation Manual). The following unit conditions must be monitored on a daily basis, failure to do so will void all warranties. Additional monitoring may be required depending on site specific requirements.

- General inspection of unit to include: inspection for leaks, damage to unit, improper operation, malfunctioning equipment, error codes or other issues.
- Inspect coolant level and condition. Add coolant as needed to maintain proper coolant levels. Replace coolant if coolant condition has degraded.
- Inspect oil level and condition. Add oil as needed to maintain proper oil levels. Replace oil at recommended service intervals or if oil is found to have degraded.

- Inspect Engine temperature and engine speed.
- Inspect containment, check for leaks and presence of fluids in containment

Maintenance logs must be maintained for the unit and provided to ESI for warranty claims. ESI offers monitoring equipment for electronic monitoring.

OPERATION & SAFETY REQUIREMENTS

Failure to adhere to these requirements will void all warranties.

- Read and understand carefully all components of the Operator's Manual prior to starting or operating the unit.
- Learn how to operate and work safely. Know your equipment and its limitations. Always keep the engine in good condition.
- Do not carry out maintenance on a running or hot unit. Keep hands away from moving parts.
- Do not climb on top of the unit to perform work of any kind.
- When lifting the unit, ensure that the lifting device is rated for the unit weight. Only lift the unit with provided lifting rings or fork pockets.
- In case of emergency, shut off the engine and notify the person in responsible charge.
- Follow all applicable laws and regulations regarding operation and maintenance of the unit.
- For Trailer Mounted Units:
 - Ensure that the trailer is registered with an applicable transport authority before towing.
 - Complete a thorough walk around inspection of the unit before towing. Inspect for damage or abnormalities and repair as needed before travel.
 - Disconnect the trailer from the tow vehicle, place wheel chocks behind the wheels and level prior to running or operating the unit.
- Refer to the various component sections of the Operator's Manual for proper maintenance and service intervals.

Failure to adhere to any of the above requirements or the requirements of Installation Instructions or Operations and Maintenance Manual will void all warranties. ESI reserves the right to update or modify this warranty at time. Contact ESI for a current warranty.



**KUBOTA ENGINE AMERICA CORPORATION
LIMITED WARRANTY ON INDUSTRIAL ENGINES
AND REPLACEMENT PARTS EFFECTIVE JANUARY 1, 2009**

OUR WARRANTY TO YOU

We warrant to you, the original purchaser, that all parts (except those referred to below) of your new Kubota industrial engine and replacement parts purchased from an Authorized Kubota Industrial Engine Distributor or OEM Distributor in the United States will be free from defects in materials or workmanship during the following periods.

1. Industrial Engines for 2 years or 2,000 hours, whichever occurs first.
2. Industrial Engines Major Component Warranty (MCW), 3 years or 3000 hours, whichever occurs first, parts only.

MCW covers cylinder block, cylinder head, crankshaft, camshaft, gears, pistons, rods, flywheel, flywheel housing, oil pump, pulleys, governor, intake manifold, oil pan, ignition distributor.

MCW does not cover rings, bearings, water pump, any electrical component, valve train components, accessory parts, seals, gaskets, carburetors, exhaust manifold, hoses, all fuel system components, muffler, any filters, radiator, fan, belts, thermostat, spark plugs, fuel transfer pumps.

3. Replacement parts for 1 year.

WHAT WE WILL DO

We will, at our option, repair or replace any part covered by this warranty which becomes defective, malfunctions or otherwise fails to conform with this warranty under normal use and service during the term of the warranty at no charge for parts or labor. (Parts only for MCW)

WHAT YOU MUST DO TO OBTAIN WARRANTY SERVICE

In order to obtain warranty repairs, you must deliver the product, together with proof of purchase, to an Authorized Kubota Industrial Engine Distributor or Dealer at your expense. The names and addresses of such Authorized Kubota Industrial Engine Distributors can be found on the internet at www.kubotaengine.com, by calling 1-800-532-9808 or by contacting:

Kubota Engine America Corporation
505 Schelter Road
Lincolnshire, IL 60069

WHAT THE WARRANTY DOES NOT COVER

This warranty **does not** cover:

1. Damage, malfunctions or failures resulting from accidents, abuse, misuse, modifications, alteration, improper servicing, or lack of performance of required maintenance service.
2. Normal maintenance services or replacement of maintenance items such as light bulbs, preheater plugs, indicator and resistant coils, filter elements, lubricants, oils, spark plugs, coolant, or belts.
3. Installation of replacement parts, unless originally installed by an Authorized Kubota Industrial Engine Distributor or Dealer.
4. Non-genuine Kubota parts.
5. Any engines damaged by use of ether or any starting aid, or greater than a 50/50% solution of antifreeze and water.
6. Injection nozzle wear or any engine damage caused by injection nozzle wear or sticking.
7. Damage caused by water entering the engine due to any cause.
8. Used Products.
9. Any damage caused by overheating that is not a direct result of a defect in materials or workmanship.
10. Any Engine not application reviewed.

engine installation to optimize functionality/performance within the OEM's equipment in order to maintain durability, customer satisfaction, and reduce warranty failures and expenses. Kubota cannot anticipate all potential failures and issues that may occur with the engine or product in the field during an application review. Therefore, machine durability testing by the OEM either in a test facility and/or in the field is critical to further reduce the potential for field failures.

The amount of time spent by KEA on an application review is significantly less than the amount of time spent by the OEM's design engineers on the application. Because of this, the KEA application review is intended to identify issues that are within the scope of the application review testing performed and in some cases recommend possible solutions. The KEA application review should never take the place of proper design and testing of the finished product by the OEM.

The KEA application review does not in any way express or imply any additional warranty coverage other than what is stated in Kubota's Limited Warranty Agreement. Kubota and its subsidiary companies are not responsible for (including, but not limited to): failures resulting from any components that are not manufactured by Kubota, misrepresented or incorrect information provided from an OEM, any changes made without KEA's knowledge, any decision by the OEM not to follow KEA's recommendations, or any application related problems or deficiencies that may arise that were not found by KEA's limited application review or the OEM's durability testing.

THIS IS THE ONLY EXPRESS WARRANTY ON OUR PRODUCTS

We neither assume nor authorize anyone to assume for us any other express warranty. The Kubota Distributor/ Dealer has no authority to make any representation or promise on behalf of Kubota Engine America Corporation or to modify the terms or limitations of this warranty in any way.

LIMITATIONS ON OUR RESPONSIBILITY WITH RESPECT TO PRODUCTS PURCHASED AND USED FOR PERSONAL, FAMILY OR HOUSEHOLD USE.

Our responsibility is to repair or replace defective parts as stated above. We will not be responsible for any other expenses, losses or inconvenience which you may sustain as a result of the purchase, use, malfunction or defective condition of our products. ANY IMPLIED WARRANTIES INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE SHALL BE LIMITED IN DURATION TO THE PERIOD SET FORTH ABOVE AND IN NO EVENT WILL WE BE LIABLE FOR ANY SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.

LIMITATIONS ON OUR RESPONSIBILITY WITH RESPECT TO PRODUCTS USED FOR RENTAL OR FOR COMMERCIAL, INDUSTRIAL OR AGRICULTURAL PURPOSES.

This warranty is in lieu of all other warranties, express or implied, and of any other obligations or liability on our part. IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE EXCLUDED. Our responsibility for any and all losses and damages resulting from any cause whatsoever, including our negligence, alleged damage or defective goods, whether such defects are discoverable or latent, shall be limited to the repair or replacement of defective parts as stated above. IN NO EVENT WILL WE BE LIABLE FOR LOSS OF USE, LOSS OF PROFITS, LOSS OF OR DAMAGE TO OTHER PROPERTY, INCONVENIENCE, COMMERCIAL LOSS, OR OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES WHATSOEVER.

APPLICATION REVIEW PROCESS: The Kubota Engine America (KEA) application review process is intended to assist the OEM with



ISUZU DIESEL ENGINES LIMITED WARRANTY

Effective Date: April 15, 2008

PLEASE COMPLETE THE ONLINE ENGINE REGISTRATION AS DETAILED BELOW IN SECTION (F).

A. Isuzu Motors America, Inc. ("ISZA") warrants to purchaser (the "Buyer") that its engines sold with this warranty when shipped, will meet all applicable specifications and will be free from defects in material and workmanship. The duration for this warranty is the warranty period (the "warranty period") shown in the schedule below. Except as otherwise provided herein, the warranty period begins at the time of the earlier to occur of (1) first retail sale of the engine or the product into which the engine is incorporated (the "first retail sale"), or (2) the accumulation of 100 engine demonstration hours. As used herein, "first retail sale" includes rental or lease. This warranty is transferable to a second owner only if approved by ISZA after ISZA's inspection of the engine and registration of the second owner.

BASE ENGINE WARRANTY TERM AND SCHEDULE

APPLICATION	WARRANTY PERIOD		COVERAGE	
	Months*	Hours*	Parts	Labor
INDUSTRIAL "2C", "3C" Models	0-12	UNLIMITED**	100%	100%
	12-24	2000**	100%	100%
	* Whichever occurs first ** Coverage for all electrical, fuel system and turbocharger components is limited to 2yrs/1000 hours, which ever occurs first. Note: In the absence of a functional hourmeter, the engine will be deemed to be in use for 8 hours per calendar day commencing from the start of the warranty period.			

All claims for failure to conform to specifications or defect in material or workmanship under this warranty must be made in writing promptly after discovery and, in any event, must be received by ISZA not later than twenty-four (24) months, after first retail sale. Defective items must be held for inspection by ISZA or its authorized distributor and, if requested, returned to ISZA, transportation prepaid.

ISZA will correct any failure to conform to specifications or any defect in material or workmanship by causing repair to be performed by an authorized service outlet, using new or remanufactured parts, within a reasonable time following the delivery of the engine to the service outlet's place of business.

If ISZA is unable to correct the failure after a reasonable number of repair attempts, ISZA will provide, at its option, one of the following: (1) a replacement unit, or (2) full refund of the purchase price of the unit. These remedies are the Buyer's exclusive remedies for breach of warranty.

The owner is responsible for the performance of regular maintenance services as specified in the operator's manual applicable to the engine.

B. THE FOREGOING WARRANTIES ARE IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS.

CONTINUED ON REVERSE SIDE

C. ISZA's obligation under the warranty shall not apply to:

1. Any engine which shall have been subject to negligence, misuse, accident, misapplication, overspeeding or proprietary fittings not manufactured or approved by ISZA.
2. Any engine that has been repaired, modified or altered by anyone in a manner, which in ISZA's sole judgment adversely affects its performance or reliability.
3. Any engine which has been fitted with or repaired with parts or components not supplied or approved by ISZA which in ISZA's sole judgment adversely affects the engine's performance or reliability.
4. Failure resulting from improper use of engine, lack of preventive maintenance or servicing including improper dismantling or removal of seals and/or governor of injection pump, or tampering with factory adjustments made by Isuzu or ISZA.
5. Engine tune-ups, normal maintenance services including but not limited to valve adjustment, normal replacement of service items, normal wear and tear of expendable parts including gaskets (except cylinder head gasket and manifold gasket) cylinder liners, starter brush, pinion and clutch of starter, elements of air cleaner, oil filter and fuel filter, glow plug, control resistance, rubber hose, vinyl pipe, injection nozzle, fan belt, rust due to prolonged storage and fuel, lubricating oil, antifreeze, etc.
6. Damage caused by prolonged or improper storage of the engine after shipment from ISZA.
7. Loss of operating time to the user while the engine or engine driven equipment is out of operation and damage to equipment powered by the engine.
8. Damage caused by prolonged engine operation at low coolant temperatures or low engine load.
9. Engine operation outside of the ambient temperature range of -13 degrees Fahrenheit to 104 degrees Fahrenheit without appropriate modifications to the engine and engine cooling systems.
10. Damage or failure resulting from the use of any type of fuel.

D. The foregoing is ISZA's only obligation and Buyer's exclusive remedy for breach of warranty. Buyer's failure to submit a claim as provided above shall specifically waive all claims for damages or other relief, including but not limited to claims based on latent defects. In no event shall Buyer be entitled to any damages, whether direct, indirect, incidental, special or consequential or for any losses, costs or expenses of any kind whether Buyer's claims are based on breach of warranty, breach of contract, tort (including negligence and strict liability) or any other theory. Any action arising hereunder or relating hereto whether based on breach of contract, or other theories, must be commenced within one (1) year after the cause of action accrues or it shall be barred. Some states do not allow limitations on warranties, or on remedies for breach of warranties in some transactions. Where disallowed by applicable state law, the limitations set forth in Part B and this Part D shall not apply.

E. The warranties set forth above are exclusive, supersede any prior communications or commitments relating to the subject matter hereof, and are expressly in lieu of all other obligations or liability on the part of ISZA. No employee of ISZA or any other person or entity is authorized to make any other warranty or assume any other liability for or on behalf of ISZA.

ENGINE REGISTRATION

F. Registering your engine allows prompt and accurate reporting before warranty service is required and will quickly enable an authorized Isuzu dealer to determine the warranty status of the engine. This registration will be used in warranty claim processing and to contact you in the unlikely event that a safety notification is required. To register your engine please visit our web site www.isuzuengines.com and click on the warranty registration link, then enter your engine serial number and model code. In the event you do not have access to the internet please contact the location where you purchased the engine or equipment for registration.

03/01/08

ISUZU MOTORS AMERICA, INC.
46401 Commerce Center Drive
Plymouth, MI 48170-9934
www.isuzuengines.com



INSTALLATION REQUIREMENTS FOR ESI OPEN SKID GENERATORS KPG, IPG, FPG AND ALL OTHER SERIES GENERATORS

The installation and commissioning of a generator is never a Plug n Play event. Proper professional review is always needed for proper operation, personal safety and to maintain warranty. All applicable codes and laws must be adhered to for proper installation.

All electrical connections must be reviewed and confirmed at the time of installation by a licensed electrician. Compatibility and configurations of system components such as but not limited to: generator, fuel systems, enclosures, switchbox, controllers and service panels must be reviewed by a qualified professional at the point of installation. All wires and hoses must have protection from chaffing as needed. An adequate and safe 12v power, fuel supply and exhaust must be provided.

Proper installation of the skid mounted generator must include a solid platform for support. The skid must be secured to prevent the unit from walking and to prevent excess vibration. The generator must be removed from the shipping pallet, crate or other shipping materials for proper installation. The open skid generator is provided with isolator mounts between the engine/genset and skid. The mass of the skid is not adequate to provide vibration isolation for the supported components without proper installation. The installation of additional isolators between the skid and mounting surface will create excess vibration and voids all warranties.

The skid must be securely attached to a concrete floor, metal structure or reinforced wooden floor designed for the application and load. All installations must be reviewed by a professional shortly after commissioning to ensure compliance with these installation requirements.

ESI highly recommends that skid mounted generators be installed with adequate fluid containment and other safeties including but not limited to remote monitoring. The installer and operator of the generator must adhere to all laws and regulations governing the installation and operation of the generator. The installer and operator must follow industry best practices where they meet or exceed the requirements laid in these instructions, the Warranty Summary or the Operations and Maintenance Manual.

Improper installation or failure to adhere to these instructions will void the warranty, may promote the risk of injury and reduce the useful life of the unit. See Warranty Summary and Operations and Maintenance Manual for further details and requirements.

Contact ESI for the latest Installation Requirements, Warranty Summary or Operations and Maintenance Manual.

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312



ESlAlaska.com

Alternator Manual

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312



THIS PAGE INTENTIONALLY LEFT BLANK

STAMFORD®

S0 and S1 Alternators
OWNER MANUAL




Table of Contents

1. FOREWORD.....	1
2. SAFETY PRECAUTIONS.....	3
3. SAFETY DIRECTIVES AND STANDARDS.....	7
4. INTRODUCTION.....	13
5. APPLICATION OF THE ALTERNATOR.....	17
6. INSTALLATION INTO THE GENERATOR SET.....	23
7. SERVICE AND MAINTENANCE.....	31
8. PARTS IDENTIFICATION.....	47
9. TECHNICAL DATA.....	49
10. SERVICE PARTS AND AFTER SALES SERVICE.....	51
11. END OF LIFE DISPOSAL.....	53

-



This page is intentionally blank.

1 Foreword

1.1 The Manual

This manual contains guidance and instructions for the installation and operation of the alternator. This manual does not include instructions for servicing and maintaining the alternator. Contact CGT Customer Service for details.

Before operating the alternator, read this manual and make sure that all personnel who work on the equipment have access to the manual and all additional documentation supplied with it. Misuse and failure to follow the instructions, and the use of non-approved parts, may invalidate the product warranty and lead to potential accidents.

This manual is an essential part of the alternator. Make sure that the manual is available to all users throughout the life of the alternator.

The manual is written for skilled electrical and mechanical technicians and engineers, who have prior knowledge and experience of generating equipment of this type. If in doubt, please seek expert advice or contact your local Cummins Generator Technologies subsidiary.

NOTICE

Information in this manual was correct when published. It may be superseded due to our policy of continuous improvement. Please visit www.stamford-avk.com for latest documentation.

-



This page is intentionally blank.

2 Safety Precautions

2.1 Safety Information and Notices used in this manual

Danger, Warning and Caution panels are used in this manual to describe the sources of hazards, their consequences and how to avoid injury. Notice panels emphasize important or critical instructions.

 DANGER
<i>Danger indicates a hazardous situation which, if not avoided, WILL result in death or serious injury.</i>

 WARNING
<i>Warning indicates a hazardous situation which, if not avoided, COULD result in death or serious injury.</i>

 CAUTION
<i>Caution indicates a hazardous situation which, if not avoided, COULD result in minor or moderate injury.</i>

NOTICE
Notice refers to a method or practice which can result in product damage, or to draw attention to additional information or explanations.

2.2 General Guidance

NOTICE
These safety precautions are for general guidance and supplement your own safety procedures and all applicable laws and standards.

2.3 Skill Requirements of Personnel

Service and maintenance procedures must only be carried out by experienced and qualified engineers, who are familiar with the procedures and the equipment.

2.4 Risk Assessment

A risk assessment has been performed on this product by Cummins, however a separate risk assessment must be performed by the user/operating company to establish all personnel-related risks. All affected users must be trained on the identified risks. Access to the Power Plant/Generator Set during operation must be restricted to persons who have been trained on these risks.

2.5 Personal Protective Equipment (PPE)

All persons operating, servicing, maintaining or working in or with a power plant or a generator set must wear appropriate Personal Protective Equipment (PPE)

Recommended PPE includes:

- Ear and Eye Protection
- Head and face protection
- Safety footwear
- Overalls that protect the lower arms and legs

Ensure that all persons are fully aware of the emergency procedures in case of accidents.

2.6 Noise

 WARNING
<p>Noise <i>Noise from a running alternator can cause serious injury by permanent hearing damage. To prevent injury, wear appropriate personal protection equipment (PPE).</i></p>

Maximum A-weighted noise emissions may reach 97 dB(A). Contact the supplier for application-specific details.

2.7 Electrical Equipment

 DANGER
<p>Live Electrical Conductors <i>Live electrical conductors can cause serious injury or death by electric shock and burns. To prevent injury and before removing covers over electrical conductors, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.</i></p>

All electrical equipment can be dangerous if not operated correctly. Always install, service and maintain the alternator in accordance with this manual. Work that requires access to electrical conductors must comply with all applicable local and national electrical safety procedures for the voltages involved and any site specific rules. Always use genuine branded replacement parts.

2.8 Lock Out/Tag Out

 WARNING
<p>Reconnected Energy Source <i>Accidental reconnection of energy sources during service and maintenance work can cause serious injury or death by electric shock, burns, crushing, severing or trapping. To prevent injury and before starting service and maintenance work, use appropriate lock out/tag out safety procedures to keep the generator set isolated from energy sources. Do not defeat or bypass the lock out/tag out safety procedures.</i></p>

2.9 Lifting

DANGER

Falling Mechanical Parts

Falling mechanical parts can cause serious injury or death by impact, crushing, severing or trapping.

To prevent injury and before lifting:

- ***Check the capacity, condition and attachment of lifting equipment (crane, hoists and jacks, including attachments to anchor, fix or support the equipment).***
- ***Check the capacity, condition and attachment of accessories for lifting (hooks, slings, shackles and eye bolts for attaching loads to lifting equipment).***
- ***Check the capacity, condition and attachment of lifting fixtures on the load.***
- ***Check the mass, integrity and stability (e.g. unbalanced or shifting center of gravity) of the load.***

WARNING

Falling Mechanical Parts

Falling mechanical parts can cause serious injury or death by impact, crushing, severing or trapping.

To prevent injury and before lifting the alternator:

- ***Do not lift the complete generator set by the alternator lifting fixtures.***
- ***Keep the alternator horizontal when lifting.***
- ***Fit drive end and non-drive end transit fittings to single bearing alternators to keep the main rotor in the frame.***

Do not remove the lifting label attached to one of the lifting points.

2.10 Alternator Operating Areas


WARNING

Ejected Debris

Debris ejected during catastrophic failure can cause serious injury or death by impact, severing or stabbing.

To prevent injury:

- ***Keep away from the air inlet and air outlet when the alternator is running.***
- ***Do not put operator controls near the air inlet and air outlet.***
- ***Do not cause overheating by running the alternator outside rating plate parameters.***
- ***Do not overload the alternator.***
- ***Do not run an alternator with excessive vibration.***
- ***Do not synchronize parallel alternators outside the specified parameters.***



Always wear suitable PPE when working in the hatched areas shown in the diagram or directly in-line with any air inlet/outlet.


Make sure this consideration is captured in your risk assessment.

2.11 Hazard Warning Labels

⚠ WARNING
<p>Safety Cover Removed A hazard exposed when a safety cover is removed can cause serious injury or death. To prevent injury:</p> <ul style="list-style-type: none"> • Fit the safety labels at the locations shown on the back of the label sheet supplied. • Observe the safety labels. • Refer to the service manual before removing covers.

The generator set manufacturer is responsible for fitting the self-adhesive hazard warning labels supplied with the alternator.

Replace labels that are missing, damaged or painted over.



3 Safety Directives and Standards

STAMFORD Alternators meet applicable European safety directives, and national and international standards relevant to alternators. The alternator must be operated within the limits specified in the relevant standards and within the parameters on the alternator rating plate.

Marine alternators meet the requirements of all the major marine classification societies.

3.1 Low Voltage Directive: Declaration of Conformity

TABLE 1. LOW VOLTAGE DIRECTIVE: DECLARATION OF CONFORMITY

EU DECLARATION OF CONFORMITY		
<p>This synchronous A.C. generator is designed for incorporation into an electricity generating-set and fulfils all the relevant provisions of the following EU Directive(s) when installed in accordance with the installation instructions contained in the product documentation:</p>		
2014/35/EU	Low Voltage Directive	
2014/30/EU	The Electromagnetic Compatibility (EMC) Directive	
<p>and that the standards and/or technical specifications referenced below have been applied:</p>		
EN 61000-6-2:2005 EN 61000-6-4:2007+A1:2011 EN ISO 12100:2010 EN 60034-1:2010 BS ISO 8528-3:2005 BS 5000-3:2006	Electromagnetic compatibility (EMC). Generic standards – Part 6-2: Immunity for industrial environments Electromagnetic compatibility (EMC). Generic standards – Part 6-4: Emission standard for industrial environments Safety of machinery – General principles for design – Risk assessment and risk reduction Rotating electrical machines - Part 1: Rating and performance Reciprocating internal combustion engine driven alternating current generating sets - Part 3: Alternating current generators for generating sets Rotating electrical machines of particular types or for particular applications - Part 3: Generators to be driven by reciprocating internal combustion engines - Requirements for resistance to vibration	
<p>This declaration has been issued under the sole responsibility of the manufacturer. The object of this Declaration is in conformity with the relevant Union harmonization Legislation.</p>		
<p>The name and address of authorised representative, authorised to compile the relevant technical documentation, is the Company Secretary, Cummins Generator Technologies Limited, 49/51 Gresham Road, Staines, Middlesex, TW18 2BD, U.K.</p>		
Date: 01 st February 2016  Signed:	Name, Title and Address: Kevan J Simon Global Technical and Quality Director Cummins Generator Technologies Fountain Court Lynch Wood Peterborough, UK PE2 6FZ	
Description	Serial Number	
<small>Registered in England under: Registration No. 441273. Cummins Generator Technologies Ltd. Registered Office: Barnack Road, Stamford, Lincolnshire PE9 2NB, England.</small>		
<small>450-16383-E</small>		

3.2 Machinery Directive: Declaration of Incorporation

TABLE 2. MACHINERY DIRECTIVE: DECLARATION OF INCORPORATION - SHEET 1

2006/42/EC MACHINERY DIRECTIVE DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY						
Function: Synchronous A.C. generator designed for incorporation into an electricity generating-set.						
The partly completed machinery supplied with this declaration: <ul style="list-style-type: none"> Is designed and constructed solely as a non-functional component to be incorporated into a machine requiring completion. Is designed to comply with the provisions of the following EU Directives so far as their level of build will allow: <table style="margin-left: 40px; border: none;"> <tr> <td style="padding-right: 20px;">2014/30/EU</td> <td>The Electromagnetic Compatibility (EMC) Directive</td> </tr> <tr> <td>2014/35/EU</td> <td>Low Voltage Directive</td> </tr> </table> Must not be put into service within the European Community ("EC") until the final machinery into which it is to be incorporated has been declared in conformity with the Machinery Directive and all other applicable EC Directives. Is designed and constructed to comply with the essential health and safety requirements of the Machinery Directive 2006/42/EC listed on sheet 2 of this Declaration. <p>The relevant technical documentation is compiled in accordance with the provisions of part B of Annex VII of the Machinery Directive. All relevant information about the partly completed machinery will be provided, in writing, on a reasoned request by the appropriate national authority to its authorised representative. The name and address of authorised representative, authorised to compile the relevant technical documentation, is the Company Secretary, Cummins Generator Technologies Limited, 49/51 Gresham Road, Staines, Middlesex, TW18 2BD, U.K.</p>			2014/30/EU	The Electromagnetic Compatibility (EMC) Directive	2014/35/EU	Low Voltage Directive
2014/30/EU	The Electromagnetic Compatibility (EMC) Directive					
2014/35/EU	Low Voltage Directive					
The undersigned representing the manufacturer:						
Date: 01 st February 2016  Signed:	Name, Title and Address: Kevan J Simon Global Technical and Quality Director Cummins Generator Technologies Fountain Court Lynch Wood Peterborough, UK PE2 6FZ					
Description	Serial Number					
<small>Registered in England under Registration No. 441273.</small> <small>Cummins Generator Technologies Ltd. Registered Office: Barnack Road, Stamford, Lincolnshire PE9 2NB, England</small>						
<small>450-16388-E</small>						

TABLE 3. MACHINERY DIRECTIVE: DECLARATION OF INCORPORATION - SHEET 2

2006/42/EC MACHINERY DIRECTIVE DECLARATION OF INCORPORATION OF PARTLY COMPLETED MACHINERY	
ESSENTIAL HEALTH AND SAFETY REQUIREMENTS RELATING TO THE DESIGN AND CONSTRUCTION OF PARTLY COMPLETED MACHINERY	
<p>1.1 General Remarks</p> <ul style="list-style-type: none"> • 1.1.2 : Principles of safety integration • 1.1.3 : Materials and products • 1.1.5 : Design of machinery to facilitate its handling <p>1.3 Protection Against Mechanical Hazards</p> <ul style="list-style-type: none"> • 1.3.1 : Risk of loss of stability • 1.3.2 : Risk of break-up during operation • 1.3.3 : Risks due to falling or ejected objects • 1.3.4 : Risks due to surfaces, edges or angles • 1.3.7 : Risks related to moving parts • 1.3.8.1 : Moving transmission parts <p>1.4 Guarding *</p> <ul style="list-style-type: none"> • 1.4.1 : Guards – General requirements * • 1.4.2.1 : Fixed guards * <p>1.5 Other Hazards</p> <ul style="list-style-type: none"> • 1.5.2 : Static electricity • 1.5.3 : Energy supply other than electric • 1.5.4 : Errors of fitting • 1.5.6 : Fire • 1.5.13 : Emissions of hazardous materials and substances <p>1.7 Information</p> <ul style="list-style-type: none"> • 1.7.1 : Information and warnings on the machinery • 1.7.4 : Instructions 	<p>LEGEND</p> <ol style="list-style-type: none"> 1. Essential Health and Safety Requirements not shown are not considered applicable for this Partly Completed Machinery or must be fulfilled by the assembler of the Machinery. 2. Essential Health and Safety Requirements shown are considered applicable for this Partly Completed Machinery and have been fulfilled by the manufacturer to the extent possible, subject to the build requirements of the Machinery assembler, the information contained in the assembly instructions and Cummins bulletins. 3. * Customers may request Partly Completed Machinery without some or all guarding attached. In these cases section 1.4 Guarding does not apply and the Essential Health and Safety Requirements for guarding must be fulfilled by the assembler of the Machinery.
Registered in England under Registration No. 441273. Cummins Generator Technologies Ltd, Registered Office: Barnack Road, Stamford, Lincolnshire PE9 2NB, England.	
450-16388-E	

3.3 Additional Information for EMC Compliance

STAMFORD alternators are designed to meet EMC emissions and immunity standards for industrial environments. Additional equipment may be required when the alternator is installed in residential, commercial and light industrial environments.

The installation 'earth/ground' arrangements require the connection of the alternator frame to the site protective earth conductor using a minimum lead length.

Installation, maintenance and servicing must be carried out by adequately trained personnel fully aware of the requirements of the relevant EC directives.

NOTICE

Cummins Generator Technologies is not liable for EMC compliance if unauthorized parts, not of STAMFORD brand, are used for maintenance and servicing.

3.4 Additional Information for CSA Compliance

To comply with Canadian Standards Association (CSA) regulations, all external wiring and components must be rated at the alternator rated voltage shown on the rating plate label.

-



This page is intentionally blank.

4 Introduction

4.1 General Description

S01/S02/S12 alternators are of brushless rotating field design, available up to 600V, 50 Hz (1500 RPM, 4 pole) or 60 Hz (1800 RPM, 4 pole), and built to meet B.S. 5000 Part 3 and other international standards.

S01/S02/S12 are self-excited, with excitation power derived from the main output windings using the AS540 AVR.

4.2 Alternator Name

TABLE 4. S01,S02, S12 ALTERNATOR NAMING FORMAT

Example:	S	0	L	1	-	D	1
	Stamford Brand	Family Series (0,1)	Low Voltage	Lamination Dia.(1,2)		Core Length	No. of Bearings

4.3 Serial Number Location

A unique serial number is stamped into the upper section of the drive end bracket and shown on two labels on the outside of the terminal box.

4.4 Rating Plate

 WARNING
<p><i>Ejected Debris</i> <i>Debris ejected during catastrophic failure can cause serious injury or death by impact, severing or stabbing.</i> <i>To prevent injury:</i></p> <ul style="list-style-type: none"> • <i>Keep away from the air inlet and air outlet when the alternator is running.</i> • <i>Do not put operator controls near the air inlet and air outlet.</i> • <i>Do not cause overheating by running the alternator outside rating plate parameters.</i> • <i>Do not overload the alternator.</i> • <i>Do not run an alternator with excessive vibration.</i> • <i>Do not synchronize parallel alternators outside the specified parameters.</i>

The fixed rating plate label states the intended operating parameters of the alternator.



FIGURE 3. DOTS VISIBLE IN LEFT, RIGHT, UPPER AND LOWER VIEWS OF 3D HOLOGRAM

-

This page is intentionally blank.

5 Application of the Alternator

WARNING

Ejected Debris

Debris ejected during catastrophic failure can cause serious injury or death by impact, severing or stabbing.

To prevent injury:

- ***Keep away from the air inlet and air outlet when the alternator is running.***
- ***Do not put operator controls near the air inlet and air outlet.***
- ***Do not cause overheating by running the alternator outside rating plate parameters.***
- ***Do not overload the alternator.***
- ***Do not run an alternator with excessive vibration.***
- ***Do not synchronize parallel alternators outside the specified parameters.***

It is the customer's responsibility to make sure that the selected alternator is suitable for the final application.

5.1 Environment

The alternators are protected to IP23 as standard. IP23 is not adequate protection for use outdoors without additional measures.

Ambient Temperature	-15° C to 40° C
Relative Humidity	< 65%
Altitude	< 1000 m

The alternator has been designed for the environment shown in the table. The alternator can operate outside these conditions if it is rated accordingly; the nameplate gives details. If the operating environment is changed after purchase, refer to the factory for a revised alternator rating.

5.2 Air Flow

Make sure that the air inlets and outlets are not obstructed when the alternator is running.

5.3 Airborne Contaminants

Contaminants such as salt, oil, exhaust fumes, chemicals, dust, and sand will reduce the effectiveness of the insulation and the life of the windings. Consider using air filters and an enclosure to protect the alternator.

5.4 Humid Conditions

The water carrying capacity of air depends on temperature. If the air temperature falls below its saturation point, dew may form on the windings, reducing the electrical resistance of the insulation. In humid conditions, additional protection may be required even if the alternator is fitted inside an enclosure. Anti-condensation heaters are supplied on request.

5.5 Anti-Condensation Heaters

DANGER

Live Electrical Conductors

Live electrical conductors can cause serious injury or death by electric shock and burns. To prevent injury and before removing covers over electrical conductors, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

Power to the anti-condensation heater is supplied from a separate source. Anti-condensation heaters raise the air temperature around the windings to deter condensation forming in humid conditions when the alternator is not operating. Best practice is to energize the heaters automatically when the alternator is off.

5.6 Enclosures

Fit an enclosure to protect the alternator from adverse environmental conditions. Make sure that air entering the alternator is of adequate flow rate, free from moisture and contaminants, and below the maximum ambient temperature on the rating plate.

Make sure there is sufficient access around the alternator for safe maintenance.

S01/S02/S12 alternators have round end brackets that will create an air flow pattern that differs from previous alternators of this size. The air flow should be modeled to identify and prevent hot air from recirculating within the enclosure.

5.7 Vibration

The alternators are designed to withstand the vibration levels encountered on generator sets built to meet the requirements of ISO 8528-9 and BS 5000-3. (Where ISO 8528 is taken to be broad band measurements and BS5000 refers to the predominant frequency of any vibrations on the generator set).

NOTICE

Exceeding either of the above specifications will have a detrimental effect on the life of the bearings and other components, and may invalidate the alternator warranty.

NOTICE

The terminal box is designed to support the fitted busbars or terminals, transformers, load cables and auxiliary terminal box. Additional mass could cause excessive vibration and lead to failure of the terminal box enclosure and mounting. Refer to the Installation Manual to connect the load cables to the terminal box. Refer to CGT before fixing any additional mass to the terminal box.

5.7.1 Definition of BS5000–3

Alternators shall be capable of continuously withstanding linear vibration levels with amplitudes of 0.25 mm between 5 Hz and 8 Hz, and velocities of 9.0 mm/s RMS between 8 Hz and 200 Hz, when measured at any point directly on the carcass or main frame of the machine. These limits refer only to the predominant frequency of vibration of any complex waveform.

5.7.2 Definition of ISO 8528-9

ISO 8528-9 refers to a broad band of frequencies; the broad band is taken to be between 10 Hertz and 1000 Hertz. The table below is an extract from ISO 8528-9 (Table C.1, value 1). This simplified table lists the vibration limits by kVA and speed for acceptable operation of standard generator set designs.


5.7.3 Linear Vibration Limits

Linear Vibration Levels As Measured On The Alternator - S01/S02/S12				
Engine Speed RPM (min ⁻¹)	Power Output S (kVA)	Vibration Displacement RMS (mm)	Vibration Velocity RMS (mm/s)	Vibration Acceleration RMS (mm/s ²)
2000 ≤ RPM ≤ 3600	S ≤ 50	0.8	50	31
	50 < S	0.64	40	25
1300 ≤ RPM < 2000	4 < S ≤ 50	0.64	40	25
	50 < S ≤ 125	0.4	25	16

The broad band is taken as 10 Hz - 1000 Hz

5.7.4 Linear Vibration Monitoring

We recommend using vibration analyzing equipment to measure vibration at the positions shown below. Check that vibration of the generator set is below the limits stated in the standards. If vibration is above the limits, the generator set builder should investigate the root causes and eliminate them. Best practice is for the generator set builder to take initial readings as a reference and for the user to periodically monitor vibration, according to the recommended service schedule, to detect a deteriorating trend.



5.7.5 Excessive Vibration

⚠ WARNING

Ejected Debris

Debris ejected during catastrophic failure can cause serious injury or death by impact, severing or stabbing.

To prevent injury:

- ***Keep away from the air inlet and air outlet when the alternator is running.***
- ***Do not put operator controls near the air inlet and air outlet.***
- ***Do not cause overheating by running the alternator outside rating plate parameters.***
- ***Do not overload the alternator.***
- ***Do not run an alternator with excessive vibration.***
- ***Do not synchronize parallel alternators outside the specified parameters.***

If the measured vibration of the generator set is not within the limits:

1. The generator set manufacturer should change the generator set design to reduce the vibration levels as much as possible.
2. Contact Cummins Generator Technologies to assess the impact on bearing and alternator life expectancy.

5.8 Bearings

5.8.1 Sealed Bearings

Inspect sealed-for-life bearings periodically, according to the recommended service schedule ([Section 7.1 on page 31](#)). Check for signs of wear, fretting or other detrimental features. Damage to seals, grease leakage or discoloration of the bearing races indicate that the bearing may need to be replaced.

5.8.2 Bearing Life

Factors that reduce bearing life or lead to bearing failure include:

- Adverse operating conditions and environment
- Stress caused by misalignment of the generator set
- Vibration from the engine that exceeds the limits in BS 5000-3 and ISO 8528-9
- Long periods (including transportation) when the alternator is stationary and subjected to vibration can cause false brinelling wear (flats on the balls and grooves on the races)
- Humid or wet conditions that cause corrosion and deterioration of the grease by emulsification.

5.8.3 Health Monitoring of the Bearings

We recommend that the user checks the bearing condition using vibration monitoring equipment. Best practice is to take initial readings as a reference and periodically monitor the bearings to detect a deteriorating trend. It will then be possible to plan a bearing change at an appropriate generator set or engine service interval.

5.8.4 Bearing Service Life Expectancy

Bearing manufacturers recognize that the service life of bearings depends on factors that are outside their control. Rather than quote a service life, practicable replacement intervals are based on the L10 life of the bearing, the type of grease, and the recommendations of the bearing and grease manufacturers.

For general purpose applications: If the correct maintenance is carried out, vibration levels do not exceed the levels stated in ISO 8528-9 and BS5000-3, and the ambient temperature does not exceed 50 °C, plan to replace the bearings within 30,000 hours of operation.

If in doubt regarding any aspect of bearing life of a STAMFORD alternator, contact the nearest authorized supplier of the alternator or contact the STAMFORD factory.

5.8.5 Standby Applications

Run alternators in standby applications at no load for a minimum of 10 minutes every week. For alternators fitted with regreasable bearings, re-grease the bearings every 6 months, regardless of the number of accumulated running hours.

-



This page is intentionally blank.

6 Installation into the Generator Set

6.1 Alternator Dimensions

Dimensions are included in the data sheet specific to the alternator model. Refer to the rating plate to identify the alternator model.

NOTICE

Data sheets are available from www.stamford-avk.com

6.2 Lifting the Alternator

WARNING

Falling Mechanical Parts

Falling mechanical parts can cause serious injury or death by impact, crushing, severing or trapping.

To prevent injury and before lifting the alternator:

- ***Do not lift the complete generator set by the alternator lifting fixtures.***
- ***Keep the alternator horizontal when lifting.***
- ***Fit drive end and non-drive end transit fittings to single bearing alternators to keep the main rotor in the frame.***

Lift the alternator by hooks or shackles attached to the lifting points (lugs or eyes) provided. A label attached to a lifting point shows the correct lifting arrangement. Use chains or lifting straps of appropriate length, and a spreader bar if necessary, to make sure that the chains or lifting straps are vertical when lifting. Make sure that the capability of the lifting equipment is sufficient for the alternator mass shown on the label.




FIGURE 4. LIFTING LABELS

6.3 Storage

If the alternator will not be used immediately, it must be stored in a clean, dry, vibration-free environment. We recommend the use of anti-condensation heaters, when available.

If the alternator can be rotated, turn the rotor a minimum of 6 revolutions every month during storage.

6.3.1 After Storage

After a period of storage, carry out the pre-running checks to determine the condition of the windings. If the windings are damp or the insulation resistance is low, follow one of the drying out procedures (see [Chapter 7 on page 31](#)).

Before putting the alternator into service, refer to the following table.

TABLE 5.

	Not Rotated during Storage	Rotated during Storage
Sealed Bearing(s)	<p>If stored less than 12 months, put the alternator into service.</p> <p>If stored more than 12 months, replace the bearing(s) then put the alternator into service.</p>	<p>If stored less than 24 months, put the alternator into service.</p> <p>If stored more than 24 months, replace the bearing(s) then put the alternator into service.</p>

6.4 Vibration Frequencies

The main vibration frequencies produced by the alternator are as follows:

- 4-pole 1500 RPM 25 Hz
- 4-pole 1800 RPM 30 Hz

Vibrations induced in the alternator by the engine are complex. It is the responsibility of the generator set designer to ensure that the alignment and stiffness of the bedplate and mountings do not allow vibration to exceed BS5000 part 3 and ISO 8528 part 9 limits.

6.5 Generator Set Coupling

⚠ WARNING

Moving Mechanical Parts

Moving mechanical parts during generator set coupling can cause serious injury by crushing, severing or trapping.

To prevent injury, keep arms, hands and fingers away from mating surfaces when coupling the generator set.

NOTICE

Do not attempt to rotate the alternator rotor by levering against the vanes of the cooling fan. The fan is not designed to withstand such forces and will be damaged.



Efficient operation and long component life depend on minimizing mechanical stresses on the alternator. When coupled in a generator set, misalignment and vibration interactions with the prime mover engine can cause mechanical stress.

Generator sets need a substantial, flat, continuous bedplate to suit the installation site floor loading, with engine and alternator mounting pads to make a firm base for accurate alignment. The height of all mounting pads must be within 0.25 mm for skid mounting, 3 mm for non-adjustable anti-vibration mounts (AVM), or 10 mm for adjustable height AVMs. Use shims to achieve level. The rotational axes of the alternator rotor and engine output shaft must be coaxial (radial alignment) and perpendicular to the same plane (angular alignment). The axial alignment of the alternator and engine coupling must be within 0.5 mm, to allow for thermal expansion without unwanted axial force on the bearings at operating temperature.

Vibration can occur by flexing of the coupling. The alternator is designed for a maximum bending moment not exceeding 17 kgm (125 lbs-ft). Check the maximum bending moment of the engine flange with the engine manufacturer.

Close-coupling of alternator and engine can increase the rigidity of the generator set. Both single and two bearing alternators can be close-coupled. The generator set builder must supply guarding for open-coupled applications.

To prevent rust during transit and storage, the alternator frame spigot, rotor coupling plates, and shaft extension have been treated with a rust preventative coating. Remove this before coupling the generator set.

To prevent movement of the rotor during transport, a drive end (DE) transit bracket is fitted. Remove the DE transit bracket and fasteners from the DE bracket before coupling the generator set.




FIGURE 5. SINGLE BEARING ALTERNATOR ROTOR SHOWING COUPLING DISCS BOLTED TO DRIVE END COUPLING HUB (AT RIGHT)

6.5.1 Single Bearing

⚠ WARNING


Falling Mechanical Parts

Falling mechanical parts can cause serious injury or death by impact, crushing, severing or trapping.

To prevent injury and before lifting the alternator:

- *Do not lift the complete generator set by the alternator lifting fixtures.*
- *Keep the alternator horizontal when lifting.*
- *Fit drive end and non-drive end transit fittings to single bearing alternators to keep the main rotor in the frame.*

1. If supplied, check that the bracket which supports the rotor underneath the fan hub is fitted in position .
2. Position the alternator close to the engine and remove the drive end transit bracket that keeps the rotor in place during transport.
3. Remove the air outlet covers from the drive end of the alternator to access the coupling and adaptor bolts.



4. If required, tighten the coupling disc bolts in the sequence shown above. See [Chapter 8 on page 47](#) for tightening torque.
5. Check the torque of bolts that fasten the coupling discs to the DE coupling hub in a clockwise direction around the bolt circle.
6. Make sure the coupling discs are concentric with the adaptor spigot. Use alignment studs to ensure that the disc and the flywheel are in alignment.
7. Make sure the axial distance from the coupling mating face on the flywheel to the mating face on the flywheel housing is within 0.5mm of nominal dimension. This ensures that the engine crankshaft float is maintained and the alternator rotor position is neutral, allowing for thermal expansion. There is no axial pre-load thrust on the engine or alternator bearings.
8. Offer the alternator to the engine and engage coupling discs and housing spigots at the same time, pushing the alternator towards the engine until the coupling discs are against the flywheel face and the housing spigots are located.


NOTICE

Do not pull the alternator to the engine using bolts through the flexible discs.

NOTICE

Failure to secure bolts can lead to excessive vibration, which in turn can lead to catastrophic alternator failure.

9. Fit heavy gauge washers under the heads of housing and coupling bolts. Screw in the bolts evenly around the coupling assembly to maintain correct alignment.




10. Tighten the bolts to fix the coupling disc to the flywheel, in the sequence shown above.
11. Check the torque of each bolt in a clockwise direction around the bolt circle to ensure all the bolts are tight. Refer to the engine manufacturer's manual for correct tightening torque.
12. Replace all covers.

6.6 Pre-Running Checks

Before starting the generator set, test the insulation resistance of windings and check that all connections are tight and in the correct location. Make sure the alternator air path is clear of obstructions. Replace all covers.

6.7 Direction of Rotation

The fan is designed for clockwise rotation, as viewed from the drive end of the alternator (unless otherwise specified when ordered). If the alternator must run counter-clockwise, please seek advice from Cummins Generator Technologies.



6.8 Phase Rotation

Main stator output is connected for a phase sequence of U V W when the alternator runs clockwise, as viewed from the drive end. If the phase rotation must be reversed, the customer must re-connect the output cables in the terminal box. Ask Cummins Generator Technologies for a circuit diagram of 'reverse phase connections'.

6.9 Voltage and Frequency

Check that the voltage and frequency shown on the alternator rating plate meet the requirements of the generator set application.

6.10 AVR Settings

The AVR is factory set for initial running tests. Check that the AVR settings are compatible with your required output. Refer to detailed instructions in the AVR manual for on- and off-load adjustments.

6.11 Electrical Connections

WARNING

Incorrect Electrical Installation and System Protection

Incorrect electrical installation and system protection can cause serious injury or death by electric shock and burns.

To prevent injury, installers must be qualified and are responsible for meeting appropriate inspectorate and local electricity authority requirements and site safety rules.

NOTICE

The terminal box is designed to support the fitted busbars or terminals, transformers, load cables and auxiliary terminal box. Additional mass could cause excessive vibration and lead to failure of the terminal box enclosure and mounting. Refer to CGT before fixing any additional mass to the terminal box.

Fault current curves and alternator reactance values are available on request from the factory so that the system designer can calculate the necessary fault protection and/or discrimination.

The installer must check that the alternator frame is bonded to the generator set bedplate, and must bond to site earth. If anti-vibration mounts are fitted between the alternator frame and its bedplate, a suitably-rated earth conductor must bridge across the anti-vibration mount.

Refer to wiring diagrams for electrical connection of the load cables. Electrical connections are made in the terminal box. Route single core cables through the insulated or non-magnetic gland plates supplied. Panels must be removed to be drilled or cut to prevent swarf entering the terminal box or alternator. After wiring, inspect the terminal box, remove all debris using a vacuum cleaner if necessary and check that no internal components are damaged or disturbed.

As standard, the alternator neutral is not bonded to the alternator frame. If required, neutral may be connected to the earth terminal in the terminal box, by a conductor of at least one half of the sectional area of a phase lead.

Load cables must be supported appropriately to avoid a tight radius at the point of entry into the terminal box, clamped at the terminal box gland, and allow at least ± 25 mm movement by the alternator on its anti-vibration mountings, without causing excessive stress to the cables and alternator load terminals.

The palm (flattened part) of load cable lugs must be clamped in direct contact with the main stator output conductors so that the whole palm area conducts the output current. The tightening torque of fasteners is 6 to 6.6 Nm.

-



This page is intentionally blank.

7 Service and Maintenance

7.1 Recommended Service Schedule

Refer to Safety Precautions section ([Chapter 2 on page 3](#)) of this manual before starting any service and maintenance activity.

Refer to Parts Identification section ([Chapter 8 on page 47](#)) for an exploded view of components and fastener information.

The recommended service schedule shows the recommended service activities in table rows, grouped by alternator subsystem. Columns of the table show the types of service activity, whether the alternator must be running, and the service levels. Service frequency is given in running hours or time interval, whichever is sooner. A cross (X) in the cells where a row intersects the columns shows a service activity type and when it is required. An asterisk (*) shows a service activity done only when necessary.

All service levels in the recommended service schedule can be purchased directly from Cummins Generator Technologies Customer Service Department,

Telephone: +44 1780 484732,

Email: emea.service@cummins.com

1. Proper service and repair are vital to the reliable operation of your alternator and the safety of anyone coming into contact with the alternator.
2. These service activities are intended to maximize the life of the alternator but shall not vary, extend or change the terms of the manufacturer's standard warranty or your obligations in that warranty.
3. Each service interval is a guide only, and developed on the basis that the alternator was installed and is operated in accordance with the manufacturer's guidelines. If the alternator is located and/or operated in adverse or unusual environmental conditions, the service intervals may need to be more frequent. The alternator should be continually monitored between services to identify any potential failure modes, signs of misuse, or excessive wear and tear.

TABLE 6. ALTERNATOR SERVICE SCHEDULE

System	SERVICE ACTIVITY X = required * = if necessary	Alternator running	TYPE				SERVICE LEVEL								
			Inspect	Test	Clean	Replace	Commission	Post Commission	250 hrs / 0.5 year	Level 1	1000 hrs / 1 year	Level 2	10,000 hrs / 2 years	Level 3	30,000 hrs / 5 years
Alternator	Alternator rating		X				X								
	Bedplate arrangement		X				X								
	Coupling arrangement		X				X				*		X		
	Environmental conditions and cleanliness		X				X	X	X	X	X	X	X		
	Ambient temperature (inside & outside)			X			X	X	X	X	X	X	X		
	Complete machine - damage, loose parts & earth bonds		X				X	X	X	X	X	X	X		
	Guards, screens, warning and safety labels		X				X	X	X	X	X	X	X		
	Maintenance access		X				X								
	Electrical nominal operating conditions & excitation	X		X			X	X	X	X	X	X	X		
	Vibration	X		X			X	X	X	X	X	X	X		
Windings	Condition of windings		X				X	X	X	X	X	X	X		
	Insulation resistance of all windings (PI test for MV/HV)			X			X	*	*	X	X	X	X		
	Insulation resistance of rotor, exciter and AUX			X				X	X						
Bearings	Condition of bearings		X				X							X	
	Sealed bearing(s)		X					every 4000 to 4500 hours							
	Sealed bearing(s)					X					*		X		
Terminal Box	All alternator/customer connections and cabling		X				X	X	X	X	X	X	X		

System	SERVICE ACTIVITY X = required * = if necessary	Alternator running	TYPE				SERVICE LEVEL								
			Inspect	Test	Clean	Replace	Commission	Post Commission	250 hrs / 0.5 year	Level 1	1000 hrs / 1 year	Level 2	10,000 hrs / 2 years	Level 3	30,000 hrs / 5 years
Controls & Auxiliaries	Initial AVR set up	X		X			X								
	AVR settings	X		X				X	X	X	X				
	Customer connection of auxiliaries			X			X		X	X	X	X			
	Function of auxiliaries			X			X	X	X	X	X	X	X		
	Anti condensation heater					X						*	X		
Rectifier	Diodes and varistors		X				X	X	X	X	X				
	Diodes and varistors					X								X	
Cooling	Air inlet temperature	X		X			X	X	X	X	X	X	X		
	Air flow (rate & direction)	X	X				X								
	Condition of fan		X				X	X	X	X	X	X	X		

7.2 Bearings

7.2.1 Introduction

NOTICE
<p>Store removed parts and tools in static- and dust-free conditions, to prevent damage or contamination.</p> <p>A bearing is damaged by the axial force needed to remove it from the rotor shaft. Do not reuse a bearing.</p> <p>A bearing is damaged if the insertion force is applied through the bearing balls. Do not press fit the outer race by force on the inner race, or vice versa.</p> <p>Do not try to turn the rotor by levering against the cooling fan vanes. The fan will be damaged.</p>

The alternator rotor is supported by a bearing at the non-drive end (NDE) and a coupling to the prime mover at the drive end (DE).

- Refer to guidelines for bearings in the alternator applications ([Section 5.8 on page 21](#)) and storage ([Section 6.3](#)) sections of this manual.
- Inspect the bearing according to the recommended service schedule. Seek advice from CGT if grease has leaked out of the bearing, notifying the bearing type and quantity leaked.
- Replace the bearing according to the recommended service schedule by one of identical type (stamped on the bearing), sourced from the original equipment manufacturer (OEM). Contact CGT for advice if an exact replacement is not available.

7.2.2 Safety

DANGER

Rotating Mechanical Parts

Rotating mechanical parts can cause serious injury or death by crushing, severing or trapping.

To prevent injury and before removing covers over rotating parts, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

WARNING

Hot Surfaces

Skin contact with hot surfaces can cause serious injury by burns.

To prevent injury, wear appropriate personal protection equipment (PPE).

CAUTION

Grease

Skin contact with grease can cause minor or moderate injury by contact dermatitis.

To prevent injury, wear appropriate personal protection equipment (PPE).

NOTICE

Do not overfill a bearing with grease; the bearing may be damaged.

Do not mix lubricant types. Change gloves to handle different lubricant

Assemble bearings in static- and dust-free conditions while wearing lint free gloves.

Store removed parts and tools in static- and dust-free conditions, to prevent damage or contamination.

A bearing is damaged by the axial force needed to remove it from the rotor shaft. Do not reuse a bearing.

A bearing is damaged if the insertion force is applied through the bearing balls. Do not press fit the outer race by force on the inner race, or vice versa.

Do not try to turn the rotor by levering against the cooling fan vanes. The fan will be damaged.

7.3 Controls

7.3.1 Introduction

An operating alternator is a harsh environment for control components. Heat and vibration can cause electrical connections to loosen and cables to fail. Routine inspection and test can identify an issue before it becomes a failure that incurs unplanned downtime.

7.3.2 Safety

DANGER

Live Electrical Conductors

Live electrical conductors can cause serious injury or death by electric shock and burns.

To prevent injury and before removing covers over electrical conductors, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

⚠ WARNING

Hot Surfaces

Skin contact with hot surfaces can cause serious injury by burns.

To prevent injury, wear appropriate personal protection equipment (PPE).

7.3.3 Requirements

Personal Protective Equipment (PPE)	Wear mandatory site PPE
Consumables	None
Parts	None
Tools	Multimeter
	Torque wrench

7.3.4 Inspect and Test

1. Remove the terminal box lid
2. Check the tightness of fasteners securing the load cables.
3. Check that cables are firmly clamped at the terminal box gland, and allow ± 25 mm movement by an alternator on anti-vibration mounts.
4. Check that all cables are anchored and unstressed within the terminal box.
5. Check all cables for signs of damage.
6. Check that AVR accessories and current transformers are correctly fitted, and cables pass centrally through current transformers (if fitted).
7. If an anti-condensation heater is fitted
 - a. Isolate the supply and measure the electrical resistance of the heater element(s). Replace the heater element if open circuit.
 - b. Test the supply voltage to the anti-condensation heater at the heater connection box. 120 VAC or 240 VAC. (depending on cartridge option and shown on a label) should be present when the alternator is stopped.
8. Check that the AVR and AVR accessories fitted in the terminal box are clean, securely fitted on anti-vibration mounts, and the cable connectors are firmly attached to the terminals.
9. For parallel operation*, check that the synchronization control cables are securely connected. (*not applicable to S0 and S1 alternators)
10. Refit and secure the terminal box lid.

7.4 Cooling System

7.4.1 Introduction

The alternators are designed to meet standards supporting EU Safety Directives, and are rated for the effect of operating temperature on winding insulation.

BS EN 60085 (≡ IEC 60085) Electrical insulation – Thermal Evaluation and Designation classifies insulation by the maximum operating temperature for a reasonable service life. Although chemical contamination and electrical and mechanical stresses also contribute, temperature is the dominant aging factor. Fan cooling maintains a stable operating temperature below the insulation class limit.

If the operating environment differs from the values shown on the rating plate, rated output must be reduced by

- 3% for class H insulation for every 5 °C that the temperature of the ambient air entering the cooling fan exceeds 40 °C, up to a maximum of 60 °C
- 3% for every 500 m increase in altitude above 1000 m, up to 4000 m, due to the reduced thermal capacity of lower density air, and
- 5% if air filters are fitted, due to restricted air flow.

Efficient cooling depends on maintaining the condition of the cooling fan, air filters and gaskets.

7.4.2 Safety

 DANGER
<p>Rotating Mechanical Parts <i>Rotating mechanical parts can cause serious injury or death by crushing, severing or trapping.</i> <i>To prevent injury and before removing covers over rotating parts, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.</i></p>

 WARNING
<p>Hot Surfaces <i>Skin contact with hot surfaces can cause serious injury by burns.</i> <i>To prevent injury, wear appropriate personal protection equipment (PPE).</i></p>

 CAUTION
<p>Dust <i>Inhaling dust can cause minor or moderate injury by irritating the lungs. Dust can cause minor or moderate injury by irritating the eyes.</i> <i>To prevent injury, wear appropriate personal protection equipment (PPE). Ventilate the area to disperse dust.</i></p>

NOTICE
<p>Do not attempt to rotate the alternator rotor by levering against the vanes of the cooling fan. The fan is not designed to withstand such forces and will be damaged.</p>

NOTICE
<p>Filters are designed to remove dust, not moisture. Wet filter elements can cause reduced air flow and overheating. Do not allow filter elements to get wet.</p>

7.4.3 Requirements

Personal Protective Equipment (PPE)	Wear mandatory site PPE
	Wear eye protection
	Wear respiratory protection
Consumables	Lint-free cleaning cloths
	Thin disposable gloves
Parts	None

Tools	None
-------	------

7.4.4 Inspect and Clean

1. Remove the DE adapter screen.
2. Inspect the fan for damaged vanes and cracks.
3. Re-install the DE adapter screen.
4. Reinstall the generator set for running.
5. Make sure the air inlets and outlets are not blocked.

7.5 Coupling

7.5.1 Introduction

Efficient operation and long component life rely on minimizing mechanical stresses on the alternator. When coupled in a generator set, misalignment and vibration interactions with the prime mover engine can cause mechanical stress.


The rotational axes of alternator rotor and engine output shaft must be coaxial (radial and angular alignment).

Torsional vibration can cause damage to internal combustion engine shaft-driven systems, if not controlled. The generator set manufacturer is responsible for assessing the effect of torsional vibration on the alternator: Rotor dimensions and inertia, and coupling details are available on request.

7.5.2 Safety

NOTICE

Do not attempt to rotate the alternator rotor by levering against the vanes of the cooling fan. The fan is not designed to withstand such forces and will be damaged.



7.5.3 Requirements

Personal Protective Equipment (PPE)	Wear mandatory site PPE
Consumables	None
Parts	None
Tools	Dial gauge
	Torque wrench

7.5.4 Inspect Mounting Points

1. Check the generator set bedplate and mounting pads are in good condition, not cracked
2. Check that rubber in anti-vibration mounts has not perished
3. Check vibration monitoring historical records for a trend of increasing vibration

7.5.4.1 Single Bearing Coupling

1. Remove the DE adapter screen to access the coupling
2. Check that the coupling discs are not damaged, cracked or distorted, and the coupling disc holes are not elongated. If any are damaged, replace the complete set of discs.
3. Check tightness of bolts fixing the coupling discs to the engine flywheel. Tighten in the sequence shown for alternator coupling in the Installation chapter ([Section 6.5.1 on page 26](#)), to the torque recommended by the engine manufacturer.
4. Refit the DE adapter screen.

7.6 Rectifier System

7.6.1 Introduction

The rectifier converts alternating current (AC) induced in the exciter rotor windings into direct current (DC) to magnetize the main rotor poles. The rectifier comprises two semicircular annular positive and negative plates, each with three diodes. In addition to connecting to the main rotor, the DC output of the rectifier also connects to a varistor (S1 only). The varistor protects the rectifier from voltage spikes and surge voltages that may be present on the rotor under various loading conditions of the alternator.

Diodes provide a low resistance to current in one direction only: Positive current will flow from anode to cathode, or another way of viewing it is that negative current will flow from cathode to anode.

The exciter rotor windings are connected to 3 diode anodes to form the positive plate and to 3 diode cathodes to form the negative plate to give full wave rectification from AC to DC. The rectifier is mounted on, and rotates with, the exciter rotor at the non-drive end (NDE).

7.6.2 Safety

 **DANGER**

Live Electrical Conductors

Live electrical conductors can cause serious injury or death by electric shock and burns.
To prevent injury and before removing covers over electrical conductors, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

 **DANGER**

Rotating Mechanical Parts

Rotating mechanical parts can cause serious injury or death by crushing, severing or trapping.
To prevent injury and before removing covers over rotating parts, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

7.6.3 Requirements

Personal Protective Equipment (PPE)	Wear appropriate PPE.
Consumables	Loctite 241 thread locking adhesive
	Midland silicone heat sink compound type MS2623 or similar
	Solder
	Solder remover wick
Parts	Full set of three anode lead diodes and three cathode lead diodes (all from the same manufacturer)
	One varistor (S1 only)
Tools	Multimeter
	Insulation tester
	Torque wrench
	Soldering gun

7.6.4 Test and Replace Varistor (S1 only)

1. Inspect the varistor.
2. Record varistor as faulty if there are signs of overheating (discoloration, blisters, melting) or disintegration.
3. Disconnect one varistor lead. Store fastener and washers.
4. Measure the resistance across the varistor. Good varistors have a resistance greater than 100 MΩ.
5. Record the varistor as faulty if the resistance is short circuit or open circuit in either direction. (Some multimeters will read O.L. at high resistance levels. Please be aware of the limits of your tools.)
6. If the varistor is faulty, replace it and replace all diodes.
7. Reconnect and check that all leads are secure, washers fitted and fasteners tight.

7.6.5 Test and Replace Diodes

 WARNING
Hot Surfaces <i>Skin contact with hot surfaces can cause serious injury by burns.</i> <i>To prevent injury, wear appropriate personal protection equipment (PPE).</i>


NOTICE
Do not tighten a diode above the stated torque. The diode will be damaged.

NOTICE
Remove NDE bracket to access diodes for S0L1 frame only.

NOTICE
Make sure no solder falls onto any component of the alternator.

NOTICE

1. Using a soldering gun and solder wick, remove the solder that connects the exciter rotor lead to one diode.



2. Measure the voltage drop across the diode in the forward direction, using the diode test function of a multimeter.
3. Measure the resistance across the diode in the reverse direction, using the 1000 VDC test voltage of an insulation tester.
4. Diode is faulty if the voltage drop in the forward direction is outside the range 0.3 to 0.9 V, or the resistance is below 20 M Ω in the reverse direction.
5. Repeat the tests for the five remaining diodes.
6. If any diode is faulty, replace the full set of six diodes (same type, same manufacturer):
 - a. Remove diode(s).
 - b. Apply a small amount of heat sink compound **only** to the base of the replacement diode(s), not the threads.
 - c. Check polarity of diode(s).
 - d. Screw each replacement diode into a threaded hole in the rectifier plate.
 - e. Apply 2.0 to 2.25 Nm (18 to 20 in-lb) torque to give good mechanical, electrical and thermal contact.
 - f. Replace the varistor (S1 only).

NOTICE

Make sure no solder falls onto any component of the alternator.

- Using a solder gun and solder, reconnect and check that all leads are secure and correctly soldered.

7.7 Windings

7.7.1 Introduction

NOTICE

Disconnect all control wiring and customer load leads from alternator winding connections before conducting these tests.

NOTICE

The Automatic Voltage Regulator (AVR) contains electronic components which would be damaged by high voltage applied during insulation resistance tests. The AVR must be disconnected before doing any insulation resistance test. Temperature sensors must be grounded to earth before doing any insulation resistance test.

Damp or dirty windings have a lower electrical resistance and could be damaged by insulation resistance tests at high voltage. If in doubt, test the resistance at low voltage (500 V) first.

Alternator performance depends on good electrical insulation of the windings. Electrical, mechanical and thermal stresses, and chemical and environmental contamination, cause the insulation to degrade. Various diagnostic tests indicate the condition of insulation by charging or discharging a test voltage on isolated windings, measuring current flow, and calculating the electrical resistance by Ohm's law.

When a DC test voltage is first applied, three currents can flow:

- **Capacitive Current:** To charge the winding to the test voltage (decays to zero in seconds),
- **Polarizing Current:** To align the insulation molecules to the applied electric field (decays to near-zero in ten minutes), and
- **Leakage Current:** Discharge to earth where the insulation resistance is lowered by moisture and contamination (increases to a constant in seconds).

For an insulation resistance test, a single measurement is made one minute after a DC test voltage is applied, when capacitive current has ended. For the polarization index test, a second measurement is made after ten minutes. An acceptable result is where the second insulation resistance measurement is at least double the first, because the polarization current has decayed. In poor insulation, where leakage current dominates, the two values are similar. A dedicated Insulation Tester takes accurate, reliable measurements and may automate some tests.

7.7.2 Safety

DANGER

Live Electrical Conductors

Live electrical conductors can cause serious injury or death by electric shock and burns.

To prevent injury and before removing covers over electrical conductors, isolate the generator set from all energy sources, remove stored energy and use lock out/tag out safety procedures.

⚠ WARNING

Live Electrical Conductors

Live electrical conductors at the winding terminals after an insulation resistance test can cause serious injury or death by electric shock or burns.

To prevent injury, discharge the windings by shorting to earth through an earthing rod for at least 5 minutes.

7.7.3 Requirements

Type	Description
Personal Protective Equipment (PPE)	Wear mandatory site PPE
Consumables	None
Parts	None
Tools	Insulation test meter
	Multimeter
	Milliohm Meter or Micro Ohmmeter
	Clamp Ammeter
	Infrared thermometer
	Earth rod

7.7.4 Test the Electrical Resistance of Windings

1. Stop the alternator.
2. Verify the electrical resistance of the exciter field (stator) winding:
 - a. Disconnect the exciter field leads F1 and F2 from the AVR.
 - b. Measure and record the electrical resistance between F1 and F2 leads with a multimeter.
 - c. Reconnect the exciter field leads F1 and F2.
3. Verify the electrical resistance of the exciter armature (rotor) winding:
 - a. Mark the leads attached to diodes on one of the two rectifier plates.
 - b. Using a solder gun and solder wick, desolder all exciter rotor leads from all diodes at the rectifier.
 - c. Measure and record the electrical resistance between pairs of marked leads (between phase windings). A specialist micro ohmmeter must be used.
 - d. Using a solder gun and solder, reconnect all exciter rotor leads to the diodes.
 - e. Make sure the fasteners are secure.
4. Verify the electrical resistance of the main field (rotor) winding:
 - a. Main rotor winding resistance can be taken directly from the rectifier studs/plates.
 - b. Measure and record the electrical resistance between the main rotor leads and the rectifier studs/plates (+ve and -ve). A specialist micro ohmmeter must be used.
5. Verify the electrical resistance of the main armature (stator) winding:
 - a. Disconnect the leads of the main stator from the output terminals.
 - b. Measure and record the electrical resistance between U1 and U2 leads and between U5 and U6 (if present). A specialist micro ohmmeter must be used.

- c. Measure and record the electrical resistance between V1 and V2 leads and between V5 and V6 (if present). A specialist micro ohmmeter must be used.
 - d. Measure and record the electrical resistance between W1 and W2 leads and between W5 and W6 (if present). A specialist micro ohmmeter must be used.
 - e. Reconnect the leads to the output terminals, as before.
 - f. Make sure the fasteners are secure.
6. Verify the resistance of Auxiliary winding (if fitted):
 - a. Disconnect the auxiliary winding leads 7 and Z2 from the AVR.
 - b. Measure and record the electrical resistance between 7 and Z2 leads with a multimeter.
 - c. Reconnect the auxiliary winding leads 7 and Z2 to the AVR.
 7. Refer to the Technical Data ([Chapter 9 on page 49](#)) to verify the measured resistances of all windings agree with the reference values.

7.7.5 Test the Insulation Resistance of Windings

NOTICE

The alternator must not be put into service until the minimum insulation resistance is achieved.

TABLE 7. TEST VOLTAGE AND MINIMUM ACCEPTABLE INSULATION RESISTANCE FOR NEW AND IN-SERVICE ALTERNATORS

	Test Voltage (V)	Minimum Insulation Resistance at 1 minute (MΩ)	
		New	In-service
Main stator	500	10	5
Aux. Winding	500	10	5
Exciter stator	500	10	5
Exciter rotor, rectifier & main rotor combined	500	10	5

1. Inspect the windings for mechanical damage or discoloration from overheating. Clean the insulation if there is hygroscopic dust and dirt contamination.
2. For main stators:
 - a. Ensure AVR sensing harness is disconnected before test.
 - b. Disconnect and ground auxiliary winding (if fitted).
 - c. Disconnect the neutral to earth conductor (if fitted).
 - d. Connect together the three leads of all phase windings (if possible).
 - e. Apply the test voltage from the table between any phase lead and earth.
 - f. Measure the insulation resistance after 1 minute (IR_{1min}).
 - g. Discharge the test voltage with an earth rod for five minutes.
 - h. If the measured insulation resistance is less than the minimum acceptable value, dry the insulation, then repeat the method.
 - i. Reconnect neutral to earth conductor (if fitted), AVR sensing harness and auxiliary winding connection.

-
3. For Auxiliary winding and exciter stators, and combined exciter and main rotors:
 - a. Ground main stator winding during the test.
 - b. Connect together both ends of the winding (if possible).
 - c. Apply the test voltage from the table between the winding and earth.
 - d. Measure the insulation resistance after 1 minute (IR_{1min}).
 - e. Discharge the test voltage with an earth rod for five minutes.
 - f. If the measured insulation resistance is less than the minimum acceptable value, dry the insulation, then repeat the method.
 - g. Repeat the method for each winding.
 - h. Remove the connections made for testing.
 - i. Remove the grounding connection.

7.7.6 Dry the Insulation

Use the methods below to dry the insulation of the main stator windings. To prevent damage as water vapor is expelled from the insulation, make sure the winding temperature does not increase faster than 5 °C per hour or exceed 90 °C.

Plot the insulation resistance graph to show when drying is complete.

7.7.6.1 Dry with Ambient Air

In many cases, the alternator can be dried sufficiently using its own cooling system. Disconnect the cables from the X+ (F1) and XX- (F2) terminals of the AVR so there is no excitation voltage supply to the exciter stator. Run the generator set in this de-excited state. Air must flow freely through the alternator to remove the moisture. Operate the anti-condensation heater (if fitted) to assist the drying effect of the air flow.

After drying is complete, re-connect the cables between the exciter stator and AVR. If the generator set is not put into service immediately, turn on the anti-condensation heater (if fitted) and retest the insulation resistance before use.

7.7.6.2 Dry with Hot Air


Direct the hot air from one or two 1 to 3 kW electrical fan heaters into the alternator air inlet. Make sure each heat source at least 300 mm away from the windings to avoid scorching or over-heating damage to the insulation. Air must flow freely through the alternator to remove the moisture.

After drying, remove the fan heaters and re-commission as appropriate.

If the generator set is not put into service immediately, turn on the anti-condensation heaters (where fitted) and retest the insulation resistance before use.

7.7.6.3 Plot IR Graph

Whichever method is used to dry out the alternator, measure the insulation resistance and temperature (if sensors fitted) of the main stator windings every 15 to 30 minutes. Plot a graph of insulation resistance, IR (y axis) against time, t (x axis).



A typical curve shows an initial increase in resistance, a fall and then a gradual rise to a steady state; if the windings are only slightly damp the dotted portion of the curve may not appear. Continue drying for another hour after steady state is reached.

NOTICE

The alternator must not be put into service until the minimum insulation resistance is achieved.


-



This page is intentionally blank.

8 Parts Identification

8.1 S0 and S1 Single Bearing Alternator



8.2 S0 and S1 Parts and Fasteners

Ref	Component	S0L1			S0L2			S1L2		
		Fastener	Quantity	Torque (Nm)	Fastener	Quantity	Torque (Nm)	Fastener	Quantity	Torque (Nm)
1	NDE Cover	M5x12	4	6	M5x12	4	6	M5x12	4	6
2	NDE Bracket	M8x35	4	26	M8x35	4	26	M8x35	4	26
3	NDE Bearing Kit	-	-	-	-	-	-	-	-	-
4	Exciter Stator (Field)	M5	4	6.5	M6	4	10	M6	4	10
5	Exciter Rotor (Armature)	-	-	-	-	-	-	-	-	-
6	Rectifier Assembly	10 UNF	2	2.3 - 3.6	10 UNF	2	2.3 - 3.6	10 UNF	2	2.3 - 3.6
7	Diode / Varistor	10 UNF	2	2.3 - 3.6	10 UNF	2	2.3 - 3.6	10 UNF	2	2.3 - 3.6
8	Terminal Board (3 Ph)	M5x20	2	6	M5x20	2	6	M5x25	2	6

Ref	Component	S0L1			S0L2			S1L2		
		Fastener	Quantity	Torque (Nm)	Fastener	Quantity	Torque (Nm)	Fastener	Quantity	Torque (Nm)
8	Terminal Board (1 Ph)	M5x20	1	6	M5x20	1	6	M5x25	1	6
9	AVR	AVM	4	-	AVM	4	-	AVM	4	-
10	Main Terminal Box to Frame fixing	M5x10	4	6	M5x10	4	6	M5x10	4	6
11	Main Stator (Armature) and Frame	-	-	-	-	-	-	-	-	-
12	Main Rotor (Field) Assembly	-	-	-	-	-	-	-	-	-
13	Fan	-	-	-	-	-	-	-	-	-
14	Coupling Disc (Fastener length as per SAE)	M8	6	43	M10	6	71.3 - 78.8	M12	6	147
15	DE Adapter (Fastener length as per SAE)	M8x35	4	26	M8x35	6	26	M8x35	6	26
16	Foot Plate	M8	4	26	M10	4	47	M10	4	47
17	DE Screen	M5x50	2	6.5	M5x50	2	6.5	M5x50	2	6.5
18	AVR Cover	M5x12	4	6	M5x12	4	6	M5x12	4	5
19	Heater Cartridge	M4x12	2		M4x12	2		M4x12	2	
20	Heater Kit (Terminal Box)	M5x10	2	6.5	M5x10	2	6.5	M5x10	2	6.5

9 Technical Data

NOTICE

Compare measurements with the technical data sheet and the test certificate supplied with the alternator.

9.1 S0/S1 Winding Resistances

Model	Winding	Resistance of windings at 20 °C (measured values should be within 10%)				
		Main Stator L-N (Ohms)	Exciter Stator L-L (Ohms)	Exciter Rotor L-L (Ohms)	Main Rotor (Ohms)	Aux. winding Lead 7-Z2 (Ohms)
S0L1-D1	311	1.9200	13.88	0.1840	0.365	-
S0L1-H1	311	1.1230	13.88	0.1840	0.410	-
S0L1-L1	311	0.8210	17.50	0.2000	0.462	-
S0L1-P1	311	0.6360	17.50	0.2000	0.505	-
S0L1-J1	05	0.4830	13.88	0.1840	0.431	-
S0L1-J1	06	0.3250	13.88	0.1840	0.431	-
S0L1-S1	05	0.2630	17.50	0.2000	0.520	-
S0L1-S1	06	0.1900	17.50	0.2000	0.520	-
S0L2-F1	311/711	0.4900	14.51	0.2680	0.595	4.82
S0L2-G1	311/711	0.4450	14.51	0.2680	0.639	5.77
S0L2-G1	06/706	0.1400	14.51	0.2680	0.639	2.71
S0L2-M1	311/711	0.2880	15.30	0.2100	0.741	5.12
S0L2-M1	06/706	0.0960	15.30	0.2100	0.741	2.55
S0L2-P1	311/711	0.2300	16.00	0.2174	0.800	4.68
S0L2-K1	05/705	0.1840	14.51	0.2680	0.698	4.01
S0L2-U1	05/705	0.1110	16.00	0.2174	0.882	3.70
S0L2-U1	06/706	0.0820	16.00	0.2174	0.882	2.70
S1L2-J1	311/711	0.1965	15.50	0.2244	0.920	4.16
S1L2-K1	05/705	0.0918	15.50	0.2244	0.965	2.83
S1L2-K1	311/711	0.1774	15.50	0.2244	0.965	3.91
S1L2-N1	311/711	0.1286	14.60	0.2440	1.040	3.76
S1L2-R1	05/705	0.0690	14.60	0.2440	1.100	2.53
S1L2-K1	06/706	0.0590	15.50	0.2244	0.965	2.20
S1L2-R1	311/711	0.1140	14.60	0.2440	1.100	3.72

Model	Winding	Resistance of windings at 20 °C (measured values should be within 10%)				
		Main Stator L-N (Ohms)	Exciter Stator L-L (Ohms)	Exciter Rotor L-L (Ohms)	Main Rotor (Ohms)	Aux. winding Lead 7-Z2 (Ohms)
S1L2-N1	06/706	0.0510	14.60	0.2440	1.040	2.38
S1L2-Y1	311/711	0.0841	16.00	0.2752	1.279	3.50
S1L2-G1	06/706	0.0850	15.50	0.2244	0.861	2.50
S1L2-H1	06/706	0.0790	15.50	0.2244	0.891	2.31

10 Service Parts and After Sales Service

10.1 Parts Orders

When ordering parts the machine serial number or machine identity number and type should be quoted, together with the part description. The machine serial number can be found on the name plate or frame.

10.2 Customer Service

Cummins Generator Technologies' service engineers are experienced professionals, trained extensively to deliver the best support possible. Our global service offers:

- On-site a.c. alternator commissioning
- On-site bearing maintenance & bearing condition monitoring
- On-site insulation integrity checks
- On-site AVR & accessories set-up

www.stamford-avk.com

Email: emea.service@cummins.com.

10.3 Recommended Service Parts

In critical applications a set of these service spares should be held with the alternator.

	S0L1	S0L2	S1L2
Description	Part Number	Part Number	Part Number
AS540 Kit	A054P369	A054P369	A054P369
NDE Bearing Kit	A054H811	A054H811	45-0866
Anti-fretting paste	45-0280	45-0280	45-0280
Rectifier service kit	A054H820	A054H820	RSK-1101
Rectifier assembly	A051C308	A054H816	45-0427

-



This page is intentionally blank.

11 End of Life Disposal

Companies specializing in reclaiming material from scrap products can reclaim most of the iron, steel and copper from the alternator. For more details, please contact Customer Service.

11.1 Recyclable material

Mechanically separate the base materials, iron, copper and steel, removing paint, polyester resin, and insulation tape and/or plastics residues from all components. Dispose of this 'waste material'

The iron, steel and copper can now be recycled.

11.2 Items requiring specialist treatment

Remove electrical cable, electronic accessories and plastic materials from the alternator. These components need special treatment to remove the waste from the reclaimable material.

Forward the reclaimed materials for recycling.

11.3 Waste material

Dispose of waste material from both of the above processes via a specialist disposal company.

-




This page is intentionally blank.



www.stamford-avk.com


Copyright 2016, Cummins Generator Technologies Ltd. All Rights Reserved
Cummins and the Cummins logo are registered trademarks of Cummins Inc.

MAIN STATOR (12 ENDS)




(T1) = NEMA EQUIVALENT

CONNECT TO AVR:




MAIN TERMINAL CONNECTIONS


SERIES STAR 3PH 4W
OUTPUT TERMINALS U.V.W.N.




SERIES DELTA 3PH 4W
OUTPUT TERMINALS U.V.W.N.




PARALLEL STAR 3PH 4W
OUTPUT TERMINALS U.V.W.N.



DOUBLE DELTA 1PH 3 WIRE
OUTPUT TERMINALS U.V.W.N.



UNLESS OTHERWISE SPECIFIED, ALL DIMENSIONS ARE IN MILLIMETERS		SIN TO		DWN S BHAGWAT			CUMMINS GENERATOR TECHNOLOGIES	
DO NOT SCALE PRINT		CKD U. DAGWALE		APVD S. JOSHI			DRAWING, WIRING SCHEMATIC	
DATE 30OCT15		SCALE 1:1		FIRST USER ON		SOL1, SOL2 & S11.2 TERMINAL CONNECTION		
ANG TOL ± 0.5°		FOR INTERPRETATION OF DIMENSIONS AND TOLERANCING, SEE ASME Y14.5-2009		FORTUNA PUN		SVC SIZE A2 A054B731		
THIS DOCUMENT CONTAINS INFORMATION SHOWN THEREON IS CONFIDENTIAL AND PROPRIETARY AND SHALL NOT BE DISCLOSED TO OTHERS IN ANY COPY OR ELECTRONIC FORM, REPRODUCED IN ANY MANNER, OR USED FOR ANY PURPOSE WITHOUT WRITTEN CONSENT OF CUMMINS INC.		CUMMINS INC.		PUN		CAD SHEET OF 1		



CHANGES

NO.	DATE	BY	DESCRIPTION
1	15/08/2011	U. DODWALE	BASE DIAGRAM
2	15/08/2011	S. JOSHI	50.2 & 51.2 WITH AUXILIARY WINDING
3	15/08/2011	M. S. JOSHI	50.2 & 51.2 WITH AUXILIARY WINDING

PROJECT INFORMATION

PROJECT NO: **A0521944**

PROJECT NAME: **TORTUNA**

DESIGNER: **M. ATHANI**

CHECKER: **U. DODWALE**

DATE: **15/08/2011**

SCALE: **1:1**

APP. VOL. ± 0.5%



ESlAlaska.com

Engine Manual

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312



THIS PAGE INTENTIONALLY LEFT BLANK

INTRODUCTION

To help you enjoy your Isuzu C series engine for many years to come, please follow these recommendations:

- Read and understand this Operation Manual before you operate the machine to ensure that you follow safe operating practices and maintenance procedures.
- Keep this Operation Manual in a convenient place for easy access.
- If this Operation Manual is lost or damaged, order a new one from your Isuzu Distributor.
- Make sure this manual is transferred to subsequent owners. This manual should be considered a permanent part of the engine and remain with it.
- Constant efforts are made to improve the quality and performance of Isuzu products, so some details included in this Operation Manual may differ slightly from your engine. If you have any questions about these differences, please contact your Isuzu Distributor.
- The specifications and components (instrument panel, fuel tank, etc.) described in this manual may differ from ones installed on your machine. Please refer to the manual provided by the manufacturer of these components.

INTRODUCTION

RECORD OF OWNERSHIP

Take a few moments to record the information you need when you contact Isuzu for service, parts or literature.

Engine model: _____

Engine serial No.: _____

Date purchased: _____

Dealer: _____

Dealer phone: _____

SYMBOL EXPLANATION

The following symbols are used throughout this manual to identify specific engine model information



This symbol indicates information pertaining to the following indirect injection engines:

- 3CH1-NGZG01
- 3CH1-SDZP01
- 3CJ1-NGZG01
- 3CJ1-SDZP01

All of the models conform to the engine emission regulations (EPA 2013 rules).



This symbol indicates information pertaining to the following direct injection engines:

- 3CE1

This model conform to the engine emission regulations (EPA 2013 rules).

TABLE OF CONTENTS

Introduction	i
Record of Ownership.....	ii
Symbol Explanation.....	ii
Table of Contents	iii
Isuzu Engine After Service	1
Isuzu Genuine Parts.....	2
Emission-Related Installation Instructions (REF).....	2
Installation of Nonroad Engines into Equipment.....	2
Allowable Air Intake Restriction and Exhaust Back Pressure.....	2
Allowable Air Intake Restriction.....	2
Allowable Exhaust Back Pressure.....	2
Safety	3
Safety Statements.....	3
Safety Precautions.....	4
Before You Operate.....	4
During Operation and Maintenance.....	4
Product Overview	13
Isuzu C series Engine Features and Applications.....	13
Component Identification.....	14
Location of Labels.....	17
Function of Major Engine Components.....	18
Function of Cooling System Components.....	20
Electronic Control System.....	21
Main Electronic Control Components and Features.....	24

TABLE OF CONTENTS

Gauges and Indicators	26
Gauges	26
Indicators	27
Gauges and Indicators of Electronic Control System	28
Gauges	28
Indicators	28
Controls	29
Key Switch	29
Glow Plugs	30
Governor Lever	30
Engine Stop Solenoid (IDI Engines)	31
Speed Control of Electronically Controlled Engines	31
Electronic Engine Speed Control	32
Before You Operate	35
Diesel Fuel	36
Diesel Fuel Specifications	36
Filling the Fuel Tank	41
Priming the Fuel System	42
Engine Oil	43
Engine Oil Specifications	43
Engine Oil Viscosity	44
Checking Engine Oil	44
Adding Engine Oil	44
Engine Oil Capacity (Typical)	45
Engine Coolant	46
Engine Coolant Specifications	47
Filling Radiator with Engine Coolant	47
Daily Check of the Cooling System	48
Engine Coolant Capacity (Typical)	48
Daily Checks	49
Visual Checks	49
Check Diesel Fuel, Engine Oil and Engine Coolant Levels	49
Check Engine Speed Control	49
Check Operator's Console	50
Check Indicators	50
Engine Operation	53
Starting Engine	54
Cold Start Device	56
High-altitude Injection Control Device	56
Checking the Engine During Operation	57
Adjust Engine Speed	59
Shutting Down the Engine	60

TABLE OF CONTENTS

Periodic Maintenance	61
Precautions.....	62
The Importance of Periodic Maintenance	62
Performing Periodic Maintenance.....	62
The Importance of Daily Checks.....	62
Keep a Log of Engine Hours and Daily Checks.....	62
Isuzu Replacement Parts.....	62
Tools Required	62
Ask Your Isuzu Distributor For Help	62
Required EPA/ARB Maintenance USA Only	62
EPA/ARB Installation Requirements USA Only	63
Tightening Fasteners	63
Standard Torque Chart.....	63
Periodic Maintenance Schedule	64
Periodic Maintenance Chart	64
Periodic Maintenance Procedures.....	66
After Initial 50 Hours of Operation	66
Every 50 Hours of Operation	71
Every 250 Hours of Operation	75
Every 500 Hours of Operation	79
Every 1000 Hours of Operation	83
Every 1500 Hours of Operation	85
Every 2000 Hours of Operation	86
Every 3000 Hours of Operation	87
Troubleshooting	89
Troubleshooting Chart	90
Troubleshooting of Electronic Control System.....	92
Fault Detection Capability	92
Troubleshooting Information	94
List of Possible Faults of Electronically Controlled Engines	95
Long-Term Storage	99
Before You Place the Engine In Long-Term Storage	100
Returning the Engine to Service	101
Specifications	103
Engine General Specifications.....	104
Principal Engine Specifications.....	105

TABLE OF CONTENTS

This Page Intentionally Left Blank

ISUZU ENGINE AFTER SERVICE

Please feel free to contact your Isuzu distributor for periodical inspection and maintenance.

ISUZU ENGINE AFTER SERVICE

ISUZU GENUINE PARTS

The Isuzu genuine parts are identical with those of used in the engine production, and accordingly, they are warranted by Isuzu Motors Limited.

The Isuzu genuine parts are supplied by the Isuzu distributors or the authorized parts suppliers. Please designate "Isuzu Genuine Parts" when you need engine parts.



EMISSION-RELATED INSTALLATION INSTRUCTIONS (REF)

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates Federal Law (40 CFR1068.105(B)), subject to fines or other penalties as described in the clean air act.

Installation of Nonroad Engines into Equipment

To ensure engines operate under the certified configurations, Isuzu has established defined application requirements when installing any certified engine into a piece of equipment. The instructions outlined below are included in our certification process and any failure to comply will be considered tampering.

Isuzu certifies engines to operate under variable speed or constant speed conditions. Engines certified as constant speed are prohibited from installation into variable speed applications. The emission control information label will identify an engine certified as constant speed.

Allowable Air Intake Restriction and Exhaust Back Pressure

Resistance to intake airflow and exhaust gas flow is generated in the intake and exhaust systems. Exceeding the limitations will affect the operation of an engine and its certified configuration. Refer to the installation requirements and limitations of the Isuzu C series Application Manual for the engine being equipped with these systems.

Allowable Air Intake Restriction

Engine model	Allowable air intake restriction ≤ kPa (mmAq)	
	Initial upper limit	Upper limit for air cleaner replacement
All models	2.94 (300)	6.23 (635)

Allowable Exhaust Back Pressure

Engine model	Allowable exhaust back pressure ≤ kPa (mmAq)	
	Initial upper limit	Upper limit for exhaust system cleaning
3CH1, 3CJ1	9.81 (1000)	11.77 (1200)
3CE1	12.75 (1300)	15.30 (1560)

SAFETY

SAFETY STATEMENTS

Isuzu is concerned for your safety and your machine's condition. Safety statements are one of the primary ways to call your attention to the potential hazards associated with Isuzu C series engine operation. Follow the precautions listed throughout the manual before operation, during operation and during periodic maintenance procedures for your safety, the safety of others and to protect the performance of your engine. Keep the labels from becoming dirty or torn and replace them if they are lost or damaged. Also, if you need to replace a part that has a label attached to it, make sure you order the new part and label at the same time.



This safety alert symbol appears with most safety statements. It means attention, become alert, your safety is involved! Please read and abide by the message that follows the safety alert symbol.

DANGER

DANGER indicates a hazardous situation which, if not avoided, *will* result in death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, *could* result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, *could* result in minor or moderate injury.

NOTICE

NOTICE indicates a situation which can cause damage to the machine, personal property and/or the environment or cause the equipment to operate improperly.

SAFETY

SAFETY PRECAUTIONS

Before You Operate

NOTICE



- Never permit anyone to operate the engine or driven machine without proper training.
- Read and understand this Operation Manual before you operate or service the machine to ensure that you follow safe operating practices and maintenance procedures.
- Machine safety signs and labels are additional reminders for safe operating and maintenance techniques.
- See your Isuzu Distributor for additional training.

During Operation and Maintenance

⚠ DANGER

Scald Hazard!



- Never remove the radiator cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the radiator cap.
- Tighten the radiator cap securely after you check the radiator. Steam can spurt out during engine operation if the cap is loose.
- Always check the level of the engine coolant by observing the reserve tank.
- Failure to comply will result in death or serious injury.

⚠ DANGER

Explosion Hazard!



- Keep the area around the battery well-ventilated. While the engine is running or the battery is charging, hydrogen gas is produced which can be easily ignited.
- Keep sparks, open flame and any other form of ignition away while the engine is running or battery is charging.
- Never short out the battery terminals, including when checking the remaining battery charge. This will result in a spark and may cause an explosion or fire. Use a hydrometer to check the remaining battery charge.
- If the electrolyte is frozen, slowly warm the battery before you recharge it.
- Failure to comply will result in death or serious injury.

Sudden Movement Hazard!



- Never start the engine by shorting out the starter terminal and the battery terminal (Jump-start). The machine may move suddenly if the machine safety circuit is released, but the gear is still engaged.
- Failure to comply will result in death or serious injury.

⚠ DANGER**Fire and Explosion Hazard!**

- Diesel fuel is extremely flammable and explosive under certain conditions.

- When you remove any fuel system component to perform maintenance (such as changing the fuel filter) place an approved container under the opening to catch the fuel.
- Never use a shop rag to catch the fuel. Vapors from the rag are flammable and explosive.
- Wipe up any spills immediately.
- Wear eye protection. The fuel system is under pressure and fuel could spray out when you remove any fuel system component.
- Only use the key switch to start the engine.
- Never jump-start the engine. Sparks caused by shorting the battery to the starter terminals may cause a fire or explosion.
- If the unit has an electric fuel pump, in the case of DI engine, since air is automatically bled, by keeping the key of the starter switch in the ON position for 10 to 15 seconds, the fuel system can be primed. If this is an IDI engine, keep the key in the ON position (within 15 seconds) until fuel without bubbles comes out from the air bleeding bolt. Here, do not turn the key to the START position.
- If the unit has a mechanical fuel pump, when you prime the fuel system, operate the fuel priming lever of the mechanical fuel pump several times until the fuel filter cup is filled with fuel. On top of that, operate the fuel feed pump for several times until fuel without bubbles comes out from the air bleeding bolt.
- Never use diesel fuel as a cleaning agent.
- Never remove the fuel cap with the engine running.

⚠ DANGER (Continued)

- Only fill the fuel tank with diesel fuel. Filling the fuel tank with gasoline may result in a fire and will damage the engine.
- Never refuel with the engine running.
- Keep sparks, open flames or any other form of ignition (match, cigarette, static electric source) well away when refueling.
- Never overfill the fuel tank.
- Fill the fuel tank. Store any containers containing fuel in a well-ventilated area, away from any combustibles or sources of ignition.
- Be sure to place the diesel fuel container on the ground when transferring the diesel fuel from the pump to the container. Hold the hose nozzle firmly against the side of the container while filling it. This prevents static electricity buildup which could cause sparks and ignite fuel vapors.
- Never place diesel fuel or other flammable material such as oil, hay or dried grass close to the engine during engine operation or shortly after shutdown.
- Before you operate the engine, check for fuel leaks. Replace rubberized fuel hoses every two years or every 2000 hours of engine operation, whichever comes first, even if the engine has been out of service. Rubberized fuel lines tend to dry out and become brittle after two years or 2000 hours of engine operation, whichever comes first.
- When you prime the fuel system, operate the fuel priming lever of the mechanical fuel pump several times until the fuel filter cup is filled with fuel.
- Failure to comply will result in death or serious injury.

SAFETY

⚠ DANGER

Crush Hazard!



- When you need to transport an engine for repair, have a helper assist you to attach it to a hoist and load it on a truck.

- Never stand under a hoisted engine. If the hoist mechanism fails, the engine will fall on you, causing death or serious injury.
- Failure to comply will result in death or serious injury.

⚠ WARNING

Sever Hazard!



- Keep hands and other body parts away from moving/rotating parts such as the cooling fan, flywheel or PTO shaft.

- Wear tight-fitting clothing and keep your hair short or tie it back while the engine is running.
- Remove all jewelry before you operate or service the machine.
- Never start the engine in gear. Sudden movement of the engine and/or machine could cause death or serious personal injury.
- Never operate the engine without the guards in place.
- Before you start the engine make sure that all bystanders are clear of the area.
- Keep children and pets away while the engine is operating.
- Check before starting the engine that any tools or shop rags used during maintenance have been removed from the area.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Exhaust Hazard!



- Never operate the engine in an enclosed area such as a garage, tunnel, underground room, manhole or ship's hold without proper ventilation.

- Never block windows, vents, or other means of ventilation if the engine is operating in an enclosed area. All internal combustion engines create carbon monoxide gas during operation. Accumulation of this gas within an enclosure could cause illness or even death.
- Make sure that all connections are tightened to specifications after repair is made to the exhaust system.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Alcohol and Drug Hazard!



- Never operate the engine while you are under the influence of alcohol or drugs.

- Never operate the engine when you are feeling ill.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Exposure Hazard!



- Wear personal protective equipment such as gloves, work shoes, eye and hearing protection as required by the task at hand.
- Never wear jewelry, unbuttoned cuffs, ties or loose-fitting clothing when you are working near moving/rotating parts such as the cooling fan, flywheel or PTO shaft.
- Always tie back long hair when you are working near moving/rotating parts such as a cooling fan, flywheel, or PTO shaft.
- Never operate the engine while wearing a headset to listen to music or radio because it will be difficult to hear the alert signals.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Burn Hazard!



- Wait until the engine cools before you drain the engine coolant. Hot engine coolant may splash and burn you.
- If you must drain the engine oil while it is still hot, stay clear of the hot engine oil to avoid being burned.
- Always wear eye protection.
- Keep your hands and other body parts away from hot engine surfaces such as the muffler, exhaust pipe, turbocharger (if equipped) and engine block during operation and shortly after you shut the engine down. These surfaces are extremely hot while the engine is operating and could seriously burn you.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Burn Hazard!



- Batteries contain sulfuric acid. Never allow battery fluid to come in contact with clothing, skin or eyes. Severe burns could result. Always wear safety goggles and protective clothing when servicing the battery. If battery fluid contacts the eyes and/or skin, immediately flush the affected area with a large amount of clean water and obtain prompt medical treatment.
- Failure to comply could result in death or serious injury.

⚠ WARNING

High-Pressure Hazard!



- Avoid skin contact with the high-pressure diesel fuel spray caused by a fuel system leak such as a broken fuel injection line. High-pressure fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure fuel spray, obtain prompt medical treatment.
- Never check for a fuel leak with your hands. Always use a piece of wood or cardboard. Have your Isuzu Distributor repair the damage.
- Failure to comply could result in death or serious injury.

SAFETY

⚠ WARNING

Shock Hazard!



- Turn off the battery switch (if equipped) or disconnect the negative battery cable before servicing the electrical system.

- Check the electrical harnesses for cracks, abrasions, and damaged or corroded connectors. Always keep the connectors and terminals clean.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Entanglement Hazard!



- Stop the engine before you begin to service it.

- Never leave the key in the key switch when you are servicing the engine. Someone may accidentally start the engine and not realize you are servicing it. This could result in a serious injury.
- If you must service the engine while it is operating, remove all jewelry, tie back long hair, and keep your hands, other body parts and clothing away from moving/rotating parts.
- Failure to comply could result in death or serious injury.

⚠ WARNING

Sudden Movement Hazard!

- Engaging the transmission or PTO at an elevated engine speed could result in unexpected movement of the equipment.
- Failure to comply could result in death or serious injury.

⚠ CAUTION

Coolant Hazard!




- Wear eye protection and rubber gloves when you handle long life or extended life engine coolant. If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

- Failure to comply may result in minor or moderate injury.

⚠ CAUTION

Flying Object Hazard!



- Always wear eye protection when servicing the engine and when using compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.

- Failure to comply may result in minor or moderate injury.

⚠ CAUTION

- When using a 120 V system only, push the change-over switch to the right (120 V).
- The main switch should always be kept in the ON position during operation.
- Before starting the engine, always turn the switches on the working instruments (lighting apparatus, motor, etc.) to their OFF position. If the switches are not OFF, the sudden application of load when the engine is started could be very dangerous.

NOTICE

- Only use diesel fuels recommended by Isuzu for the best engine performance, to prevent engine damage and to comply with EPA/ARB warranty requirements.
- Only use clean diesel fuel.
- Never remove the primary strainer (if equipped) from the fuel tank filler port. If removed, dirt and debris could get into the fuel system causing it to clog.

- Only use the engine oil specified. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine oil. Carefully clean the oil cap/dipstick and the surrounding area before you remove the cap.
- Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- Never overfill the engine with engine oil.
- Always keep the oil level between the upper and lower lines on the oil cap/dipstick.
- Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.

- Only use the engine coolant specified. Other engine coolants may affect warranty coverage, cause an internal buildup of rust and scale and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine coolant. Carefully clean the radiator cap and the surrounding area before you remove the cap.
- Never mix different types of engine coolants. This may adversely affect the properties of the engine coolant.

NOTICE

Never attempt to adjust the low or high idle speed limit screw. This may impair the safety and performance of the machine and shorten its life. If adjustment is ever required, contact your Isuzu Distributor.

If any problem is noted during the visual check, the necessary corrective action should be taken before you operate the engine.

New engine break-in:

- On the initial engine start-up, allow the engine to idle for approximately 15 minutes while you check for proper engine oil pressure, diesel fuel leaks, engine oil leaks, coolant leaks, and for proper operation of the indicators and/or gauges.
- During the first hour of operation, vary the engine speed and the load on the engine. Short periods of maximum engine speed and load are desirable. Avoid prolonged operation at minimum or maximum engine speeds and loads for the next four to five hours.
- During the break-in period, carefully observe the engine oil pressure and engine temperature.
- During the break-in period, check the engine oil and coolant levels frequently.

If any indicator fails to illuminate when the key switch is in the ON position, see your Isuzu Distributor for service before operating the engine.

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

SAFETY

NOTICE

If the engine fails to start:
Wait until the engine comes to a complete stop before you attempt to start it again. Engaging the starter while the engine is still rotating will result in damage to the starter and flywheel.

Never use an engine starting aid such as ether. Engine damage will result.

Never engage the starter motor while the engine is running. This may damage the starter motor pinion and/or ring gear.

Make sure the engine is installed on a level surface. If a continuously running engine is installed at an angle greater than (30°) in any direction or if an engine runs for short periods of time (less than three minutes) at an angle greater than (35°) in any direction, engine oil may enter the combustion chamber causing excessive engine speed and white exhaust smoke. This may cause serious engine damage.

If any indicator illuminates during engine operation, stop the engine immediately. Determine the cause and repair the problem before you continue to operate the engine.

The illustrations and descriptions of optional equipment in this manual, such as the operator's console, are for a typical engine installation. Refer to the documentation supplied by the optional equipment manufacturer for specific operation and maintenance instructions.

NOTICE

Observe the following environmental operating conditions to maintain engine performance and avoid premature engine wear:

- Avoid operating in extremely dusty conditions.
- Avoid operating in the presence of chemical gases or fumes.
- Avoid operating in a corrosive atmosphere such as salt water spray.
- Never install the engine in a floodplain unless proper precautions are taken to avoid being subject to a flood.
- Never expose the engine to the rain.
- The standard range of ambient temperatures for the normal operation of Isuzu engines is from -15 °C (+5 °F) to +45 °C (+113 °F).
- If the ambient temperature exceeds +45 °C (+113 °F) the engine may overheat and cause the engine oil to break down.
- If the ambient temperature is below -15 °C (+5 °F) the engine will be hard to start and the engine oil may not flow easily.
- Contact your Isuzu Distributor if the engine will be operated outside of this standard temperature range.
- Contact your Isuzu Distributor if the engine will be operated at high altitude. High altitude reduces engine power, de-stabilizes operation and generates exhaust gas that exceeds the specification amount in design.

NOTICE

- When the engine is operated in dusty conditions, clean the air cleaner element more frequently.
- Never operate the engine with the air cleaner element(s) removed. This may allow foreign material to enter the engine and damage it.

The maximum air intake restriction, in terms of differential pressure measurement, must not exceed 0.90 psi (6.23 kPa; 635 mmAq). Clean or replace the air cleaner element if the air intake restriction exceeds the above mentioned value.

For maximum engine life, Isuzu recommends that when shutting the engine down, you allow the engine to idle, without load, for five minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger (if equipped) and exhaust system, to cool slightly before the engine itself is shut down.

- Never attempt to modify the engine's design or safety features such as defeating the engine speed limit control or the diesel fuel injection quantity control.
- Modifications may impair the engine's safety and performance characteristics and shorten the engine's life. Any alterations to this engine may void its warranty. Be sure to use Isuzu genuine replacement parts.

Protect the air cleaner, turbocharger (if equipped) and electric components from damage when you use steam or high-pressure water to clean the engine.

Never use high-pressure water or compressed air at greater than 28 psi (193 kPa; 19686 mmAq) or a wire brush to clean the radiator fins. Radiator fins damage easily.

NOTICE

Establish a periodic maintenance plan according to the engine application and make sure you perform the required periodic maintenance at intervals indicated. Failure to follow these guidelines will impair the engine's safety and performance characteristics, shorten the engine's life and may affect the warranty coverage on your engine.

Consult your Isuzu Distributor for assistance when checking items marked with a ●.

Make it a habit to perform daily checks. See *Daily Checks in the Before You Operate Section of this manual.*

Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor machine performance and helps extend the life of the engine.

The tightening torque in the *Standard Torque Chart in the Periodic Maintenance Section of this manual* should be applied only to the bolts with a "7" head. (JIS strength classification: 7T)

- Apply 60 % torque to bolts that are not listed.
- Apply 80 % torque when tightened to aluminum alloy.



SAFETY

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

NOTICE

Precautions for handling desiccant

Disposal:

This material is disposable as non-flammable. however, the bag is flammable and if it is necessary, then tear the bag and discard the bag and the contents separately. It is desirable to bury the contents in the bag under ground. Dispose in accordance with the disposal standards for industrial waste defined by local laws and regulations.

Handling:

The contents of the bag do not leak out in the normal use. Take the following emergency measures, however, if the contents leak out.

- If the contents get on the skin, rinse thoroughly with running water.
- If the contents get in the eyes, rinse thoroughly with water. Consult with doctors when any abnormalities are found.
- If the contents get in the mouth, rinse thoroughly with water. Drink water to dilute if the content is swallowed, though a small amount is harmless. Consult with doctors when any abnormalities are found.

Characteristics of materials:

- | | |
|---|--------------|
| • Calcium Chloride (CaCl ₂) | Approx. 57 % |
| • Grain Polysaccharide | Approx. 28 % |
| • Grain Skins | Approx. 9 % |
| • Ethylene Polymer (Bag) | Approx. 5 % |

Hazard information:

- | | |
|------------------|-------------|
| • Explosiveness | None |
| • Inflammability | Inflammable |
| • Combustibility | None |
| • Oxidation | None |

PRODUCT OVERVIEW

ISUZU C SERIES ENGINE FEATURES AND APPLICATIONS

Isuzu C series engine is environmentally friendly and is designed to:

- Lower the amount of exhaust gas emissions.
- Reduce engine noise and vibration.
- Be easy to start thanks to the specially designed fuel injection pump and combustion system.
- Be economical to run because diesel fuel and engine oil consumption are reduced.
- Be easy to operate due to the minimum amount of required maintenance and their compact design.
- Be durable and reliable due in part to the newly designed fuel injection valve and fuel injection pump.

Isuzu C series engine is designed to supply power to a wide variety of driven machines including:

- Construction
- Agriculture
- Power generation

We are sure that you will agree these features provide excellent value in an industrial diesel engine.

These engines are designed to deliver power to driven machines by means of a “direct coupled drive” or “belt drive.” In direct coupled drive engine applications, the engine’s flywheel housing or end plate is coupled directly to the driven machine. In belt drive engine applications, a belt drive is used to power the driven machine. If you have applications that require a belt drive and/or front power take-off (PTO), please contact your Isuzu Distributor.

The engine is designed for a wide range of applications. Options, such as fuel tank, control panel, indicators, gauges and alarms, are available to customize the application.

Since designing the application and installing the engine require special knowledge and skill, always consult your Isuzu Distributor for these services. They will help you:

- Select optional equipment. Optional equipment should be selected to match the work conditions and environment.
- Maximize engine performance with a minimum amount of downtime and safety related incidents by carefully matching the characteristics of the engine with the driven machine.
- Plan for safe fuel piping, exhaust piping, electrical wiring, ventilation and accurate engine installation.
- Design your applications so they meet requirements of the local authorities.


PRODUCT OVERVIEW

COMPONENT IDENTIFICATION



3CH1-NGZG01, 3CH1-SDZP01, 3CJ1-NGZG01

Figure 1 shows where major indirect injection engine components are located.



- 1 – Lifting eye (flywheel end)
- 2 – Engine coolant pump
- 3 – Lifting eye (engine cooling fan end)
- 4 – Engine cooling fan
- 5 – V-belt
- 6 – Crankshaft V-pulley
- 7 – Side filler port (engine oil)
- 8 – Drain plug (engine oil)*
- 9 – Fuel inlet
- 10 – Mechanical fuel pump
- 11 – Dipstick (engine oil)
- 12 – Fuel priming lever
- 13 – Engine oil filter

- 14 – Governor lever
- 15 – Fuel injection pump
- 16 – Intake manifold
- 17 – Air intake port (from air cleaner)
- 18 – Fuel filter
- 19 – Fuel return to fuel tank
- 20 – Top filler port (engine oil)
- 21 – Rocker arm cover
- 22 – Flywheel
- 23 – Starter motor
- 24 – Exhaust manifold
- 25 – Alternator

Figure 1


* Engine oil drain plug location may vary based on oil pan options.

PRODUCT OVERVIEW



3CJ1-SDZP01

Figure 2 shows where major indirect injection engine components are located.



- 1 – Air intake port (from air cleaner)
- 2 – Lifting eye (flywheel end)
- 3 – Intake manifold
- 4 – Lifting eye (engine cooling fan end)
- 5 – Engine coolant pump
- 6 – Engine cooling fan
- 7 – V-belt
- 8 – Crankshaft V-pulley
- 9 – Side filler port (engine oil)
- 10 – Drain plug (engine oil)*
- 11 – Engine oil filter

- 12 – Mechanical fuel pump
- 13 – Fuel injection pump
- 14 – Dipstick (engine oil)
- 15 – Governor lever
- 16 – Top filler port (engine oil)
- 17 – Rocker arm cover
- 18 – Exhaust manifold
- 19 – Flywheel
- 20 – Starter motor
- 21 – Alternator

Figure 2


* Engine oil drain plug location may vary based on oil pan options.

PRODUCT OVERVIEW



3CE1

Figure 3 shows where major direct injection engine components are located.



- | | |
|---|---|
| <ul style="list-style-type: none"> 1 – Lifting eye (flywheel end) 2 – Lifting eye (engine cooling fan end) 3 – Engine coolant pump 4 – Engine cooling fan 5 – Crankshaft V-pulley 6 – V-belt 7 – Side filler port (engine oil) 8 – Engine oil cooler 9 – Fuel injection pump 10 – Engine oil filter 11 – Intake manifold | <ul style="list-style-type: none"> 12 – Dipstick (engine oil) 13 – Fuel filter 14 – Fuel return to fuel tank 15 – Fuel inlet 16 – Top filler port (engine oil) 17 – Rocker arm cover 18 – EGR valve 19 – Flywheel 20 – Starter motor 21 – Exhaust manifold 22 – Alternator |
|---|---|

Figure 3

** Engine oil drain plug location may vary based on oil pan options.*

LOCATION OF LABELS



Figure 4 shows the location of regulatory and safety labels on Isuzu C series indirect injection model engine.




Figure 4

The typical location of the emission control information label is shown **(Figure 4, (1))**.

Typical location of the engine nameplate is shown **(Figure 4, (2))**.



Figure 5 shows the location of regulatory and safety labels on Isuzu C series direct injection model engine.




Figure 5

■ Location of labels/nameplates on direct injection model engines

Model	Engine nameplate	EPA/ARB certification label
3CE1	On the top of the locker arm cover (cooling fan end) Figure 5, (2)	On the top of the locker arm cover (flywheel end) Figure 5, (1)

PRODUCT OVERVIEW

FUNCTION OF MAJOR ENGINE COMPONENTS

Components	Functions
Air cleaner	The air cleaner prevents airborne contaminants from entering the engine. Since the air cleaner is application specific, it must be carefully selected by an application engineer. It is not part of the basic engine package as shipped from the Isuzu factory. Periodic replacement of the air cleaner filter element is necessary. <i>See the Periodic Maintenance Schedule on page 64</i> for the replacement frequency.
Starter motor	The starter motor is powered by the battery. When you turn the key switch in the operator's console to the START position, the starter motor engages with the ring gear installed on the flywheel and starts the flywheel in motion.
Alternator	The alternator is driven by a V-belt which is powered by the crankshaft V-pulley. The alternator supplies electricity to the engine systems and charges the battery while the engine is running.
Dipstick (engine oil)	The engine oil dipstick is used to determine the amount of engine oil in the crankcase.
Side and top filler port (engine oil)	You can fill the crankcase with engine oil from either the side or top filler port depending upon which one is most convenient.
Engine oil filter	The engine oil filter removes contaminants and sediment from the engine oil. Periodic replacement of the engine oil filter is necessary. <i>See the Periodic Maintenance Schedule on page 64</i> for the replacement frequency.
 Engine oil cooler (if equipped)	The engine oil cooler helps to keep the engine oil cool. Engine coolant from the cooling system is circulated by the coolant pump through an adapter at the base of the engine to the oil cooler and then to the cylinder block and back to the coolant pump.
Fuel tank	The fuel tank is a reservoir that holds diesel fuel. When fuel leaves the fuel tank it goes to the water separator. Next, fuel is pumped to the fuel filter by the electric or mechanical fuel pump. Next the fuel goes to the fuel injection pump. Since fuel is used to keep the fuel injection pump cool and lubricated, more fuel than necessary enters the injection pump. When the injection pump pressure reaches a preset value, a relief valve allows excess fuel to be returned back to the fuel tank. The fuel tank is a required engine component.
Water separator	The water separator removes contaminants, sediment and water from diesel fuel going to the fuel filter. This is a required component of the fuel system and is standard equipment with every engine. The separator is installed between the fuel tank and the fuel pump. Periodically drain the water from the water separator using the drain valve at the bottom of the separator.
Electric fuel pump	The electric fuel pump makes sure there is a constant supply of diesel fuel to the fuel injection pump. The electric fuel pump is electro-magnetic and runs on 12 V DC. An electric fuel pump may be installed as an option or as standard equipment. Standard equipment may vary based on engine model and specification. If an electric fuel pump is installed, turn the key switch to the ON position for 10 to 15 seconds to prime the fuel system.

PRODUCT OVERVIEW

Components	Functions
 Mechanical fuel pump	The mechanical fuel pump is a diaphragm-type of pump and is installed on the fuel injection pump body. The mechanical fuel pump is driven by a cam on the camshaft of the fuel injection pump. An electric fuel pump is available as an option. The mechanical fuel pump is not installed on the fuel injection pump if the electric fuel pump option is installed.
 Fuel priming lever	If the unit has a mechanical fuel pump, a fuel priming lever on the mechanical fuel pump primes the fuel system. The fuel system needs to be primed before you start the engine for the first time, if you run out of fuel, or if fuel system service is performed. To prime the fuel system, operate the fuel priming lever until the cup in the fuel filter is full of fuel.
Fuel filter	The fuel filter removes contaminants and sediments from the diesel fuel. Periodic replacement of the fuel filter is necessary. <i>See the Periodic Maintenance Schedule on page 64</i> for the replacement frequency. Please note that the word “diesel” is implied throughout this manual when the word “fuel” is used.

PRODUCT OVERVIEW

FUNCTION OF COOLING SYSTEM COMPONENTS

Components	Functions
<p>Cooling system</p>	<p>The C series engine is liquid-cooled by means of a cooling system. The cooling system consists of a radiator, radiator cap, engine cooling fan, engine coolant pump, thermostat, and reserve tank. Note that all cooling system components are required for proper engine operation. Since some of the components are application specific, they must be carefully selected by an application engineer. The application specific items are not part of the basic engine package as shipped from the Isuzu factory.</p>
<ul style="list-style-type: none"> • Engine cooling fan 	<p>The engine cooling fan is driven by a V-belt which is powered by the crankshaft V-pulley. The purpose of the engine cooling fan is to circulate air through the radiator.</p>
<ul style="list-style-type: none"> • Engine coolant pump 	<p>The engine coolant pump circulates the engine coolant through the cylinder block and cylinder head and returns the engine coolant to the radiator.</p>
<ul style="list-style-type: none"> • Radiator 	<p>The radiator acts as a heat exchanger. As the engine coolant circulates through the cylinder block it absorbs heat. The heat in the engine coolant is dissipated in the radiator. As the engine cooling fan circulates air through the radiator, the heat is transferred to the air.</p>
<ul style="list-style-type: none"> • Radiator cap 	<p>The radiator cap controls the cooling system pressure. The cooling system is pressurized to raise the boiling point of the engine coolant. As the engine coolant temperature rises, the system pressure and the coolant volume increases. When the pressure reaches a preset value, the release valve in the radiator cap opens and the excess engine coolant flows into the reserve tank. As the engine coolant temperature is reduced, the system pressure and volume is reduced and the vacuum valve in the radiator cap opens allowing engine coolant to flow from the reserve tank back into the radiator.</p>
<ul style="list-style-type: none"> • Reserve tank 	<p>The reserve tank contains the overflow of engine coolant from the radiator. If you need to add engine coolant to the system, add it to the reserve tank, not the radiator.</p>
<ul style="list-style-type: none"> • Thermostat 	<p>A thermostat is placed in the cooling system to prevent engine coolant from circulating into the radiator until the engine coolant temperature reaches a preset temperature. When the engine is cold, no engine coolant flows through the radiator. Once the engine reaches its operating temperature the thermostat opens and allows engine coolant to flow through the radiator. By letting the engine warm up as quickly as possible, the thermostat reduces engine wear, deposits and emissions.</p>

ELECTRONIC CONTROL SYSTEM



3CE1

WARNING

- Never use the E-ECU for other purposes than intended or in other ways than specified by Isuzu. Doing so could result in the violation of emission control regulations and will void the product warranty.
- Improper use or misuse of the E-ECU may result in death or serious injury due to an abrupt and unexpected increase in engine speed.

WARNING

- Be sure to use the E-ECU in conjunction with the engines whose models or serial numbers are specified by Isuzu. Other E-ECU/engine combinations than specified will void the engine warranty.
- Improper use or misuse of the E-ECU may result in death or serious injury due to an abrupt and unexpected increase in engine speed.

WARNING

- Replacing the fuel injection pump involves rewriting the fuel injection data in the E-ECU. Be sure to contact your Isuzu Distributor before replacing the fuel injection pump. Failure to rewrite the fuel injection data before replacing the fuel injection pump will void the engine warranty.
- Improper use or misuse of the E-ECU may result in death or serious injury due to an abrupt and unexpected increase in engine speed.

WARNING

- Replacing the E-ECU involves migrating the fuel injection data to the existing E-ECU to the new unit. Be sure to contact your Isuzu Distributor before replacing the E-ECU. Failure to migrate the fuel injection data before replacing the E-ECU will void the engine warranty.
- Improper use or misuse of the E-ECU may result in death or serious injury due to an abrupt and unexpected increase in engine speed.

PRODUCT OVERVIEW

NOTICE

Shut down the engine if the fault indicator comes on.

Continuing running the engine with the fault indicator being on may result in a serious malfunction of or damage to the engine, and will void the engine warranty.

NOTICE

Do not energize the starter for a period of longer than 15 seconds.

Take a pause of at least 30 seconds between energization of the starter.

Otherwise the starter could suffer damage.

NOTICE

- High-pressure washing not recommended.
- Avoid using high-pressure washing for electronic or electric devices installed in, on or around the engine, including the E-ECU, relays and harness couplers.

Otherwise such devices may suffer malfunction due to water ingress into them.

NOTICE

- Do not plug or unplug the E-ECU for a period of at least 6 seconds after power to the unit has been turned on or off.
- Do not touch connector pins of the E-ECU with bare hands.
Doing so may result in corrosion of the connector pins and/or damage to the internal circuits of the E-ECU due to static electricity.
- Do not force a measuring probe into the female coupler.
Doing so may cause contact failure of the connector pins, resulting in malfunction of the E-ECU.
- Take care to prevent water from entering the couplers when plugging or unplugging the connector.
Water inside the couplers may cause corrosion, resulting in malfunction of the E-ECU.
- Avoid plugging/unplugging the connector more than approx. 10 times.
Frequent plugging/unplugging of the connector may cause contact failure of the connector pins, resulting in malfunction of the E-ECU.
- Do not use the E-ECU that has ever suffered drop impact.

NOTICE

Always check the battery for proper charge.

Otherwise the electronically controlled engines may fail to start.

PRODUCT OVERVIEW

Model 3CE1 engine come with the Exhaust Gas Recirculation (EGR) system to conform to the engine emission regulations (EPA 2013 rules). The EGR system and an electronic governor (Eco-governor) constitute an electronic engine control system.

The electronic engine control system regulates the exhaust gas recirculation flow rate and the fuel injection volume depending on the engine load and speed signals from the engine controller (E-ECU), so that the exhaust gas is kept clean according to the emission control regulations. **Figure 6** illustrates the electronic engine control system.

Features of the electronic engine control system include:

- Engine speed control schemes
Droop control/Low-idling speed up/Auto deceleration/High-idling speed down/Black smoke suppression
- Starting aid
Auto preheating/After heating
- Engine failure detection
- CAN communication with the control system of the driven machine

Consult the operation manual for the driven machine for applicability of the features that depends on the machine.




Figure 6

PRODUCT OVERVIEW

MAIN ELECTRONIC CONTROL COMPONENTS AND FEATURES



3CE1

Component/feature	Description
Engine controller (E-ECU)	Adjusts the rack position of the fuel injection pump depending on the speed command signal from the accelerator sensor, thus regulating the engine speed and power. The engine controller also regulates the opening of the EGR valve depending on the engine speed and power. It serves as the master station for the following components/control features.
Electronic governor (Eco-governor)	Consists of the engine speed sensor, rack actuator, etc., and is directly connected to the fuel injection pump in order to regulate the rack position of the fuel injection pump depending on the signals communicated with the E-ECU.
Fuel injection pump (for Eco-governor)	Is of single plunger type and equipped with a CSD solenoid valve that allows the fuel injection timing to advance and the injection quantity to increase, thereby improving the cold start performance of the engine.
EGR valve	Controls the exhaust gas recirculation flow rate depending on the engine speed/load signals from the E-ECU. It is installed on the top of the exhaust manifold.
Accelerator sensor	Unlike mechanical governors, the Eco-governor has no governor lever. The accelerator sensor serves as the governor lever to provide the speed command signal (voltage signal) to the E-ECU for engine speed control. It is installed in the operator cabin of the driven machine. Constant speed engines for e.g. generator use do not require accelerator sensors because the engine speed can be shifted via a switch on the operator's console.
Optional	CAN communication capability is available as an option.
Fault indicator	Is installed on the operator's console. If a fault occurs in the E-ECU or Eco-governor, the fault indicator flashes alerting the operator to a fault. The number of flashes and/or the flashing pattern vary depending on the type or source of the fault, enabling quick-fix.
Optional	
Engine diagnosis tool	Allows the operator to troubleshoot the cause of a problem based on detailed information regarding the problem occurring in the E-ECU or Eco-governor. This tool can also be used for data maintenance tasks including programming and mapping. See <i>Troubleshooting Chart</i> on page 90.
Option for service	
Engine coolant temperature sensor	Allows the CSD and ERG to be controlled in engine cold-start conditions.

PRODUCT OVERVIEW

Component/feature		Description
ON-glow at start	Optional	When the key switch is turned to the ON position, the glow plugs are energized for up to 15 seconds. The duration of energization depends on the engine coolant temperature. The HEAT indicator is on during energization. When the indicator goes out, turn the key switch to the START position to start the engine.
Droop control		Reduces the engine speed by a certain percentage from no load to full (rated) load in steady state operation. The same percentage droop is maintained even when the load increases at any no-load speed.
Isochronous control	Optional	Offers a constant engine speed from no load to full load. The engine speed does not decrease even when the load increases at any no-load speed.
Low-idling speed up		Increases the low-idling speed to up to 1000 min ⁻¹ (rpm) depending on the engine coolant temperature. When the coolant temperature reaches a predetermined value, this feature returns the engine speed to the normal low idle setting, thus reducing the warm-up time.
High-idling speed down	Optional	Decreases the high-idling speed depending on the engine coolant temperature. When the coolant temperature falls to a predetermined value, this feature returns the engine speed to the normal high idle setting, thus minimizing the emission of white smoke at low temperatures.
Auto deceleration	Optional	Brings the running engine in low idle mode automatically when the accelerator pedal is not operated for a predetermined period of time. When the pedal is operated, i.e., the accelerator sensor is activated, the low idle mode is cancelled.

PRODUCT OVERVIEW

GAUGES AND INDICATORS

The operator's console provides you with the means to start and stop the unit and a series of gauges and indicators that inform you about the current status of the engine. This is a required engine component. Since the operator's console is application specific, it must be carefully selected by an application engineer. It is not part of the basic engine package as shipped from the Isuzu factory.

NOTICE

The illustrations and descriptions of optional equipment in this manual, such as the operator's console, are for a typical engine installation. Refer to the documentation supplied by the optional equipment manufacturer for specific operation and maintenance instructions.




Figure 8

Gauges

The following gauges are located on a typical operator's console. Some operator's consoles may not have the gauges described here or may have different gauges.




Figure 7

Tachometer - The tachometer display (**Figure 7, (1)**) or (**Figure 8, (1)**) shows the engine speed in revolutions per minute (RPM).

Engine coolant temperature - The engine coolant temperature display (**Figure 7, (2)**) or (**Figure 8, (2)**) shows the temperature of the engine coolant.

Engine oil pressure - The engine oil pressure display (**Figure 7, (3)**) or (**Figure 8, (3)**) shows the pressure of the engine oil.

Hour meter - The hour meter display (**Figure 7, (4)**) or (**Figure 8, (4)**) shows the total number of hours the engine has run. This is useful for planning the *Periodic Maintenance Procedures* on page 66.

PRODUCT OVERVIEW

Indicators

The following indicators are located on a typical operator's console.




Figure 9




Figure 10

HEAT indicator (Figure 9, (1)) - For the "ON-glow" type of the starter switch that does not have the HEAT position in the counterclockwise direction of the ON position, by turning the key to the ON position, the preheating function automatically activates, and the HEAT indicator (**Figure 9, (1)**) lights up. 4 seconds after the indicator turns off is when to start the operation. In the case of 3CE1 (DI), the indicator goes off after 15 seconds. *Please refer to HEAT on page 28 about the HEAT indicator of the electronic controlled engine.*

HEAT indicator (Figure 10, (1)) - When cold starting the engine, in order to activate the glow plug, the starter key needs to be turned to the HEAT position (left side of OFF) (**Figure 10, (5)**). By turning the key to the HEAT position and keeping it at that position, the HEAT indicator (**Figure 10, (1)**) lights up, and after 4 seconds, it turns off. The time the indicator turns off is when to start the operation. In the case of 3CE1 (DI), the indicator goes off after 15 seconds.

Battery charge (Figure 9, (2)) or (Figure 10, (2)) - When the key is turned to the ON position, the charge indicator lights up. When the engine is started, the alternator (or dynamo) generates power, and the battery starts charging. Then the indicator goes off. This indicator will also come on when there is a problem in the charging system. This indicator does not tell you the charging timing (when the battery is low). *See Troubleshooting Chart on page 90.*

Engine oil pressure (Figure 9, (3)) or (Figure 10, (3)) - This indicator will come on if the engine oil pressure is below or exceeds normal limits. *See Troubleshooting Chart on page 90.*

Engine coolant temperature (Figure 9, (4)) or (Figure 10, (4)) - This indicator will come on if the engine coolant temperature exceeds normal limits. *See Troubleshooting Chart on page 90.*

Auxiliary (Figure 9, (5)) - Used for special applications.

PRODUCT OVERVIEW

GAUGES AND INDICATORS OF ELECTRONIC CONTROL SYSTEM



Gauges

The following gauges are located on a typical operator's console of the electronically controlled engines. Some operator's consoles may not have the gauges described here or may have different gauges.

NOTICE

The illustrations and descriptions of optional equipment in this manual, such as the operator's console, are for a typical engine installation. Refer to the documentation supplied by the optional equipment manufacturer for specific operation and maintenance instructions.

Indicators

The following indicators are located on a typical operator's console.

See the *Gauges and Indicators* section for description of indicators that are not described below.

Fault (Figure 11, (1)) (optional) - This indicator will flash if a fault occurs in the E-ECU or Eco-governor. The number of flashes and/or the flashing pattern vary depending on the type or source of the fault. See *Troubleshooting Chart* on page 90.


Auxiliary (Figure 11, (2)) - Reserved as an optional fault indicator.

HEAT (Figure 11, (3)) - This indicator will come on when the glow plugs are energized when cold starting the engine. For the electronic controlled engine, by turning the key switch to the ON position (**Figure 11, (7)**), the ECU detects the temperature of the engine coolant, and the HEAT indicator turns on for a preset period of time (Maximum 15 seconds), then the glow plug will be preheated. The time the lamp came off is when to start the operation.

When an optional after heater is installed, it is energized for up to 80 sec. after the engine has started, during which, however, the indicator is not on.

Others (optional) - Other optional indicators including those for indicating the air cleaner is clogged or the water separator is filled with water can also be installed on the console. See the operation manual for the driven machine for details.

Machine events including alarms and faults are all stored in memory of the E-ECU and can be loaded into the service tool.



Optional key switch: Turning it to ON energizes the glow plugs automatically.

Figure 11

Figure 11 Typical Operator's Console

CONTROLS

Key Switch

The key switch for the operator's console illustrated in **Figure 12** has three positions - OFF, ON, START and HEAT.




Figure 12

NOTICE

For maximum engine life, Isuzu recommends that when shutting the engine down, you allow the engine to idle, without load, for five minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger (if equipped) and exhaust system, to cool slightly before the engine itself is shut down.

OFF (key straight up and down) (**Figure 12, (1)**) and (**Figure 13, (1)**) - When you turn the key to this position the engine shuts down. Electric current to the gauges and indicators is shut off. You can insert and remove the key in this position.

ON (**Figure 12, (2)**) and (**Figure 13, (2)**) - This is the position the key will be in when the engine is running. When the engine is not running, use this position to energize the gauges, indicators, electric fuel pump and auxiliary devices.

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

START (**Figure 12, (3)**) and (**Figure 13, (3)**) - Turn the key to this position to start the engine. As soon as the engine starts, release the key and it will automatically return to the ON position. Some key switches may be equipped with a feature that prevents you from turning the key to the START position while the engine is running. When operating a key switch with this feature, you cannot turn the key to the START position without first returning the key to the OFF position.

The key switch for the operator's console illustrated in **Figure 13** has four positions - OFF, ON, START, and HEAT.

PRODUCT OVERVIEW




Figure 13

NOTICE

For maximum engine life, Isuzu recommends that when shutting the engine down, you allow the engine to idle, without load, for five minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger (if equipped) and exhaust system, to cool slightly before the engine itself is shut down.

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

HEAT (Figure 13, (4)) - You must turn the key to the HEAT position to activate the glow plug. The indicator will flash for several seconds when you turn the key to HEAT. You can turn the key to START when the indicator goes out.

Glow Plugs

Glow plugs help make the engine easy to start at cold temperatures. During the engine starting sequence, the glow plugs are activated for approximately 4 seconds (15 seconds in case of 3CE1). After the pre-heat indicator goes out, the engine can be started.

These plugs are installed in the cylinder head swirl chambers for IDI engines or in the combustion chambers for DI engines.

Governor Lever




Figure 14

NOTICE


Never attempt to adjust the low or high idle speed limit screw. This may impair the safety and performance of the machine and shorten its life. If adjustment is ever required, contact your Isuzu Distributor.

The governor lever (**Figure 14, (1)**) controls the engine speed. The lever is linked to the engine speed control device in the driven machine.

The high idle speed limit screw (**Figure 14, (2)**) restricts the maximum engine speed when the engine is operated without a load.

The low idle speed limit screw (**Figure 14, (3)**) sets engine speed while it is idling.

Engine Stop Solenoid (IDI Engines)



045045-00X00

Figure 15

When the key is turned to the ON position, the engine stop solenoid (**Figure 15, (1)**) is energized and allows the fuel injection pump to deliver fuel to the engine, allowing the engine to be started. When the key is turned to the OFF position, the engine stop solenoid is de-energized and shuts off the fuel supply from the fuel injection pump to the engine, causing the engine to stop.

Speed Control of Electronically Controlled Engines

3CE1

The electronically controlled engines have no governor lever. For these engines, the position signal of the throttle lever or accelerator pedal of the driven machine is converted into an electric signal by the accelerator sensor **Figure 16**, which is then delivered to the rack actuator of the Eco-governor **Figure 18** through the E-ECU **Figure 17**, allowing the engine speed to be controlled.




Figure 16




Figure 17




Figure 18

PRODUCT OVERVIEW

Electronic Engine Speed Control



■ **Start and stop of electronic controlled engines**

The electronic controlled engines have no engine stop solenoid. The ECU controls the engine start/stop sequence.

■ **Engine performance curves**

Figure 20 shows typical engine speed curves that outline the relationship between engine speed and load.

Droop control

The VM series engines for general use are designed so that the engine speed is reduced by a certain percentage from 30 % load to full rated load. See curves (1) in Figure 19 below. The same percentage droop is maintained at any no-load speed.

Isochronous control

The CL series consists of isochronous design engines, the speed of which is kept constant from no load to full rated load. See curves (2) in Figure 19 below.

Some VM series engines for general use may be custom-engineered and have the isochronous capability. Consult the operation manual for the driven machine for application details of such engines.




Figure 19




Figure 20

Figure 20 Typical operator's console and switch arrangement

Low-idling speed up

This feature increases the low-idling speed to some extent depending on the engine coolant temperature. When the coolant temperature reaches a predetermined value, this feature returns the engine speed to the normal low idle setting, thus reducing the warm-up time.

Auto deceleration (optional)

This feature brings the running engine in low idle mode automatically when the accelerator pedal is not operated for a predetermined period of time. When the pedal is operated, i.e., the accelerator sensor is activated, the low idle mode is cancelled.

A certain ON/OFF combination of switches (1) - (4) on the operator's console **Figure 20** will implement this optional feature. For details, see the operation manual for the driven machine.

High-idling speed down (optional)

This feature decreases the high-idling speed depending on the engine coolant temperature. When the coolant temperature falls to a predetermined value, this feature returns the engine speed to the normal high idle setting, thus minimizing the emission of white smoke at low temperatures.

A certain ON/OFF combination of switches (1) - (4) on the operator's console **Figure 20** will implement this optional feature. For details, see the operation manual for the driven machine.

Others

Other optional features can be provided by selecting certain ON/OFF combinations of switches (1) - (4) on the operator's console **Figure 20** will implement this optional feature. For details, see the operation manual for the driven machine.

PRODUCT OVERVIEW

This Page Intentionally Left Blank

BEFORE YOU OPERATE

This section of the Operation Manual describes the diesel fuel, engine oil, and engine coolant specifications and how to replenish them. It also describes the daily engine checkout.

BEFORE YOU OPERATE

DIESEL FUEL

Diesel Fuel Specifications

Diesel fuel should comply with the following specifications. The table lists several worldwide specifications for diesel fuels.

Diesel fuel specification	Location
ASTM D975 No. 1D S15 No. 2D S15	USA
EN590:96	European Union
ISO 8217 DMX	International
BS 2869-A1 or A2	United Kingdom
JIS K2204 Grade No. 2	Japan
KSM-2610	Korea
GB252	China

■ Additional technical fuel requirements

- When operating the engine in cold districts or high altitudes, the fuel cetane number should be equal to 45 or higher.
- **The sulfur content must not exceed 15 ppm by volume. A higher sulfur content fuel may cause sulfuric acid corrosion in the cylinders of the engines. Especially in U.S.A. and Canada, Ultra Low Sulfur fuel must be used.**
- Use the fuel that can be used where the temperature is 12 °C (53.6 °F) lower than the expected lowest temperature to prevent the fuel from freezing.
- Bio-diesel fuels. *See Bio-diesel fuels on page 37.*
- Water and sediment in the fuel should not exceed 0.05 % by volume.
- Ash content not to exceed 0.01 % by volume.
- Carbon residue content not to exceed 0.35 % by volume. Less than 0.1 % is preferred.
- Total aromatics content should not exceed 35 % by volume. Less than 30 % is preferred.

- PAH (Polycyclic Aromatic Hydrocarbons) content should be below 10 % by volume.
- Metal content of Mg, Si, and Al should be equal to or lower than 1 mass ppm. (Test analysis method JPI-5S-44-95)
- The diesel fuel should be free from Zn and Na.
- Lubricity: Wear mark of WS1.4 should be Max. 0.018 in. (460 μm) at HFRR test.

■ Precautions and concerns regarding the use of diesel fuel

- Never use kerosene.
- Never mix kerosene or used engine oil with the diesel fuel.
- Never use residual fuels that cause diesel fuel filter clogging and carbon deposits on the nozzles.
- Never use fuels stored for long time in a drum can or the like.
- Never keep fuel in containers with zinc plating on the inside.
- Never use fuels purchased from unauthorized dealer.
- Fuel additives are not recommended. Some fuel additives may cause poor engine performance. Consult your Isuzu representative for more information.

BEFORE YOU OPERATE

■ Bio-diesel fuels

General description of biodiesel

1. Biodiesel is a renewable, oxygenated fuel made from agricultural and renewable resources such as soybeans or rapeseeds. Biodiesel is a fuel comprised of methyl or ethyl ester oxygenates of long chain fatty acids derived from the transesterification of vegetable oils, animal fats, and cooking oils. It contains no petroleum-based diesel fuel but can be blended at any level with petroleum-based diesel fuel. In case it is not blended with petroleum-based diesel fuel such biodiesel is referred to as "B100", which means that it consists of 100 % (pure) biodiesel. However, most common biodiesel is blended with conventional (petroleum-based) diesel fuel. The percentage of the blend can be identified by its name. For example, "B7" consists of 7 % biodiesel and 93 % conventional diesel fuel. The unprocessed vegetable oil is not considered as diesel fuel.

2. Advantages of biodiesel:

- Biodiesel produces less visible smoke and a lower amount of particulate matter.
- Biodiesel is biodegradable and nontoxic.
- Biodiesel is safer than conventional diesel fuel because of its higher flash point.

Following the increased interest in the reduction of emissions and the reduction of the use of petroleum distillate based fuels; many governments and regulating bodies encourage the use of biodiesel.

3. Disadvantages of biodiesel:

Concentrations that are higher than 7 % of biodiesel (higher than B7) can have an adverse affect on the engine's performance, its integrity and/or durability. The risk of problems occurring in the engine increases as the level of biodiesel blend increases. The following negative affects are exemplary and typical for the usage of high concentrated biodiesel blends:

- Biodiesel can accelerate the oxidation of Aluminum, Brass, Bronze, Copper and Zinc.
- Biodiesel damages, and finally seeps through certain seals, gaskets, hoses, glues and plastics.
- Certain natural rubbers, nitride and butyl rubbers will become harder and more brittle as degradation proceeds when used with biodiesel.
- The deteriorated biodiesel creates deposits in the engines.
- Due to its natural characteristic, biodiesel will decrease the engine output by approximately 2 percent (in case of B20) comparing to conventional (petroleum-based) diesel fuel.
- The fuel consumption ratio will increase by approximately 3 percent (in case of B20) comparing to conventional diesel fuel.

Approved engines

Isuzu C series engine can be operated with biodiesel with concentrations up to B20. In case of using biodiesel fuel up to B7 concentrations, no special preparations etc. have to be made and the original operating conditions and service intervals as stated in the operating manuals apply. In case of running below indicated engines with biodiesel concentrations from B8 to B20, the required operating conditions (*see below **Conditions for the operation with biodiesel (from B8 to B20)***) have to be observed.

Other than the following listed engines cannot be run with biodiesel:

- 3CE1, 3CH1 and 3CJ1 Tier 4

BEFORE YOU OPERATE

Approved fuel

In case of using biodiesel (only concentrations up to B20) such fuel should comply with the below recommended standards. However, raw pressed vegetable oils are not considered to be biodiesel and are not acceptable for use as fuel in any concentration in Isuzu engines.

1. EN14214 (European standard) and/or ASTM D-6751 (American standard).
In North America, biodiesel and biodiesel blends must be purchased from the BQ-9000 accredited producers and BQ-9000 certified distributors.
2. All applicable engines can be operated with biodiesel fuel up to B20 (20 % bio-fuel blend) as a maximum concentration.
(For your information: In Japan, the legally allowed maximum concentration for on-road applications is B5.)

Conditions for the operation with biodiesel (from B8 to B20)

When operating your applicable Isuzu C series engine with biodiesel blends concentrated above B8, we seriously recommend observing the following operation, service and maintenance conditions:

1. The original service interval of the below stated services as indicated in the respective Isuzu engine standard operation manual, the application manual and the service manual should be halved (please refer to your own manuals for the each service interval):
 - Replacement interval of engine oil filter, engine oil and the fuel filter.
 - Cleaning interval of the water separator
 - Drain interval of the fuel tank.
2. It is required to inspect, clean and adjust the fuel injector every 1000 operating hours.
3. Before using the bio-diesel fuel of B10 or higher, replace the following parts.
 - Fuel hose (The hose must be replaced every 2 years or 2000 hours regardless of the bio fuel type.)
 - O-ring of fuel filter

- O-ring of water separator
- When replacing a diaphragm type fuel feed pump to an electronic type, replace to the feed pump and the pump cover instructed to the attached list.
- If the water separator is not attached, it needs to be attached.

Please refer to the attached list of exchange parts for details.

4. Please use only biodiesel fuel that is appropriate to the intended operation environment of the engines. This especially applies if the operating ambient temperature falls below 0 degree centigrade.
5. In particular, operation with biodiesel requires daily maintenance as follows:
 - Please daily check the engine oil level. If the oil level rises above the oil level of the previous day, the engine oil needs to be immediately replaced.
 - Please daily check the water level of the water separator. If the water level rises above the "max" indicator, an immediate drain of the water separator is required.
6. Biodiesel blends up to B20 can only be used for a limited time of up to 3 months of the date of biodiesel manufacture. Therefore biodiesel needs to be used at latest within 2 months from the time of filling the tank or within 3 months from the time of production by the fuel supplier, whichever comes first.
7. Before a long-term storage without operating the engine, the biodiesel needs to be drained out completely and the engine has to be run for 30 minutes with conventional diesel fuel as indicated in your operation manual.


BEFORE YOU OPERATE

■ KIT parts list for B10 through B 20

		3CH1, 3CJ1	3CE1
		5-8640-2407-0	5-8640-2408-0
Fuel oil tank - / - Fuel oil tank	No.	(1)	(1)
	Length	2000	2000
	Part No.	5-8640-2241-0	5-8640-2241-0
	Part name	FO-T CMP	FO-T CMP
	Number	2	2
Fuel feed pump - Fuel oil filter	No.	(3)	(4)
	Length	450	1000
	Part No.	5-8640-2242-0	5-8640-2247-0
	Part name	FO-T CMP	FO-T CMP
	Number	1	1
Fuel oil filter - Fuel injection pump	No.	(6)	(5)
	Length	270	220
	Part No.	5-8640-2243-0	5-8640-2248-0
	Part name	FO-T CMP	FO-T CMP
	Number	1	1
Fuel injection pump - Fuel oil filter	No.	(11)	(7)
	Length	450	300
	Part No.	5-8640-2244-0	5-8640-2249-0
	Part name	FO-T CMP	FO-T CMP
	Number	1	1
Cap, fuel injection nozzle	Part No.		5-8640-1423-0 5-8640-0112-0
	Part name	No need	CAP CLIP
	Number		1 1
Fuel injection nozzle -Fuel injection nozzle	No.		(13)
	Length		115
	Part No.	No need	5-8640-1791-0
	Part name		FO-T CMP
	Number		2
Fuel injection nozzle - Fuel injection pump	No.	(16)	(17)
	Length	150	Formed pipe
	Part No.	5-8640-2245-0	5-8640-2250-0
	Part name	FO-T CMP	FO-T CMP
	Number	1	1
Fuel oil filter		Need to change only O-ring. P44: 5-8640-2246-0 --> A	No need (Because of cartridge type)
Water separator		Need to change only O-ring. P44: 5-8640-2246-0 --> B	Need to change only O-ring. G75 : 5-8640-2251-0 --> C P16 : 5-8640-1755-0 --> D P7 : 5-8640-2252-0 --> E G65 : 5-8640-2418-0 --> C (Need only for TAIYO-GIKEN)

		5-8640-2409-0
Fuel feed pump		Electric feed pump: 5-8640-0024-0 Cover assy, feed pump: 5-8640-1927-0

BEFORE YOU OPERATE



BEFORE YOU OPERATE

Filling the Fuel Tank

⚠ DANGER**Fire and Explosion Hazard!**

- Diesel fuel is flammable and explosive under certain conditions.



- Only fill the fuel tank with diesel fuel. Filling the fuel tank with gasoline may result in a fire and will damage the engine.
- Never refuel with the engine running.
- Wipe up all spills immediately.
- Keep sparks, open flames or any other form of ignition (match, cigarette, static electric source) well away when refueling.
- Never overfill the fuel tank.
- Fill the fuel tank. Store any containers containing fuel in a well-ventilated area, away from any combustibles or sources of ignition.
- Be sure to place the diesel fuel container on the ground when transferring the diesel fuel from the pump to the container. Hold the hose nozzle firmly against the side of the container while filling it. This prevents static electricity buildup which could cause sparks and ignite fuel vapors.
- Never place diesel fuel or other flammable material such as oil, hay or dried grass close to the engine during engine operation or shortly after shutdown.
- Before you operate the engine, check for fuel leaks. Replace rubberized fuel hoses every two years or every 2000 hours of engine operation, whichever comes first, even if the engine has been out of service. Rubberized fuel lines tend to dry out and become brittle after two years or 2000 hours of engine operation, whichever comes first.
- Failure to comply will result in death or serious injury.

NOTICE

- Only use diesel fuels recommended by Isuzu for the best engine performance, to prevent engine damage and to comply with EPA/ARB warranty requirements.
- Only use clean diesel fuel.
- Never remove the primary strainer (if equipped) from the fuel tank filler port. If removed, dirt and debris could get into the fuel system causing it to clog.

Note that a typical fuel tank is shown. The fuel tank on your equipment may be different.

1. Clean the area around the fuel cap (**Figure 1, (1)**).
2. Remove the fuel cap from the fuel tank (**Figure 1, (2)**).
3. Observe the fuel level sight gauge (**Figure 1, (3)**) and stop filling when gauge shows fuel tank is full. Never overfill the fuel tank.
4. Replace the fuel cap (**Figure 1, (1)**), hand tighten. Over tightening the fuel cap will damage it.




Figure 1

BEFORE YOU OPERATE

Priming the Fuel System

⚠ DANGER

Fire and Explosion Hazard!

- Diesel fuel is flammable and explosive under certain conditions.



- If the unit has an electric fuel pump, when you prime the fuel system, turn the key switch to the ON position for 10 to 15 seconds to allow the electric fuel pump to prime the system.
- If the unit has a mechanical fuel pump, when you prime the fuel system, operate the fuel priming lever of the mechanical fuel pump several times until the fuel filter cup is filled with fuel.
- Failure to comply will result in death or serious injury.



The fuel system needs to be primed under certain conditions:

- Before starting the engine for the first time
- After running out of fuel and fuel has been added to the fuel tank
- After fuel system maintenance such as changing the fuel filter and draining the water separator, or replacing a fuel system component.

To prime the fuel system if an electric fuel pump is installed:

1. Turn the key to the ON position for 10 to 15 seconds. This will allow the electric fuel pump to prime the fuel system.
2. Never use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion and/or ring gear.

To prime the fuel system if a mechanical fuel pump is installed:

1. Operate the fuel priming lever (**Figure 2, (1)**) several times until the fuel filter cup (**Figure 2, (2)**) is filled with fuel.
2. Never use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion and/or ring gear.




Figure 2

BEFORE YOU OPERATE

The fuel system needs to be primed under certain conditions:

- Before starting the engine for the first time
- After running out of fuel and fuel has been added to the fuel tank
- After fuel system maintenance such as changing the fuel filter and draining the water separator, or replacing a fuel system component.

To prime the fuel system:

1. Turn the key to the ON position for 10 to 15 seconds. This will allow the electric fuel pump to prime the fuel system.
2. Never use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion and/or ring gear.

ENGINE OIL**NOTICE**

- Only use the engine oil specified. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine oil. Carefully clean the oil cap/dipstick and the surrounding area before you remove the cap.
- Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.

Engine Oil Specifications

Use an engine oil that meets or exceeds the following guidelines and classifications:

■ Service categories

- API service categories CD, CF, CF-4, CI-4 (Use an API CF or higher quality oil for electronically controlled engines.)
- ACEA service categories E-3, E-4, and E-5
- JASO service category DH-1

■ Definitions

- API classification (American Petroleum Institute)
- ACEA classification (Association des Constructeurs Européens d'Automobiles)
- JASO (Japanese Automobile Standards Organization)

BEFORE YOU OPERATE

Note:

- Be sure the engine oil, engine oil storage containers, and engine oil filling equipment are free of sediments and water.
- Change the engine oil after the first 50 hours of operation and then at every 250 hours thereafter.
- Select the oil viscosity based on the ambient temperature where the engine is being operated. See the SAE Service Grade Viscosity Chart (Figure 3).
- Isuzu does not recommend the use of engine oil "additives."

■ Additional technical engine oil requirements:

The engine oil must be changed when the Total Base Number (TBN) has been reduced to 1.0 mgKOH/g. TBN (mgKOH/g) test method; JIS K-201-5.2-2 (HCl), ASTM D4739 (HCl).

Engine Oil Viscosity

Select the appropriate engine oil viscosity based on the ambient temperature and use the SAE service grade viscosity chart in Figure 3.





Figure 3

Checking Engine Oil

1. Make sure engine is level.
2. Remove dipstick (Figure 4, (1)) and wipe with clean cloth.
3. Fully reinsert dipstick.
4. Remove dipstick. The oil level should be between upper (Figure 4, (2)) and lower (Figure 4, (3)) lines on the dipstick.
5. Fully reinsert dipstick.

Adding Engine Oil

1. Make sure engine is level.
2. Remove oil cap (Figure 4, (4)).
3. Add indicated amount of engine oil at the top or side engine oil filler port (Figure 4, (5)).
4. Wait three minutes and check oil level.
5. Add more oil if necessary.
6. Reinstall oil cap (Figure 4, (4)) and hand-tighten. Over-tightening may damage the cap.



BEFORE YOU OPERATE




Figure 4

CAUTION

To refuel the engine oil, refuel slowly after removing the dipstick and both caps. If you refuel rapidly, the oil intrusion to the intake occurs through the PCV valve of the valve cover. It will result in an oil hammer at engine start, which may cause damage to the engine.

Engine Oil Capacity (Typical)

Note: These are the engine oil capacities associated with a "Deep Standard" oil pan. Oil capacity will vary dependent upon which optional oil pan is used. Refer to the operation manual provided by the driven machine manufacturer for the actual engine oil capacity of your machine.

The following are the engine oil capacities for various Isuzu C series engine.

 Engine oil capacity (typical)	
Engine model	Dipstick upper limit/lower limit
3CH1-NGZG01 3CH1-SDZP01	3.6/1.9 qt (3.4/1.8 ℓ)
3CJ1-NGZG01	3,0/1,6 qt (2,8/1,5 ℓ)
3CJ1-SDZP01	3.1/1.7 qt (2.9/1.6 ℓ)

 Engine oil capacity (typical)	
Engine model	Dipstick upper limit/lower limit
3CE1	7.1/4.1 qt (6.7/3.9 ℓ)

BEFORE YOU OPERATE

ENGINE COOLANT

⚠ DANGER



Scald Hazard!

- Never remove the radiator cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the radiator cap.

- Tighten the radiator cap securely after you check the radiator. Steam can spurt out during engine operation if the cap is loose.
- Always check the level of the engine coolant by observing the reserve tank.
- Failure to comply will result in death or serious injury.

⚠ WARNING



Burn Hazard!

- Wait until the engine cools before you drain the engine coolant. Hot engine coolant may splash and burn you.

- Failure to comply could result in death or serious injury.

⚠ CAUTION

Coolant Hazard!



- Wear eye protection and rubber gloves when you handle long life or extended life engine coolant. If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

- Failure to comply may result in minor or moderate injury.

NOTICE

- Only use the engine coolant specified. Other engine coolants may affect warranty coverage, cause an internal buildup of rust and scale and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine coolant. Carefully clean the radiator cap and the surrounding area before you remove the cap.
- Never mix different types of engine coolants. This may adversely affect the properties of the engine coolant.

BEFORE YOU OPERATE**Engine Coolant Specifications**

Use a Long Life Coolant (LLC) or an Extended Life Coolant (ELC) that meets or exceeds the following guidelines and specifications.

- ASTM D6210, D4985 (US)
- JIS K-2234 (Japan)
- SAE J814C, J1941, J1034 or J2036 (International)

Alternative engine coolant

If an Extended or Long Life Coolant is not available, alternatively, you may use an ethylene glycol or propylene glycol based conventional coolant (green).



NOTICE

- Always use a mix of coolant and water. Never use water only.
- Mix coolant and water per the mixing instructions on the coolant container.
- Water quality is important to coolant performance. Isuzu recommends that soft, distilled or demineralized water be used to mix with coolants.
- Never mix extended or long life coolants and conventional (green) coolants.
- Never mix different types and/or colors of extended life coolants.
- Replace the coolant every 1000 engine hours or once a year.

Filling Radiator with Engine Coolant

Fill the radiator and reserve tank as follows. This procedure is for filling the radiator for the first time or refilling it after it is flushed. Note that a typical radiator is illustrated.

1. Check to be sure the radiator drain plug is installed and tightened or the drain valve (**Figure 5, (1)**) is closed. Also make sure the coolant drain plug (**Figure 6, (1)**) in the cylinder block is closed.

**Figure 5****Figure 6**

BEFORE YOU OPERATE

2. Remove the radiator cap (**Figure 5, (2)**) by turning it counterclockwise about 1/3 of a turn.
3. Pour the engine coolant slowly into the radiator until it is even with the lip of the engine coolant filler port. Make sure that air bubbles do not develop as you fill the radiator.
4. Reinstall the radiator cap (**Figure 5, (2)**). Align the tabs on the back side of the radiator cap with the notches on the engine coolant filler port. Press down and turn the cap clockwise about 1/3 of a turn.
5. Remove the cap of the reserve tank (**Figure 5, (3)**), and fill it to the LOW (COLD) mark (**Figure 5, (4)**) with engine coolant. Reinstall the cap.
6. Check the hose (**Figure 5, (5)**) that connects the reserve tank (**Figure 5, (3)**) to the radiator. Be sure it is securely connected and there are no cracks or damage. If the hose is damaged, engine coolant will leak out instead of going into the reserve tank.
7. Run the engine until it reaches operating temperature. Check the level of engine coolant in the reserve tank. When the engine is running and the engine coolant is at normal temperature, the coolant level in the reserve tank should be at or near the FULL (HOT) mark (**Figure 5, (6)**). If the coolant is not at the FULL (HOT) mark, add coolant to the reserve tank to bring the coolant level to the FULL (HOT) mark.

Daily Check of the Cooling System

1. Check the level of engine coolant in the reserve tank. When the engine is cold, the coolant level in the tank should be at or slightly above the LOW (COLD) mark (**Figure 5, (4)**) on the coolant reserve tank.
If the coolant level is at the FULL (HOT) mark (**Figure 5, (6)**) when the engine is cold, the coolant will expand when it becomes hot and possibly spray out of the overflow hose.
2. Add additional engine coolant to the reserve tank if necessary.
3. Check the radiator hoses for cracks, abrasions, cuts or other damage. Replace as necessary.

Engine Coolant Capacity (Typical)

Note: Capacities listed are for the engine only without a radiator. Refer to the operation manual provided by the driven machine manufacturer for actual engine coolant capacity on your machine.

The following are the engine coolant capacities for various Isuzu C series engine.

 Engine coolant capacity (typical)	
Engine model	Engine coolant capacity
3CH1-NGZG01 3CH1-SDZP01	1.0 qt (0.9 ℓ)
3CJ1-NGZG01	1.0 qt (0.9 ℓ)
3CJ1-SDZP01	1.1 qt (1.0 ℓ)

 Engine coolant capacity (typical)	
Engine model	Engine coolant capacity
3CE1	2.1 qt (2.0 ℓ)

BEFORE YOU OPERATE

DAILY CHECKS

Before you begin any job, make sure the Isuzu C series engine is in good operating condition. Make sure you check the following items before you start your shift and have any repairs completed before you start work.

WARNING

High-Pressure Hazard!



- **Avoid skin contact with the high-pressure diesel fuel spray caused by a fuel system leak such as a broken fuel injection line. High-pressure fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure fuel spray, obtain prompt medical treatment.**
- **Never check for a fuel leak with your hands. Always use a piece of wood or cardboard. Have your Isuzu Distributor repair the damage.**
- **Failure to comply could result in death or serious injury.**

NOTICE

Make it a habit to perform daily checks. See *Daily Checks in the Before You Operate Section of this manual.*

Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor machine performance and helps extend the life of the engine.

Visual Checks

1. Check for engine oil leaks.
2. Check for fuel leaks.
3. Check for engine coolant leaks.
4. Check for damaged or missing parts.
5. Check for loose, missing or damaged fasteners.
6. Check the electrical harnesses for cracks, abrasions, and damaged or corroded connectors.
7. Check hoses for cracks, abrasions, and damaged, loose or corroded clamps.
8. Check and clean radiator fins as necessary. See *Check and clean radiator fins on page 76.*
9. Check the water separator for presence of water and contaminants. If you find any water or contaminants, drain the water separator. See *Drain water separator on page 71.* If you have to drain the water separator frequently, drain the fuel tank and check for the presence of water in your fuel supply. See *Drain fuel tank on page 75.*

NOTICE

If any problem is noted during the visual check, the necessary corrective action should be taken before you operate the engine.

Check Diesel Fuel, Engine Oil and Engine Coolant Levels

Follow the procedures in *Diesel Fuel on page 36*, *Engine Oil on page 43* and *Engine Coolant on page 46* to check these levels.

Check Engine Speed Control

Check the engine speed control for smooth operation, adjust and lubricate or clean as necessary. See *Check and adjust the governor lever and engine speed control (except electronically controlled engines) on page 77.*

BEFORE YOU OPERATE

Check Operator's Console

Before you operate the engine you should make sure that all of the indicators are functioning properly.

Check Indicators

Isuzu C series engine are available with various operator's consoles. In the below Figures, three types of typical operator's console including the one for electronic controlled engines are shown as examples.




Figure 7




Figure 8




Figure 9

HEAT

Figure 8 shows a typical indicator arrangement on the operator's console. With the specification of standard glow (preheat), as you turn the key switch to the HEAT position, the HEAT indicator is turned on for 4 seconds, showing that the glow plugs are energized. When the indicator goes off, turn the key switch to START position and start the engine. In the case of 3CE1 (DI), the indicator goes off after 15 seconds.

Figure 7 shows an indicator arrangement with the specification for ON-glow. As you turn the key switch to ON position, the HEAT indicator is turned on for 4 seconds. When the indicator goes off, turn the key switch to the START position and start the engine. In the case of 3CE1 (DI), the indicator goes off after 15 seconds.

Figure 9 shows an operator's console of an electronic controlled engine. The electronic controlled engine has an ON-glow specification. Depending on the water temperature, the heat indicator will turn on for 15 seconds at the longest, and preheats the glow plugs. When the indicator goes off, turn the key switch to the START position and start the engine.

BEFORE YOU OPERATE

Battery charge (Figure 7, (2)) or (Figure 8, (2)) or (Figure 9, (4)) - Stays on until the engine is running and the alternator is supplying charging current. This indicator does not indicate whether the battery is discharged.

Engine oil pressure (Figure 7, (3)) or (Figure 8, (3)) or (Figure 9, (5)) - Stays on until the engine is running and the oil pressure is within normal limits.

Engine coolant temperature (Figure 7, (4)) or (Figure 8, (4)) or (Figure 9, (6)) - Stays on momentarily. Comes back on if engine overheats.

Auxiliary (Figure 7, (5)) or (Figure 9, (2)) - Stays on momentarily. Used for special applications.

Here is a summary of how these indicators function. The table shows what happens when you turn the key in a certain direction (e.g., OFF to ON).

Fault indicator (Figure 9, (1)) (optional) - Illuminates for approx. 2 sec. when the key switch is turned to ON, and stays off while the engine is running. If a fault occurs in the Eco-governor system or during energization of the E-ECU, this indicator will flash in a certain pattern to indicate what fault has occurred. See the troubleshooting section for details.

BEFORE YOU OPERATE

Indicator		OFF to HEAT	OFF to ON	ON to OFF	
HEAT Figure 7, (1) Figure 8, (1) Figure 9, (3)	ON-glow type	Glow	NA	IDI (3CH1, 3CJ1) turns off after indicating for 4 seconds. DI (3CE1) turns off after indicating for 15 seconds. Note that, for electronic control type engines (3CE1), the indicators are controlled from 1 to 15 seconds depending on the temperature of cooling water.	OFF
	HEAT position available on key switch	Glow	IDI (3CH1, 3CJ1) turns off after indicating for 4 seconds. DI (3CE1) turns off after indicating for 15 seconds.	OFF	OFF
Battery charge Figure 7, (2) Figure 8, (2) Figure 9, (4)		NA	ON	OFF (Stays on until alternator is supplying charging current. Remains on if there is a problem in the charging system. This indicator does not indicate whether the battery is discharged.)	
Engine oil pressure Figure 7, (3) Figure 8, (3) Figure 9, (5)		NA	ON	OFF (Stays on until oil pressure reaches normal operating pressure. Remains on, or comes back on, if there is a problem in the lubrication system.)	
Engine coolant temperature Figure 7, (4) Figure 8, (4) Figure 9, (6)		NA	ON	OFF (Stays on momentarily. Comes back on if there is a problem in the cooling system.)	
Auxiliary Figure 7, (5) Figure 9, (2)		NA	ON	OFF	
Fault (optional) Figure 9, (1) 3CE1		NA	Lights for 2 sec. only.	OFF (Flashes or intermittently lights if a fault occurs in the E-ECU or Eco-governor.)	

ENGINE OPERATION

This section of the Operation Manual describes the procedures for starting the engine, checking engine performance during operation, and shutting the engine down.

ENGINE OPERATION

STARTING ENGINE

Use the following procedure to start the engine. Note that two typical operator's consoles are shown for illustrative purposes only.

1. Make sure you follow the procedures stated in the *Daily Checks* on page 49.
2. Before first starting electronically controlled engines 3CE1: The E-ECU of the electronically controlled engines shown above needs to be initialized at initial power up. When the fault indicator comes on at initial power up, the E-ECU has finished initialization. Then always turn the key switch to the OFF position once before starting the engine. (The E-ECU has usually been initialized before the driven machine is delivered). From the second power up, make sure the fault indicator is on for 2 sec. when turning the key switch to the ON position.
3. Make sure the water separator fuel valve (**Figure 1, (1)**) is in the ON position (**Figure 1, (2)**).





Figure 1

4. Set the transmission (if equipped) in the NEUTRAL position.
5. Disengage the PTO (if equipped).
6. Set the engine speed control to the mid-position.




Figure 2

NOTICE

Never use an engine starting aid such as ether. Engine damage will result.

7. Insert the key into the key switch (**Figure 2, (1)**) or (**Figure 3, (1)**).

ENGINE OPERATION




Figure 3

8. Turn the key to the ON position (**Figure 2, (2)**) or the HEAT position (**Figure 3, (2)**). The pre-heat indicator (**Figure 2, (3)**) flashes for several seconds and then goes out. After the pre-heat indicator goes out you can start the engine.

Note: The glow plugs are used to assist starting in cold weather conditions. If you are operating your engine in normal or warm weather conditions, you may bypass the Pre-Heat/Heat functions and go directly to Start.

NOTICE

Never hold the key in the START position for longer than 15 seconds or the starter motor will overheat.

9. Turn the key clockwise to the START position (**Figure 2, (4)**) or (**Figure 3, (4)**). Release the key as soon as the engine starts. It will return to the ON position (**Figure 2, (2)**) or (**Figure 3, (5)**).

Note: The starter of electronically controlled engines 3CE1 will start with a delay of approx. 0.5 sec. after the key switch has been turned to the ON position. This is because the E-ECU self-diagnostics has run and is not a failure.

10. If the engine fails to start:

- 1- Wait until the engine comes to a complete stop before you attempt to start it again. Engaging the starter while the engine is still rotating will result in damage to the starter and flywheel.

Note: Some key switches are equipped with an interlock that will not allow you to re-engage the starter without first turning the key to the OFF position.

- 2- Wait at least 30 seconds before you attempt to start the engine again. This procedure will allow the battery voltage to recover and prevent damage to the starter motor due to the low battery voltage.

ENGINE OPERATION



COLD START DEVICE

⚠ WARNING

Sudden Movement Hazard!

- **Engaging the transmission or PTO at an elevated engine speed could result in unexpected movement of the equipment.**
- **Failure to comply could result in death or serious injury.**

The cold start device on direct injection models improves engine starting at lower temperatures.

- If the engine cooling system temperature is below 5 °C (41 °F), the cold start device automatically advances the fuel injection timing and slightly increases the fuel injection volume.
- The engine idle speed will be slightly elevated for approximately the first 5 minutes of operation.
- When the cold start device is activated, you may notice a slight increase in the amount of exhaust smoke. This is normal.
- Never engage the transmission or PTO while the cold start device is activated or unexpected movement of the machine may result.

HIGH-ALTITUDE INJECTION CONTROL DEVICE

3CH1, 3CJ1

This series has a high-altitude injection control device installed. It suppresses black smoke when operating at high altitudes and at the same time aims to control particulate matter.

The device consists of an output control solenoid that is attached to the fuel injection pump and a solenoid driver (with an atmospheric pressure sensor) that is assembled on the implement side. The output control solenoid actuates at engine start. (It does not actuate during engine operation.) At engine start, the starter operates and the engine starts running. 4 seconds after the starter turns off, the solenoid driver measures the atmospheric pressure and determines whether to actuate the solenoid. (The solenoid is energized during normal operation, but it is turned off during the start of the control device.) If at this time the atmospheric pressure sensor determines that the altitude is 2624 ft (800 m) or more, the control device operates. It reduces the fuel injection amount and thus controls the occurrence of black smoke. Because of this reduction in the injection amount, the output decreases. At 5500 ft (1676 m), the decrease in output (i.e. torque) is 20 % of the maximum at low altitudes. Therefore, only apply medium to low load when operating at high altitudes.

NOTICE

The injection control device does not actuate during engine operation. (Switch operation is not performed.) Therefore, when the control device is not yet operating and the machine is moved to a high altitude during operation, or when the control device is already operating and the machine is moved to a low altitude, turn the key switch to OFF (engine stop). This resets the control device. After re-starting the engine, the necessity for injection control is again determined.




Figure 4

CHECKING THE ENGINE DURING OPERATION

⚠ WARNING



High-Pressure Hazard!

- Avoid skin contact with the high-pressure diesel fuel spray caused by a fuel system leak such as a broken fuel injection line. High-pressure fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure fuel spray, obtain prompt medical treatment.
- Never check for a fuel leak with your hands. Always use a piece of wood or cardboard. Have your Isuzu Distributor repair the damage.
- Failure to comply could result in death or serious injury.

NOTICE

Make sure the engine is installed on a level surface. If a continuously running engine is installed at an angle greater than (IDI = 25°, DI = 30°) in any direction or if an engine runs for short periods of time (less than three minutes) at an angle greater than (IDI = 30°, DI = 35°) in any direction, engine oil may enter the combustion chamber causing excessive engine speed and white exhaust smoke. This may cause serious engine damage.

ENGINE OPERATION

NOTICE

New engine break-in:

- On the initial engine start-up, allow the engine to idle for approximately 15 minutes while you check for proper engine oil pressure, diesel fuel leaks, engine oil leaks, coolant leaks, and for proper operation of the indicators and/or gauges.
- During the first hour of operation, vary the engine speed and the load on the engine. Short periods of maximum engine speed and load are desirable. Avoid prolonged operation at minimum or maximum engine speeds and loads for the next four to five hours.
- During the break-in period, carefully observe the engine oil pressure and engine temperature.
- During the break-in period, check the engine oil and coolant levels frequently.

NOTICE

Never engage the starter motor while the engine is running. This may damage the starter motor pinion and/or ring gear.

1. While the engine is running, check the gauges for normal indications. The gauges shown in **Figure 6** and **Figure 5** are provided for illustrative purposes only.




Figure 5




Figure 6

- **Tachometer (Figure 6, (1)) or (Figure 5, (1))** - Make sure the engine speed is within normal limits.
- **Engine oil pressure (Figure 6, (2)) or (Figure 5, (3))** - Make sure the engine oil pressure is within normal limits. See *Principal Engine Specifications* on page 105.
- **Engine coolant temperature (Figure 6, (3)) or (Figure 5, (2))** - Make sure the engine coolant temperature is within normal limits.
- **Hour meter** - The hour meter display **(Figure 6, (4)) or (Figure 5, (4))** shows the total number of hours the engine has run. This is useful for planning periodic maintenance operations. See *Periodic Maintenance Schedule* on page 64.
- If any of the gauges shows an out of normal limits condition, shut down the engine and have the necessary repairs performed.

2. After the engine has reached operating temperature, all of the indicators (**Figure 6, (5)**) or (**Figure 5, (5)**) should be off. If any of the indicators are on, shut down the engine and have the necessary repairs performed.
3. Check for white or black smoke from the exhaust system. A small amount of white exhaust smoke is normal on start-up of a cold engine. Black exhaust smoke could mean the engine is overloaded or is being over-fueled. If either of these conditions persists, contact your Isuzu Distributor.
4. Check for abnormal sounds or vibration. In some applications the engine and its mounting may start to resonate and cause unusual vibrations at certain engine speeds. Avoid running the engine at these speeds. If the abnormal sounds or vibration cannot be resolved, shut down the engine and have the necessary repairs performed. Contact your Isuzu Distributor.
5. Check for any fuel, engine coolant or engine oil leaks. If any leaks are found shut down the engine and have the necessary repairs performed.
6. Check the fuel level during operation. If the fuel level runs low, stop the engine and refuel.

ADJUST ENGINE SPEED

NOTICE

New engine break-in:

- On the initial engine start-up, allow the engine to idle for approximately 15 minutes while you check for proper engine oil pressure, diesel fuel leaks, engine oil leaks, coolant leaks, and for proper operation of the indicators and/or gauges.
- During the first hour of operation, vary the engine speed and the load on the engine. Short periods of maximum engine speed and load are desirable. Avoid prolonged operation at minimum or maximum engine speeds and loads for the next four to five hours.
- During the break-in period, carefully observe the engine oil pressure and engine temperature.
- During the break-in period, check the engine oil and coolant levels frequently.

Use the engine speed control to adjust the engine speed for the task that will be performed.

ENGINE OPERATION

SHUTTING DOWN THE ENGINE

NOTICE

For maximum engine life, Isuzu recommends that when shutting the engine down, you allow the engine to idle, without load, for five minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger (if equipped) and exhaust system, to cool slightly before the engine itself is shut down.

Follow these steps to shut down the engine:

1. Disengage the PTO and/or set the transmission to NEUTRAL (if equipped).
2. Set the engine speed control to its lowest setting.
3. Run the engine at low idle speed for at least five minutes before you shut it down.




Figure 7

4. Turn the key to the OFF position (**Figure 7, (1)**) or (**Figure 8, (1)**) and remove it from the key switch.




Figure 8

5. If the engine will not be used for six months or longer, follow the additional instructions in *Long-Term Storage on page 99*.

PERIODIC MAINTENANCE

This section of the Operation Manual describes the procedures for proper care and maintenance of the engine.

PERIODIC MAINTENANCE

PRECAUTIONS

The Importance of Periodic Maintenance

Engine deterioration and wear occurs in proportion to length of time the engine has been in service and the conditions the engine is subject to during operation. Periodic maintenance prevents unexpected downtime, reduces the number of accidents due to poor machine performance and helps extend the life of the engine.

Performing Periodic Maintenance

WARNING

Exhaust Hazard!



- **Never operate the engine in an enclosed area such as a garage, tunnel, underground room, manhole or ship's hold without proper ventilation.**
- **Never block windows, vents, or other means of ventilation if the engine is operating in an enclosed area. All internal combustion engines create carbon monoxide gas during operation. Accumulation of this gas within an enclosure could cause illness or even death.**
- **Make sure that all connections are tightened to specifications after repair is made to the exhaust system.**
- **Failure to comply could result in death or serious injury.**

Perform periodic maintenance procedures in an open, level area free from traffic. If possible, perform the procedures indoors to prevent environmental conditions, such as rain, wind, or snow, from damaging the machine.

The Importance of Daily Checks

Periodic Maintenance Schedules assume that the daily checks are performed on a regular basis. Make it a habit of performing daily checks before the start of each shift. *See Daily Checks on page 49.*

Keep a Log of Engine Hours and Daily Checks

Keep a log of the number of hours the engine is run each day and a log of the daily checks performed. Also note the date, type of repair (e.g., replaced alternator), and parts needed for any service needed between the periodic maintenance intervals. Periodic maintenance intervals are every 50, 250, 500, 1000, 1500, 2000 and 3000 engine hours. Failure to perform periodic maintenance will shorten the life of the engine.

Isuzu Replacement Parts

Isuzu recommends that you use "Isuzu genuine parts" when replacement parts are needed. Genuine replacement parts help ensure long engine life.

Tools Required

Before you start any periodic maintenance procedure make sure you have the tools you need to perform all of the required tasks.

Ask Your Isuzu Distributor For Help

Our professional service technicians have the expertise and skills to help you with any maintenance or service related procedures you need help with.

Required EPA/ARB Maintenance USA Only

To maintain optimum engine performance and compliance with the Environmental Protection Agency (EPA) Regulations Non-Road Engines and the California Air Resources Board (ARB, California), it is essential that you follow the *Periodic Maintenance Schedule on page 64* and *Periodic Maintenance Procedures on page 66*.

PERIODIC MAINTENANCE

EPA/ARB Installation Requirements USA Only

The following are the installation requirements for the EPA/ARB. Unless these requirements are met, the exhaust gas emissions will not be within the limits specified by the EPA and ARB.

Therefore, periodically perform the maintenance and cleaning of air cleaner and muffler.

Maximum Exhaust Gas Restriction shall be:



- 3CH1, 3CJ1: 1.71 PSI (11.8 kPa; 1200 mm Aq) or less



- 3CE1: 2.22 PSI (15.3 kPa, 1560 mm Aq) or less

Maximum air intake restriction shall be 0.90 PSI (6.23 kPa; 635 mmAq) or less. Clean or replace the air cleaner element if the air intake restriction exceeds the above mentioned value.

Note: EGR-equipped engines have a range of allowable intake and exhaust restrictions; a minimum and a maximum value.

Tightening Fasteners

Use the correct amount of torque when you tighten fasteners on the machine. Applying excessive torque may damage the fastener or component and not enough torque may cause a leak or component failure.

NOTICE

The tightening torque in the *Standard Torque Chart in the Periodic Maintenance Section of this manual* should be applied only to the bolts with a “7” head. (JIS strength classification: 7T)

- Apply 60 % torque to bolts that are not listed.
- Apply 80 % torque when tightened to aluminum alloy.



STANDARD TORQUE CHART

Thread Size x Pitch mm		M6 x 1.0	M8 x 1.25	M10 x 1.5	M12 x 1.75	M14 x 1.5	M16 x 1.5
Tightening torque	in.-lb	96.0 ± 9.0	–	–	–	–	–
	ft-lb	–	19.0 ± 2.0	36.0 ± 4.0	65.0 ± 7.0	101.0 ± 7.0	167.0 ± 7.0
	N·m	10.8 ± 1.0	25.5 ± 2.9	49.0 ± 4.9	88.3 ± 9.8	137.0 ± 9.8	226.0 ± 9.8
	kgf/m	1.1 ± 0.1	2.6 ± 0.3	5.0 ± 0.5	9.0 ± 1.0	14.0 ± 1.5	23.0 ± 2.0

Note: Torque values shown in this manual are for clean, non-lubricated fasteners unless otherwise specified.

PERIODIC MAINTENANCE

PERIODIC MAINTENANCE SCHEDULE

Daily and periodic maintenance is important to keep the engine in good operating condition. The following is a summary of maintenance items by periodic maintenance intervals. Periodic maintenance intervals vary depending on engine application, loads, diesel fuel and engine oil used and are hard to establish definitively. The following should be treated only as a general guideline.

NOTICE

Establish a periodic maintenance plan according to the engine application and make sure you perform the required periodic maintenance at intervals indicated. Failure to follow these guidelines will impair the engine's safety and performance characteristics, shorten the engine's life and may affect the warranty coverage on your engine.

Consult your Isuzu Distributor for assistance when checking items marked with a ●.

Periodic Maintenance Chart

○: Check ◇: Replace ●: Contact your Isuzu Distributor

System	Check item	Daily	Periodic maintenance interval						
			Every 50 hours	Every 250 hours	Every 500 hours	Every 1000 hours	Every 1500 hours	Every 2000 hours	Every 3000 hours
Cooling system	Check and refill engine coolant	○							
	Check and clean radiator fins			○					
	Check and adjust cooling fan V-belt		○ 1st time	○ 2nd and after					
	Change coolant					◇ or every 1 year which-ever comes first			
Cylinder head	Check and adjust intake/exhaust valve clearance					●			
Electrical equipment	Check indicators	○							
	Check battery and recharge		○						
Engine oil	Check engine oil level	○							
	Drain and fill engine oil			◇ 1st time	◇ 2nd and after				
	Replace engine oil filter								

PERIODIC MAINTENANCE

○: Check ◇: Replace ●: Contact your Isuzu Distributor

System	Check item	Daily	Periodic maintenance interval						
			Every 50 hours	Every 250 hours	Every 500 hours	Every 1000 hours	Every 1500 hours	Every 2000 hours	Every 3000 hours
Engine speed control	Check and adjust governor lever and engine speed control	○		○					
Emission control warranty	Inspect, clean and test fuel injection nozzle, if necessary						●		
	 Inspect, clean and test EGR valve								●
	Inspect crankcase breather system						●		
Fuel	Check and refill fuel tank level	○							
	Drain fuel tank			○					
	Drain water separator		○						
	Check water separator	○							
	Clean water separator				○				
	Replace fuel filter				◇				
Hoses	Check and replace fuel hoses and engine coolant hoses							◇ or every 2 years.	
Intake and exhaust	Clean or replace air cleaner element			○	◇				
Complete engine	Overall visual check daily	○							

Note: These procedures are considered normal maintenance and are performed at the owner's expense.

PERIODIC MAINTENANCE

PERIODIC MAINTENANCE PROCEDURES

After Initial 50 Hours of Operation

Perform the following maintenance after the initial 50 hours of operation.

- **Replace engine oil and engine oil filter**
- **Check and adjust cooling fan V-belt**
- **Replace engine oil and engine oil filter**

⚠ WARNING

Burn Hazard!



- **If you must drain the engine oil while it is still hot, stay clear of the hot engine oil to avoid being burned.**

- **Always wear eye protection.**
- **Failure to comply could result in death or serious injury.**

⚠ WARNING

Sudden Movement Hazard!

- **Engaging the transmission or PTO at an elevated engine speed could result in unexpected movement of the equipment.**
- **Failure to comply could result in death or serious injury.**

NOTICE

- Only use the engine oil specified. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine oil. Carefully clean the oil cap/dipstick and the surrounding area before you remove the cap.
- Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.

NOTICE



- Always be environmentally responsible.
- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

PERIODIC MAINTENANCE

The engine oil on a new engine becomes contaminated from the initial break-in of internal parts. It is very important that the initial oil change is performed as scheduled.

Note: The oil drain plug may be in another location if an optional oil pan is used.

Drain the engine oil as follows:

1. Make sure the engine is level.
2. Start the engine and bring it up to operating temperature.
3. Stop the engine.
4. Remove one of the oil filler caps (**Figure 1, (1)**) to vent the engine crankcase and allow the engine oil to drain more easily.
5. Position a container under the engine to collect waste oil.






Figure 1

PERIODIC MAINTENANCE

6. Remove the oil drain plug (**Figure 2, (1)**) from the engine oil pan. Allow oil to drain.
7. After all oil has been drained from the engine, reinstall the oil drain plug (**Figure 2, (1)**) and tighten to 40 - 47 ft-lb (53.9 - 63.7 N-m, 5.5 - 6.5 kgf/m).
8. Dispose of used oil properly.

■ Replace the engine oil filter

⚠ CAUTION

To refuel the engine oil, refuel slowly after removing the dipstick and both caps. If you refuel rapidly, the oil intrusion to the intake occurs through the PCV valve of the valve cover. It will result in an oil hammer at engine start, which may cause damage to the engine.

1. Turn the engine oil filter (**Figure 2, (2)**) counterclockwise (**Figure 2, (3)**) using an oil filter wrench.
2. Clean the engine oil filter mounting face.
3. Lightly coat the gasket on the new oil filter with engine oil. Install the new engine oil filter manually by turning it clockwise (**Figure 2, (4)**) until it contacts the mounting surface. Tighten to 14 - 17 ft-lb (19.6 - 23.5 N-m, 2.0 - 2.4 kgf/m) or one additional turn using the oil filter wrench.

 Engine oil filter part No.	
Engine model	Part No.
3CH1, 3CJ1	5-8640-0632-0 (68x65L)

 Engine oil filter part No.		
Engine model	Part No.	
	Standard	Dust proof*
3CE1	5-8640-1515-0 (80x80L)	5-8640-1495-0 (80x100L)

* Consult the operation manual for the driven machine for applicability of the dust proof filter.

4. Add new engine oil to the engine through either of the oil filler ports as specified in *Adding Engine Oil* on page 44.

NOTICE

- Never overfill the engine with engine oil.
- Always keep the oil level between the upper and lower lines on the oil cap/dipstick.





Figure 2

5. Warm up the engine by running it for 5 minutes and check for any engine oil leaks.
6. After engine is warm, shut it off and let it sit for 10 minutes.
7. Recheck the engine oil level.
8. Add engine oil to engine oil filler port (**Figure 3, (5)**) as needed until the level is between the upper (**Figure 3, (2)**) and lower lines (**Figure 3, (3)**) shown on the dipstick (**Figure 3, (1)**).

PERIODIC MAINTENANCE

- Reinstall the oil filler cap (**Figure 3, (4)**). If any engine oil is spilled, wipe it away with a clean cloth.





Figure 3

■ Check and adjust cooling fan V-belt

The V-belt will slip if it does not have the proper tension. This will prevent the alternator from generating sufficient power. Also, the engine will overheat due to the engine coolant pump pulley slipping.

Check and adjust the V-belt tension (deflection) as follows:

- Press the V-belt down with your thumb with a force of approximately 22 ft-lb (98 N-m, 10 kgf/m) to check the deflection.

There are three positions to check for V-belt tension (**Figure 4, (A), (B) and (C)**). You can check the tension at whichever position is the most accessible. The proper deflection of a used V-belt at each position is:

Used V-belt tension		
A	B	C
3/8 - 1/2 in. (10 - 14 mm)	1/4 - 3/8 in. (7 - 10 mm)	5/16 - 1/2 in. (9 - 13 mm)

Note: A "Used V-Belt" refers to a V-belt which has been used on a running engine for five minutes or more.

PERIODIC MAINTENANCE





Figure 4

2. If necessary, adjust the V-belt tension. Loosen the adjusting bolt (**Figure 5, (1)**) and related bolts and/or nuts, then move the alternator (**Figure 5, (2)**) with a pry bar (**Figure 5, (3)**) to tighten the V-belt to the desired tension. Then tighten the adjusting bolts and/or nuts.





Figure 5

3. Tighten the V-belt to the proper tension. There must be clearance (**Figure 6, (1)**) between the V-belt and the bottom of the pulley groove. If there is no clearance (**Figure 6, (2)**) between the V-belt and the bottom of the pulley groove, replace the V-belt.

PERIODIC MAINTENANCE




Figure 6

4. Check the V-belt for cracks, oil or wear. If any of these conditions exist, replace the V-belt.
5. Install the new V-belt. Refer to the table for proper tension.

New V-belt tension		
A	B	C
5/16 - 7/16 in. (8 - 12 mm)	3/16 - 5/16 in. (5 - 8 mm)	1/4 - 7/16 in. (7 - 11 mm)

6. After adjusting, run the engine for 5 minutes or more. Check the tension again using the specifications for a used V-belt.

Used V-belt tension		
A	B	C
3/8 - 1/2 in. (10 - 14 mm)	1/4 - 3/8 in. (7 - 10 mm)	5/16 - 1/2 in. (9 - 13 mm)

Every 50 Hours of Operation

After you complete the initial 50 hour maintenance procedures, perform the following procedures every 50 hours thereafter.

- Drain water separator
- Check battery

■ Drain water separator

⚠ DANGER

Fire and Explosion Hazard!



- Diesel fuel is flammable and explosive under certain conditions.

- When you remove any fuel system component to perform maintenance (such as changing the fuel filter) place an approved container under the opening to catch the fuel.
- Never use a shop rag to catch the fuel. Vapors from the rag are flammable and explosive.
- Wipe up any spills immediately.
- Wear eye protection. The fuel system is under pressure and fuel could spray out when you remove any fuel system component.
- Failure to comply will result in death or serious injury.

NOTICE



If no water drips when the water separator drain valve is opened, loosen the air vent screw on the top of the water separator by using a screwdriver to turn it counterclockwise 2 - 3 turns.

This may occur if the water separator is positioned higher than the fuel level in the fuel tank. After draining the water separator, be sure to tighten the air vent screw.

PERIODIC MAINTENANCE

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

Drain the water separator whenever there are contaminants, such as water, collected in the bottom of the cup. Never wait until the scheduled periodic maintenance if contaminants are discovered.

The separator cup is made from semi-transparent material. In the cup is a red-colored float ring. The float ring will rise to the surface of the water to show how much needs to be drained. Also, some optional water separators are equipped with a sensor to detect the amount of contaminants. This sensor sends a signal to an indicator to alert the operator.



Drain the water separator as follows:




Figure 7


1. Position an approved container under the water separator (**Figure 7, (1)**) to collect the contaminants.
2. Close (**Figure 7, (2)**) the fuel valve (**Figure 7, (3)**).
3. Turn the retaining ring (**Figure 7, (4)**) to the left (**Figure 7, (9)**).
4. Carefully remove the cup (**Figure 7, (1)**). Remove the retaining spring (**Figure 7, (6)**) and float (**Figure 7, (7)**) from the cup. Pour the fuel into an approved container and dispose of waste properly. Hold the bottom of the cup with a shop towel to prevent the fuel from dripping. Wipe up any spills immediately.
5. Clean the inside of the cup.
6. Inspect the condition of the mesh filter (**Figure 7, (10)**). Clean the mesh filter if necessary.
7. Inspect the condition of the O-ring (**Figure 7, (11)**). Replace the O-ring if necessary.
8. Put the float (**Figure 7, (7)**) and retaining spring (**Figure 7, (6)**) inside the cup.

PERIODIC MAINTENANCE

9. Reinstall the cup to the mounting flange (**Figure 7, (8)**) and turn the retaining ring (**Figure 7, (4)**) to the right (**Figure 7, (5)**). hand-tighten only.
10. Open the fuel valve (**Figure 7, (3)**).
11. Be sure to prime the diesel fuel system when you are done. See *Priming the Fuel System on page 42*.
12. Check for fuel leaks.



Drain the water separator as follows:



045099-01X01

Figure 8

1. Position an approved container under the water separator (**Figure 8, (1)**) to collect water and contaminants drained from the water separator.
2. Close (**Figure 8, (2)**) the fuel valve (**Figure 8, (3)**).
3. Open the drain valve (**Figure 8, (4)**) at the bottom of the water separator. Drain any water collected inside. If no water comes out, loosen the air vent screw (**Figure 8, (5)**) at the top of the water separator by turning it counterclockwise 2 - 3 turns.
4. If still no water comes out, open the fuel valve (**Figure 8, (3)**).
5. After draining the water separator, hand-tighten the drain valve.

Tightening torque	1 - 2 N·m (0.1 - 0.2 kgf·m)
-------------------	--------------------------------

6. Be sure to tighten the air vent screw if it is loosened.
7. Open the fuel valve.
8. Be sure to prime the diesel fuel system. See *Priming the Fuel System on page 42*.
9. Check for fuel leaks.

■ Check battery and recharge

⚠ DANGER

Explosion Hazard!



- Never short out the battery terminals, including when checking the remaining battery charge. This will result in a spark and may cause an explosion or fire. Use a hydrometer to check the remaining battery charge.

- If the electrolyte is frozen, slowly warm the battery before you recharge it.
- Failure to comply will result in death or serious injury.

⚠ WARNING

Burn Hazard!



- Batteries contain sulfuric acid. Never allow battery fluid to come in contact with clothing, skin or eyes. Severe burns could result. Always wear safety goggles and protective clothing when servicing the battery. If battery fluid contacts the eyes and/or skin, immediately flush the affected area with a large amount of clean water and obtain prompt medical treatment.

- Failure to comply could result in death or serious injury.

PERIODIC MAINTENANCE

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.




Figure 9

- When the amount of fluid nears the lower limit (**Figure 9, (3)**), fill with distilled water (**Figure 9, (2)**) so it is at the upper limit (**Figure 9, (1)**). If operation continues with insufficient battery fluid, the battery life is shortened, and the battery may overheat and explode. During the summer, check the fluid level more often than specified.

- If the engine cranking speed is so slow that the engine does not start, recharge the battery. Use a specialized battery charger to recharge the battery with a voltage of 8 volts or less. Charging the battery by booster even with a voltage of 8 bolts or less will generate an abnormally high voltage and destroy electrical equipment. Further, in the electronic control engine, when unavoidably using a rapid charger to recharge, do not insert and turn the starter key to ON position while the battery is being charged. Avoid using a charger equipped with a boost function (cell start support) to start the engine. The ECU may be damaged by applied excessive voltage.
- If the engine still will not start after charging, have your Isuzu Distributor check the battery and the engine's starting system.
- If operating the machine where the ambient temperature could drop to $-15\text{ }^{\circ}\text{C}$ ($5\text{ }^{\circ}\text{F}$) or less, remove the battery from the machine at the end of the day. Store the battery in a warm place until the next use. This will help start the engine easily at low ambient temperatures.

PERIODIC MAINTENANCE

Every 250 Hours of Operation

Perform the following maintenance every 250 hours of operation.

- Drain fuel tank
- Replace engine oil and engine oil filter
- Check and clean radiator fins
- Check and adjust cooling fan V-belt
- Check and adjust the governor lever and engine speed control
- Clean air cleaner element

■ Drain fuel tank

⚠ DANGER

Fire and Explosion Hazard!



- Diesel fuel is flammable and explosive under certain conditions.

- When you remove any fuel system component to perform maintenance (such as changing the fuel filter) place an approved container under the opening to catch the fuel.
- Never use a shop rag to catch the fuel. Vapors from the rag are flammable and explosive.
- Wipe up any spills immediately.
- Wear eye protection. The fuel system is under pressure and fuel could spray out when you remove any fuel system component.
- Failure to comply will result in death or serious injury.

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

Note that a typical fuel tank is illustrated.

1. Position an approved container under the diesel fuel tank (**Figure 10, (1)**) to collect the contaminants.




Figure 10

2. Remove the fuel cap (**Figure 10, (3)**).
3. Remove the drain plug (**Figure 10, (2)**) to drain the contaminants (water, dirt, etc.) from the bottom of the tank.
4. Drain the tank until clean diesel fuel with no water or dirt flows out. Reinstall and tighten the drain plug firmly.
5. Reinstall the fuel cap.
6. Check for leaks.

PERIODIC MAINTENANCE

■ Replace engine oil and engine oil filter

NOTICE

- Only use the engine oil specified. Other engine oils may affect warranty coverage, cause internal engine components to seize and/or shorten engine life.
- Prevent dirt and debris from contaminating the engine oil. Carefully clean the oil cap/dipstick and the surrounding area before you remove the cap.
- Never mix different types of engine oil. This may adversely affect the lubricating properties of the engine oil.
- Never overfill. Overfilling may result in white exhaust smoke, engine overspeed or internal damage.

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

Change the engine oil every 250 hours of operation after the initial change at 50 hours. Replace the engine oil filter at the same time.

See *Replace engine oil and engine oil filter* on page 66.

■ Check and clean radiator fins

CAUTION



Flying Object Hazard!

- Always wear eye protection when servicing the engine and when using compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.
- Failure to comply may result in minor or moderate injury.

Dirt and dust adhering to the radiator fins reduce the cooling performance, causing overheating. Make it a rule to check the radiator fins daily and clean as needed.

Note that a typical radiator is shown in **Figure 11** for illustrative purposes only.

- Blow off dirt and dust from fins and radiator with 28 PSI (0.19 MPa, 2 kgf/cm²) or less of compressed air (**Figure 11, (1)**). Be careful not to damage the fins with the compressed air.




Figure 11

- If there is a large amount of contamination on the fins, apply detergent, thoroughly clean and rinse with tap water.

PERIODIC MAINTENANCE

NOTICE

Never use high-pressure water or compressed air at greater than 28 PSI (193 kPa; 19686 mmAq) or a wire brush to clean the radiator fins. Radiator fins damage easily.

■ Check and adjust cooling fan V-belt

Check and adjust the cooling fan V-belt every 250 hours of operation after the initial 50 hour V-belt maintenance. See *Check and adjust cooling fan V-belt on page 69.*

■ Check and adjust the governor lever and engine speed control (except electronically controlled engines)

The governor lever and engine speed control (throttle lever, accelerator pedal etc.), are connected together by a cable or linkage. If the cable becomes stretched, or the linkage wears or loosens, the governor lever may not respond to a change in the position of the engine speed control.

NOTICE

Never attempt to adjust the low or high idle speed limit screw. This may impair the safety and performance of the machine and shorten its life. If the idle speed limit screws require adjustment, see your Isuzu Distributor.

1. Check that the governor lever (**Figure 12, (1)**) makes firm contact with the high idle stop (**Figure 12, (2)**) and the low idle speed limit screw (**Figure 12, (3)**) when the engine speed control is in the full speed or low idle speed positions.
2. If the governor lever does not make proper contact with the high idle stop or the low idle speed limit screw, adjust the throttle cable or linkage as necessary.

Note: Do not force the throttle cable or linkage to move. This may damage the the governor lever, the throttle cable or linkage and cause irregular operation of the engine speed control.

NOTICE

The engine speed control (throttle lever, accelerator pedal etc.), should be equipped with stops to prevent the application of excessive pressure by the governor lever to either the high idle stop or low idle speed limit screw.

See your Isuzu Distributor for the adjustment procedures for your specific engine or machine.





Figure 12

PERIODIC MAINTENANCE

■ Clean air cleaner element

⚠ CAUTION

Flying Object Hazard!



- Always wear eye protection when servicing the engine and when using compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.

- Failure to comply may result in minor or moderate injury.

Note that a typical air cleaner is shown in **Figure 13** and **Figure 14** for illustrative purposes only.




Figure 13




Figure 14

The engine performance is adversely affected when the air cleaner element is clogged with dust. Be sure to clean the air filter element periodically.

1. Unlatch and remove the air cleaner cover (**Figure 13, (1)**).
2. Remove the element (**Figure 13, (2)**) (outer element if equipped with two elements).
3. Blow air (**Figure 13, (3)**) through the element from the inside out using 42 - 71 PSI (0.29 - 0.49 MPa, 3.0 - 5.0 kgf/cm²) compressed air to remove the particulates. Use the lowest possible air pressure to remove the dust without damaging the element.
4. If the air cleaner is equipped with a double element, only remove and replace the inner element (**Figure 14, (1)**) if the engine lacks power or the dust indicator actuates (if equipped).

Note: The inner element should not be removed when cleaning or replacing the outer element. The inner element is used to prevent dust from entering the engine while servicing the outer element.

5. Replace the element with a new one if the element is damaged, excessively dirty or oily.
6. Clean inside of the air cleaner cover.
7. Reinstall the element into the air cleaner case (**Figure 13, (4)**).

*Note: If there is a red line (**Figure 14, (2)**) in the outer element, reinsert the element until the overlap position of red line and end face of the air cleaner case.*

8. Reinstall the air cleaner cover making sure you match the arrow (**Figure 13, (5)**) on the cover with the arrow on the case (**Figure 13, (6)**).
9. Latch the air cleaner cover to the case.

NOTICE

- When the engine is operated in dusty conditions, clean the air cleaner element more frequently.
- Never operate the engine with the air cleaner element(s) removed. This may allow foreign material to enter the engine and damage it.

PERIODIC MAINTENANCE

Every 500 Hours of Operation

Perform the following maintenance every 500 hours of operation.

- Replace air cleaner element
- Replace fuel filter (element)
- Clean water separator

■ Replace air cleaner element

NOTICE

The maximum air intake restriction, in terms of differential pressure measurement, must not exceed 0.90 PSI (6.23 kPa; 635 mmAq). Clean or replace the air cleaner element if the air intake restriction exceeds the above mentioned value.

Replace the air cleaner element (**Figure 13, (2)**) every 500 hours even if it is not damaged or dirty.

When replacing the element, clean the inside of the air cleaner case (**Figure 13, (4)**).

If the air cleaner is equipped with a double element, *only remove and replace the inner element (Figure 14, (1)) if the engine lacks power or the dust indicator actuates (if equipped)*. This is in addition to replacing the outer element.

■ Replace fuel filter (element)

! DANGER**Fire and Explosion Hazard!**

- Diesel fuel is flammable and explosive under certain conditions.

- When you remove any fuel system component to perform maintenance (such as changing the fuel filter) place an approved container under the opening to catch the fuel.
- Never use a shop rag to catch the fuel. Vapors from the rag are flammable and explosive.
- Wipe up any spills immediately.
- Wear eye protection. The fuel system is under pressure and fuel could spray out when you remove any fuel system component.
- Failure to comply will result in death or serious injury.

NOTICE

For maximum engine life, Isuzu recommends that when shutting the engine down, you allow the engine to idle, without load, for five minutes. This will allow the engine components that operate at high temperatures, such as the turbocharger (if equipped) and exhaust system, to cool slightly before the engine itself is shut down.

NOTICE

- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

PERIODIC MAINTENANCE



Replace the fuel filter element at specified intervals to prevent contaminants from adversely affecting the diesel fuel flow.

1. Stop the engine and allow it to cool.
2. Close the fuel valve of the water separator.
3. Turn the retaining ring (**Figure 15, (1)**) to the left (**Figure 15, (5)**).




Figure 15

4. Carefully remove the cup (**Figure 15, (3)**). Pour the fuel into an approved container and dispose of waste properly. Hold the bottom of the cup with a shop towel to prevent the fuel from dripping. Wipe up any spills immediately.
5. Remove the fuel filter element (**Figure 15, (4)**) by pulling it down.
6. Replace the fuel filter element with a new one.

Applicable fuel filter element part No.		
Engine model	Part No.	
	Standard	Dust proof*
3CH1, 3CJ1	5-8640-0778-0	5-8640-1510-0

* This is a fuel filter for DI, and should be installed with a different filter bracket. Consult the operation manual for the driven machine for applicability of the dust proof filter.

7. Wash the inside of the cup.
8. Check the condition of the O-ring (**Figure 15, (6)**). Replace if necessary.
9. Install the cup to the mounting flange and turn the retaining ring (**Figure 15, (1)**) to the right (**Figure 15, (2)**). Hand-tighten only.
10. Open the fuel valve of the water separator.
11. Prime the fuel system. See *Priming the Fuel System on page 42*.
12. Check for fuel leaks.



Replace the fuel filter at specified intervals to prevent contaminants from adversely affecting the diesel fuel flow.

1. Stop the engine and allow it to cool.
2. Close the fuel valve of the water separator.
3. Remove the fuel filter using a filter wrench to turn it to the left (**Figure 16, (1)**). When removing the fuel filter, carefully hold it to prevent the fuel from spilling. Wipe up all spilled fuel.




Figure 16

4. Clean the filter mounting surface and apply a small amount of diesel fuel to the gasket of the new fuel filter.
5. Install the new fuel filter. Hand-tighten it to the right (**Figure 16, (2)**) until it comes in contact with the mounting surface. Use a filter wrench and tighten to 14 - 17 ft-lb (19.6 - 23.5 N-m, 2.0 - 2.4 kgf/m) or one additional turn using the filter wrench.

Applicable fuel filter part No.		
Engine model	Part No.	
	Standard	Dust proof*
3CE1	5-8640-1510-0	5-8640-1496-0

* Consult the operation manual for the driven machine for applicability of the dust proof filter.

6. Open the fuel valve of the water separator.
7. Prime the fuel system. See *Priming the Fuel System on page 42*.
8. Check for fuel leaks.

PERIODIC MAINTENANCE

■ **Clean water separator**

⚠ DANGER

Fire and Explosion Hazard!



- Diesel fuel is flammable and explosive under certain conditions.

- Never use diesel fuel as a cleaning agent.
- When you remove any fuel system component to perform maintenance (such as changing the fuel filter) place an approved container under the opening to catch the fuel.
- Never use a shop rag to catch the fuel. Vapors from the rag are flammable and explosive.
- Wipe up any spills immediately.
- Wear eye protection. The fuel system is under pressure and fuel could spray out when you remove any fuel system component.
- Failure to comply will result in death or serious injury.

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.



Periodically clean the water separator element and inside cup.

1. Position an approved container under the cup (**Figure 17, (1)**) of the water separator to collect the contaminants.




Figure 17

2. Close (**Figure 17, (2)**) the fuel valve (**Figure 17, (3)**).
 3. Turn the retaining ring (**Figure 17, (4)**) to the left (**Figure 17, (9)**).
 4. Carefully remove the cup (**Figure 17, (1)**). Remove the retaining spring (**Figure 17, (6)**) and float (**Figure 17, (7)**) from the cup. Pour the fuel into an approved container and dispose of waste properly. Hold the bottom of the cup with a shop towel to prevent the fuel from dripping. Wipe up any spills immediately.
 5. Remove the element by pulling it down (**Figure 17, (10)**).
 6. Wash the inside of the element and cup with new fuel. If the element is damaged or broken, replace with a new one.
- | Applicable mesh filter part No. | |
|---------------------------------|---------------|
| Engine model | Part No. |
| 3CH1, 3CJ1 | 5-8640-0832-0 |
7. Attach the element to the main body.
 8. Inspect condition of the O-ring (**Figure 17, (11)**). Replace if necessary.

PERIODIC MAINTENANCE

9. Put the float (**Figure 17, (7)**) and retaining spring (**Figure 17, (6)**) inside the cup.
10. Install the cup to the mounting flange (**Figure 17, (8)**) and turn the retaining ring (**Figure 17, (4)**) to the right (**Figure 17, (5)**). Hand-tighten only.
11. Open the fuel valve (**Figure 17, (3)**).
12. Prime the fuel system. See *Priming the Fuel System on page 42*.
13. Check for fuel leaks.



Periodically clean the water separator element and inside the cup.

1. Position an approved container under the cup (**Figure 18, (1)**) of the water separator to collect the contaminants.
2. Close (**Figure 18, (2)**) the fuel valve (**Figure 18, (3)**).
3. Loosen the drain valve (**Figure 18, (4)**) and drain the contaminants. See *Drain water separator on page 71*.
4. Turn the cup (**Figure 18, (1)**) to the left (**Figure 18, (10)**) and remove the cup (**Figure 18, (1)**). If equipped, disconnect the sensor wire from the cup before removing the cup.
5. Carefully hold the cup to prevent fuel from spilling. If you spill any fuel, clean up the spill completely.

7. Clean the element (**Figure 18, (9)**) and inside cup. Replace the element if it is damaged.

Applicable element part No.	
Engine model	Part No.
3CE1	5-8640-2106-0

8. Install the element into the top of body.
9. Position the float ring in the cup.
10. Check the condition of the O-ring. Replace if necessary.
11. Install the cup to the body by tightening the cup to the right (**Figure 18, (6)**) to 18 - 22 N·m (1.8 - 2.2 kfg·m).
12. Close the drain valve. Reconnect the sensor wire if equipped.
13. Open the fuel valve (**Figure 18, (3)**).
14. Prime the fuel system. See *Priming the Fuel System on page 42*.
15. Check for leaks.




Figure 18

6. Remove the float ring (**Figure 18, (8)**) from the cup. Pour the contaminants into the container and dispose of it properly.

PERIODIC MAINTENANCE

Every 1000 Hours of Operation

Perform the following maintenance every 1000 hours of operation.

- **Change coolant**
- **Check and adjust intake/exhaust valve clearance**

⚠ DANGER



Scald Hazard!

- **Never remove the radiator cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the radiator cap.**
- **Tighten the radiator cap securely after you check the radiator. Steam can spurt out during engine operation if the cap is loose.**
- **Always check the level of the engine coolant by observing the reserve tank.**
- **Failure to comply will result in death or serious injury.**

⚠ WARNING



Burn Hazard!

- **Wait until the engine cools before you drain the engine coolant. Hot engine coolant may splash and burn you.**
- **Failure to comply could result in death or serious injury.**

⚠ CAUTION

Coolant Hazard!



- **Wear eye protection and rubber gloves when you handle long life or extended life engine coolant. If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.**

- **Failure to comply may result in minor or moderate injury.**

NOTICE



- Always be environmentally responsible.

- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

■ Change coolant

Engine coolant contaminated with rust or water scale reduces the cooling effect. Even when extended life engine coolant is properly mixed, the engine coolant gets contaminated as its ingredients deteriorate. Drain, flush and refill the cooling system with new coolant every 1000 hours or once a year, whichever comes first.

PERIODIC MAINTENANCE

1. Allow engine and coolant to cool.
2. Remove the radiator cap (**Figure 19, (1)**).
3. Remove the drain plug or open the drain valve (**Figure 19, (2)**) at the bottom of the radiator and drain the engine coolant.




Figure 19

4. Drain the coolant from the engine block.
 - On models not equipped with an oil cooler, remove the coolant drain plug (**Figure 20, (1)**) from the engine block.




Figure 20

5. After draining the engine coolant, flush the radiator and engine block to remove any rust, scale and contaminants. Then reinstall and tighten the drain plug or close the drain valve in the radiator. Reinstall and tighten the engine block drain plug.
6. Fill radiator and engine with engine coolant. See *Filling Radiator with Engine Coolant* on page 47.

■ Check and adjust intake/exhaust valve clearance

Improper intake/exhaust valve clearance will cause the engine to run noisily, resulting in poor engine performance and engine damage. Proper adjustment is necessary to maintain the correct timing for opening and closing the valves. See your Isuzu Distributor to inspect and adjust the intake/exhaust valve clearance.

PERIODIC MAINTENANCE

Every 1500 Hours of Operation

Perform the following maintenance every 1500 hours of operation.

- **Inspect, clean and test fuel injection nozzle, if necessary**
- **Inspect crankcase breather system**
- **Inspect, clean and test fuel injection nozzle**

WARNING

High-Pressure Hazard!



- **Avoid skin contact with the high-pressure diesel fuel spray caused by a fuel system leak such as a broken fuel injection line. High-pressure fuel can penetrate your skin and result in serious injury. If you are exposed to high-pressure fuel spray, obtain prompt medical treatment.**
- **Never check for a fuel leak with your hands. Always use a piece of wood or cardboard. Have your Isuzu Distributor repair the damage.**
- **Failure to comply could result in death or serious injury.**

Proper operation of the fuel injectors is required to obtain the optimum injection pattern for full engine performance. The EPA/ARB requires that you have the injectors inspected, cleaned and tested every 1500 hours. See your Isuzu Distributor for this service.

This procedure is considered normal maintenance and is performed at the owner's expense. This procedure is not covered by the Isuzu Motors Limited Warranty.

■ **Inspect crankcase breather system**

Proper operation of the crankcase breather system is required to maintain the emission requirements of the engine. The EPA/ARB requires that you have the crankcase breather system inspected every 1500 hours. See your Isuzu Distributor for this service.

PERIODIC MAINTENANCE

Every 2000 Hours of Operation

Perform the following maintenance every 2000 hours of operation.

- Check and replace fuel hoses and engine coolant hoses
- Check and replace fuel hoses and engine coolant hoses

⚠ DANGER



Scald Hazard!

- Never remove the radiator cap if the engine is hot. Steam and hot engine coolant will spurt out and seriously burn you. Allow the engine to cool down before you attempt to remove the radiator cap.
- Tighten the radiator cap securely after you check the radiator. Steam can spurt out during engine operation if the cap is loose.
- Always check the level of the engine coolant by observing the reserve tank.
- Failure to comply will result in death or serious injury.

⚠ WARNING




Burn Hazard!

- If you must drain the engine oil while it is still hot, stay clear of the hot engine oil to avoid being burned.
- Always wear eye protection.
- Failure to comply could result in death or serious injury.

⚠ CAUTION

Coolant Hazard!



- Wear eye protection and rubber gloves when you handle long life or extended life engine coolant. If contact with the eyes or skin should occur, flush eyes and wash immediately with clean water.

- Failure to comply may result in minor or moderate injury.

NOTICE



- Always be environmentally responsible.
- Follow the guidelines of the EPA or other governmental agencies for the proper disposal of hazardous materials such as engine oil, diesel fuel and engine coolant. Consult the local authorities or reclamation facility.
- Never dispose of hazardous materials irresponsibly by dumping them into a sewer, on the ground, or into ground water or waterways.
- Failure to follow these procedures may seriously harm the environment.

■ Check and replace fuel hoses and engine coolant hoses

Regularly check the fuel system and engine coolant system hoses. If they are cracked or degraded, replace them. Replace the hoses at least every two years. See your Isuzu Distributor to replace fuel hoses and engine coolant system hoses.

Every 3000 Hours of Operation

Perform the following maintenance every 3000 hours of operation.

- **Inspect, clean and test EGR valve**

3CE1


- **Inspect, clean and test EGR valve**

3CE1

The EGR valve is a key component for cleaning exhaust gas.

To prevent the valve from deteriorating in exhaust gas recirculation performance due to carbon accumulation, inspect, clean and test the valve at least every 3000 hours.

Consult your Isuzu Distributor for this service.



045050-00X00

Figure 21

PERIODIC MAINTENANCE

This Page Intentionally Left Blank

TROUBLESHOOTING

If a problem occurs, stop the engine immediately.
Refer to the SYMPTOM column in the
Troubleshooting Chart to identify the problem.

NOTICE

If any indicator fails to illuminate when the key
switch is in the ON position, see your Isuzu
Distributor for service before operating the engine.

If any indicator illuminates during engine operation,
stop the engine immediately. Determine the cause
and repair the problem before you continue to
operate the engine.

TROUBLESHOOTING

TROUBLESHOOTING CHART

Symptom	Probable cause	Action	Refer to
Indicator turns ON - engine running			
Engine oil pressure indicator	Low level of engine oil	Check and adjust oil level as necessary	<i>Checking Engine Oil on page 44</i>
	Too high an oil level		
	Clogged engine oil filter	Replace engine oil filter	<i>Replace engine oil and engine oil filter on page 66</i>
Engine coolant indicator	Low engine coolant level	Add engine coolant	<i>Filling Radiator with Engine Coolant on page 47</i>
	Dirty radiator fins	Clean the radiator fins	<i>Check and clean radiator fins on page 76</i>
	Engine coolant leaking	See Isuzu Distributor	–
	V-belt loose or damaged	Adjust V-belt or replace	<i>Check and adjust cooling fan V-belt on page 69</i>
	Contaminated engine coolant	See Isuzu Distributor	–
	Faulty engine coolant pump		–
Battery Indicator	V-belt loose or damaged	Adjust V-belt or replace	<i>Check and adjust cooling fan V-belt on page 69</i>
	Battery failure	Check battery condition	<i>Check battery and recharge on page 73</i>
	Faulty alternator	See Isuzu Distributor	–
Indicator does not turn ON - key switch is turned to ON (OFF → ON) - engine not running			
	Faulty electrical wiring or faulty indicator	See Isuzu Distributor	–
Indicator stays ON - key switch is turned from start to ON (START → ON) - engine not running			
Battery indicator stays ON	Faulty alternator	See Isuzu Distributor	–
Engine oil pressure indicator stays ON	Faulty engine oil pressure switch		–
	No or low level of engine oil	Check and adjust oil level as necessary	<i>Checking Engine Oil on page 44</i>
	Clogged engine oil filter	Replace engine oil filter	<i>Replace engine oil and engine oil filter on page 66</i>

TROUBLESHOOTING

Symptom	Probable cause	Action	Refer to
Engine does not Start			
Starter motor operates but engine does not start	No diesel fuel	Refuel and prime fuel system	<i>Filling the Fuel Tank on page 41</i>
	Air in fuel system	Prime fuel system	<i>Priming the Fuel System on page 42</i>
	Improper diesel fuel	Replace with recommended diesel fuel	<i>Diesel Fuel Specifications on page 36</i>
	Clogged fuel filter	Replace fuel filter	<i>Replace fuel filter (element) on page 79</i>
	Poor fuel injection	See Isuzu Distributor	–
	Compressed air leakage from intake/exhaust valves		–
	Faulty engine stop solenoid		–
Starter motor does not operate or rotates too slowly (engine can be turned manually)	Battery needs charging	Check electrolyte, recharge	<i>Check battery and recharge on page 73</i>
	Faulty cable connection at battery terminals	Clean terminals, retighten	–
	Faulty starter switch	See Isuzu Distributor	–
	Faulty starter motor		–
Engine cannot be manually turned	Inner parts seized or damaged		–
White or black exhaust smoke			
Black exhaust smoke	Engine overloaded	Reduce load	–
	Clogged air cleaner element	Clean element or replace	<i>Clean air cleaner element on page 78</i>
	Improper diesel fuel	Replace with recommended diesel fuel	<i>Diesel Fuel Specifications on page 36</i>
	Faulty spraying of fuel injection	See Isuzu Distributor	–
	Excessive intake/exhaust valve clearance		–
	Faulty EGR valve		–
White exhaust smoke	Improper diesel fuel	Replace with recommended diesel fuel	<i>Diesel Fuel Specifications on page 36</i>
	Faulty spray pattern of fuel injection	See Isuzu Distributor	–
	Fuel injection timing delay		–
	Engine burning oil		–

TROUBLESHOOTING

TROUBLESHOOTING OF ELECTRONIC CONTROL SYSTEM



⚠ WARNING

- Never use the E-ECU for other purposes than intended or in other ways than specified by Isuzu. Doing so could result in the violation of emission control regulations and will void the product warranty.
- Replacing the fuel injection pump involves rewriting the fuel injection data in the E-ECU. Be sure to contact your Isuzu Distributor before replacing the fuel injection pump. Failure to rewrite the fuel injection data before replacing the fuel injection pump will void the engine warranty.
- Replacing the E-ECU involves migrating the fuel injection data to the existing E-ECU to the new unit. Be sure to contact your Isuzu Distributor before replacing the E-ECU. Failure to migrate the fuel injection data before replacing the E-ECU will void the engine warranty.
- Improper use or misuse of the E-ECU may result in death or serious injury due to an abrupt and unexpected increase in engine speed.

Fault Detection Capability

The E-ECU has a fault detection capability. See *List of Possible Faults of Electronically Controlled Engines* on page 95.


A fault indicator (Optional) is located on the operator's console as shown in **Figure 1**.

This indicator comes on at power up of the E-ECU and goes out after 2 sec.

Once a fault is detected, then the indicator flashes in certain patterns, providing fault information to the operator.

NOTICE

Shut down the engine if the fault indicator comes on. Continuing running the engine with the fault indicator being on may result in a serious malfunction of or damage to the engine, and will void the engine warranty.



1 – Fault indicator

Figure 1

Figure 1 Typical Operator's Console

TROUBLESHOOTING

Figure 2 exemplifies flashing patterns that represent an accelerator fault (5 flashes) or EGR valve fault (1 to 3 flashes) occurring at power up. If multiple faults occur simultaneously, the indicator indicates all the faults in order of smaller to larger number of flashes.




Figure 2

NOTICE

If the fault indicator comes on, check and note the flashing pattern, shut down the engine without delay and contact your Isuzu Distributor.

TROUBLESHOOTING

TROUBLESHOOTING INFORMATION

If your engine does not operate properly, refer to the troubleshooting chart or consult your Isuzu Distributor.

Supply the Isuzu Distributor with the following information:

- Model name and serial number of your engine
- The driven machine type (tractor, generator, skid steer loader), manufacturer's name, model and serial number
- How long the engine has been in service (the number of engine hours or the number of calendar months)
- Operating conditions when problem occurs:
 - Engine RPM
 - Color of exhaust smoke
 - Type of diesel fuel
 - Type of engine oil
 - Flashing patterns of indicators (When an electronically controlled engine and the fault indicator are used)
 - Any abnormal noises or vibration
 - Operating environment such as high altitude or extreme ambient temperatures, etc.
- Engine maintenance history and previous problems
- Other factors that contribute to the problem

LIST OF POSSIBLE FAULTS OF ELECTRONICALLY CONTROLLED ENGINES



No.	Fault (alarm) location	Fault/alarm condition	Engine status	Reset condition	Availability of detection features	No. of flashes/flashing pattern of fault indicator
1	Coolant temperature sensor	Sensor voltage is over 4.8 V or under 0.2 V	Continues to run at a coolant temperature of 30 °C	Voltage returns to normal	Standard	4
2	Accelerator sensor	Sensor voltage is over 4.8 V or under 0.2 V	Continues to run at 1500 min ⁻¹ (rpm)	Voltage returns to normal	Default	5
3	Speed sensor	Engine start switch (E8) is on, but engine speed is zero	Is shut down. (When optional auxiliary speed sensor is equipped: Auxiliary speed sensor works in place of faulty speed sensor and engine continues to run at up to 1800 min ⁻¹ (rpm). If auxiliary sensor also fails, engine is shut down.	Key switch is turned to OFF	Standard	6
		Engine speed momentarily decreased to lower than specified lower limit				
4	Rack position sensor	Rack position relative to rack actuator is without specified limits.	Continues to run without rack position sensing at up to 150 % of low idling speed or 80 % of high idling speed, whichever is lower	Key switch is turned to OFF	Standard	7
5	Rack actuator	Rack actuator output is without specified limits	Is shut down	Key switch is turned to OFF	Standard	8
		Engine accelerates even though rack actuator output is minimized				
		Engine stalls while rack position sensor fails				
6	EGR valve	LOW status was detected even though port was off	Continues to run at up to 92 % of rated power output and up to 1800 min ⁻¹ (rpm)	Key switch is turned to OFF	Default	1-3
		HIGH status was detected even though port was on				
7	CSD solenoid valve	LOW status was detected even though port was on	Continues to run while CSD feature is canceled	Key switch is turned to OFF	Standard	1-4
		HIGH status was detected even though port was off				
8	Starting aid relay	LOW status was detected even though port was off	Continues to run while starting aid relay is off	Key switch is turned to OFF	Optional	1-5
		HIGH status was detected even though port was on				

TROUBLESHOOTING

No.	Fault (alarm) location	Fault/alarm condition	Engine status	Reset condition	Availability of detection features	No. of flashes/flashing pattern of fault indicator
9	Main relay	Power cannot be turned off even though main relay is off	Continues to run normally	Relay returns to normal. This fault will persist even if key switch is turned to OFF.	Default	1-6
10	Rack actuator relay	LOW status was detected even though port was off	Is shut down	Key switch is turned to OFF	Standard	1-7
		HIGH status was detected even though port was on				
11	Oil pressure switch	Oil pressure switch is not turned on while engine is stopped	Continues to run normally. (Other option can be selected).	Key switch is turned to OFF	Optional	2-1
12	Power supply voltage	An ECU supply voltage of under 10.0 V was detected	Continues to run normally	Voltage returns to normal	Standard	2-3
		An ECU supply voltage of over 16.0 V was detected				
13	ECU temperature (alarm)	ECU temperature is over 105 °C	Continues to run normally. (Other option can be selected).	Temperature returns to normal; under 100 °C (other optional setting is allowed)	Optional	2-5
14	Oil pressure	Oil pressure switch is not turned off while engine is running	Continues to run normally. (Other option can be selected).	Pressure returns to normal	Optional	3-1
15	Battery charge (alarm)	Battery changing switch is not turned off while engine is running	Continues to run normally	Key switch is turned to OFF	Optional	3-2
16	Battery charging switch	Battery changing switch is not turned off while engine is running	Continues to run normally	Key switch is turned to OFF	Optional	2-2
17	Coolant temperature (alarm)	Coolant temperature is over 110 °C	Continues to run normally. (Other option can be selected).	Temperature returns to normal; under 105 °C (other optional setting is allowed)	Standard	3-6

TROUBLESHOOTING

No.	Fault (alarm) location	Fault/alarm condition	Engine status	Reset condition	Availability of detection features	No. of flashes/flashing pattern of fault indicator
18	ECU-ROM	Flash ROM checksum error occurred	Is shut down	Key switch is turned to OFF	Standard	4-1
19	ECU-EEPROM	Reading/writing error occurred	Continues to run normally			
		Checksum error occurred				
21	ECU-sub CPU	Communication with sub microcomputer failed	Continues to run normally			
22	ECU-mapping format	Mapping format is invalid	Is shut down			
23	ECU-temperature sensor	Sensor voltage is over 4.6 V or under 1.0 V	Continues to run normally	Temperature returns to normal		

TROUBLESHOOTING

This Page Intentionally Left Blank

LONG-TERM STORAGE

This section of the Operation Manual describes the procedures necessary to place the engine into long-term storage (six months or longer) and how to place it back into operation.

LONG-TERM STORAGE

BEFORE YOU PLACE THE ENGINE IN LONG-TERM STORAGE

DANGER

Explosion Hazard!



- **Never short out the battery terminals, including when checking the remaining battery charge. This will result in a spark and may cause an explosion or fire. Use a hydrometer to check the remaining battery charge.**

- **If the electrolyte is frozen, slowly warm the battery before you recharge it.**
- **Failure to comply will result in death or serious injury.**

WARNING

Burn Hazard!



- **Batteries contain sulfuric acid. Never allow battery fluid to come in contact with clothing, skin or eyes. Severe burns could result. Always wear safety goggles and protective clothing when servicing the battery. If battery fluid contacts the eyes and/or skin, immediately flush the affected area with a large amount of clean water and obtain prompt medical treatment.**

- **Failure to comply could result in death or serious injury.**

CAUTION

Flying Object Hazard!



- **Always wear eye protection when servicing the engine and when using compressed air or high-pressure water. Dust, flying debris, compressed air, pressurized water or steam may injure your eyes.**

- **Failure to comply may result in minor or moderate injury.**

NOTICE

Protect the air cleaner, turbocharger (if equipped) and electric components from damage when you use steam or high-pressure water to clean the engine.

Perform the next Preventive Maintenance procedure. For example, if there are 10 hours remaining before the 250 hour maintenance, you should do the maintenance before you place the engine in storage.

See *Periodic Maintenance Schedule* on page 64.

1. Flush the radiator and refill with Long Life Engine Coolant. See *Engine Coolant Specifications* on page 47 for engine coolant specifications and See *Filling Radiator with Engine Coolant* on page 47 for the procedure for draining and refilling the cooling system.
2. Clean the exterior of the engine so it is free of grease and oil.
3. Drain the fuel tank or make sure it is completely full. See *Filling the Fuel Tank* on page 41.
4. Lubricate exposed parts of the engine speed control system.
5. Protect the air cleaner, muffler and electrical components (alternator, starter motor, switches, EGR valve, controller) from water and dust.
6. Disconnect the negative (-) battery cable to prevent the battery from discharging.
7. Check the battery fluid and add distilled water as required. See *Check battery and recharge* on page 73.
8. Charge the battery once a month during storage.
9. Rotate the engine without starting, every four to six months.

RETURNING THE ENGINE TO SERVICE

1. Perform the *Daily Checks on page 49*.
2. The engine should be pre-oiled before startup. Crank the engine, leaving the fuel system shut off so the engine will not start, for 15 seconds. Then pause for 30 seconds. Repeat the procedure until you have cranked the engine for a total of one minute. This will circulate the oil in the engine's lubrication system.
3. Prime the fuel system. See *Priming the Fuel System on page 42*.
4. Start the engine. Allow the engine to idle for approximately 15 minutes while you check for:
 - Proper oil pressure
 - Fuel, engine oil, or coolant leaks
 - Proper operation of the indicators and/or gauges.
5. Avoid prolonged operation at minimum or maximum engine speeds and loads for the remainder of the first hour of operation.

LONG-TERM STORAGE

This Page Intentionally Left Blank

SPECIFICATIONS

SPECIFICATIONS

ENGINE GENERAL SPECIFICATIONS


Type	Vertical in-line, water cooled, 4-cycle diesel engine	
Combustion system	Direct injection models	Direct injection
	Indirect injection models	Swirl chamber (ball-type)
Starting system	Electric starting	
Cooling system	Radiator	
Lubricating system	Forced lubrication with trochoid pump	
PTO position	Flywheel end	
Direction of rotation	Counterclockwise viewed from flywheel end	

Note:

- The information described in Principal Engine Specifications is for a “standard” engine. To obtain the information for the engine installed in your driven machine, please refer to the manual provided by the driven machine manufacturer.
- Engine rating conditions are as follows (SAE J1349, ISO 3046/1):
 - Atmospheric condition: Room temperature 25 °C (77 °F), atmospheric pressure 29.53 in. Hg (100 kPa, 750 mm Hg), relative humidity 30 %
 - Fuel temperature at fuel injector pump Inlet: 40 °C (104 °F)
 - Fuel feeding pressure: 20 ± 10 kPa (net) after engine break-in has been performed with the cooling fan, air cleaner and muffler installed to the engine.
 - With cooling fan, air cleaner, muffler: Isuzu standard
 - After the engine break-in period. Output allowable deviation: ± 3 %
 - 1 PS = 0.7355 kW
 - 1 hp SAE (Society of Automotive Engineers) = 0.7457 kW

■ Engine family

The following is an explanation of the Engine Family field designation:



PRINCIPAL ENGINE SPECIFICATIONS

■ 3CH1-NGZG01, 3CH1-SDZP01

Engine model		3CH1-NGZG01	3CH1-SDZP01
Type		Vertical in-line 4-cycle diesel engine	
Combustion system		Ball-type swirl chamber (IDI)	
Aspiration		Naturally aspiration	
No. of cylinders		3	
Bore x stroke	mm	ø80 x 84	
Displacement	L	1.266	
Engine rotation speed	min ⁻¹	1800	3000
Continuous rated output	kW	9.7	-
	PS	13.2	
Rated output (Gross)	kW	10.7	17.8
	PS	14.6	24.2
High idling	min ⁻¹	1925	3235
Engine weight (dry)	kg	130	99/117
Compression ratio		23.1	
PTO position		Flywheel end	
Direction of rotation		Counterclockwise viewed from flywheel end	
Speed governor		Mechanical, centrifugal type (all speed governor)	
Cooling system		Liquid-cooled with radiator	
Lubricating system		Forced lubrication with trochoid pump	
Normal oil pressure at rated engine speed	MPa	0.34	
Normal oil pressure at low idle speed	MPa	0.06	
Starting system		Electric starting (starter motor: DC12 V - 1.1 kW)	
Charging system		Alternator: 12 V, 40 A	
Recommended battery capacity		12 V 433CCA	
Starting aids		Glow plug (3 or 4 seconds)	
Dimensions (L x W x H)	mm	567 x 427 x 532	523 x 427 x 532
Engine oil pan capacity	L	3.4/1.8 (Dipstick upper limit/lower limit)	
Engine coolant capacity	L	0.9 (Engine only)	
Standard cooling fan	mm	ø335 x 6 blade pusher-type *1	
Crank V-pulley dia./ Fan V-pulley dia.	mm	ø110/ø100 *1	
Top clearance	mm	0.778 ± 0.069 (consider oil clearance)	

*1: May vary depending on the driven machine.

SPECIFICATIONS

■ 3CE1

Engine model	3CE1		
Type	Vertical in-line 4-cycle diesel engine		
Combustion system	Direct injection (DI)		
Aspiration	Naturally aspiration		
No. of cylinders	3		
Bore x stroke	mm	ø88 x 90	
Displacement	L	1.642	
Engine rotation speed	min ⁻¹	1500	1800
Continuous rated output	kW	13.0	14.3
	PS	17.7	19.4
Output (Gross)	kW	14.3	15.7
	PS	19.4	21.3
High idling	min ⁻¹	1600	1915
Engine weight (dry)	kg	158	
Compression ratio	19.1		
PTO position	Flywheel end		
Direction of rotation	Counterclockwise viewed from flywheel end		
Speed governor	Mechanical governor (all-speed governor)		
Cooling system	Liquid-cooled with radiator		
Lubricating system	Forced lubrication with trochoid pump		
Normal oil pressure at rated engine speed	MPa	0.294	
Normal oil pressure at low idle speed	MPa	0.059	
Starting system	Electric starting (starter motor: DC12 V - 1.7 kW)		
Charging system	Alternator: 12 V, 40 A		
Recommended battery capacity	12 V 413CCA		
Starting aids	Glow plug (15 seconds)		
Dimensions (L x W x H)	mm	608 x 532 x 709	
Engine oil pan capacity	L	6.7/3.9 (Dipstick upper limit/lower limit)	
Engine coolant capacity	L	2.0 (Engine only)	
Standard cooling fan	mm	ø360 x 6 blade pusher-type *1	
Crank V-pulley dia./ Fan V-pulley dia.	mm	ø120/ø90 *1	
Top clearance	mm	0.73 ± 0.06 (consider oil clearance)	

*1: May vary depending on the driven machine.

SPECIFICATIONS

■ **3CJ1-NGZG01**

Engine model		3CJ1-NGZG01		
Type		Vertical in-line 4-cycle diesel engine		
Combustion system		Ball-type swirl chamber (IDI)		
Aspiration		Naturally aspiration		
No. of cylinders		3		
Bore x stroke	mm	ø74 x 77		
Displacement	L	0.993		
Engine rotation speed	min ⁻¹	2400	2500	3000
Continuous rated output	kW	-		
	PS	-		
Rated output (Gross)	kW	11.2	11.6	14.2
	PS	15.2	15.8	19.3
High idling	min ⁻¹	2595	2700	3210
Engine weight (dry)	kg	98/103		
Compression ratio		23.1		
PTO position		Flywheel end		
Direction of rotation		Counterclockwise viewed from flywheel end		
Speed governor		Mechanical, centrifugal type (all speed governor)		
Cooling system		Liquid-cooled with radiator		
Lubricating system		Forced lubrication with trochoid pump		
Normal oil pressure at rated engine speed	MPa	0.34		
Normal oil pressure at low idle speed	MPa	0.06		
Starting system		Electric starting (starter motor: DC12 V - 1.0 kW)		
Charging system		Alternator: 12 V, 40 A		
Recommended battery capacity		12 V 433CCA		
Starting aids		Glow plug (3 seconds)		
Dimensions (L x W x H)	mm	504 x 441 x 542		
Engine oil pan capacity	L	2.8/1.5 (Dipstick upper limit/lower limit)		
Engine coolant capacity	L	0.9 (Engine only)		
Standard cooling fan	mm	ø310 x 5 blade pusher-type *1		
Crank V-pulley dia./ Fan V-pulley dia.	mm	ø110/ø100 *1		
Top clearance	mm	0.778 ± 0.069 (consider oil clearance)		

*1: May vary depending on the driven machine.

SPECIFICATIONS

■ 3CJ1-SDZP01

Engine model	3CJ1-SDZP01	
Type	Vertical in-line 4-cycle diesel engine	
Combustion system	Ball-type swirl chamber (IDI)	
Aspiration	Naturally aspiration	
No. of cylinders	3	
Bore x stroke	mm	ø74 x 77
Displacement	L	0.993
Engine rotation speed	min ⁻¹	3000
Continuous rated output (Gross)	kW	13.6
	PS	18.5
Rated output (Gross)	kW	14.9
	PS	20.3
High idling	min ⁻¹	3175
Engine weight (dry)	kg	110
Compression ratio	23.5	
PTO position	Flywheel end	
Direction of rotation	Counterclockwise viewed from flywheel end	
Speed governor	Mechanical, centrifugal type (all speed governor)	
Cooling system	Liquid-cooled with radiator	
Lubricating system	Forced lubrication with trochoid pump	
Normal oil pressure at rated engine speed	MPa	0.34
Normal oil pressure at low idle speed	MPa	0.06
Starting system	Electric starting (starter motor: DC12 V - 1.2 kW)	
Charging system	Alternator: 12 V, 40 A	
Recommended battery capacity	12 V 433CCA	
Starting aids	Glow plug (4 seconds)	
Dimensions (L x W x H)	mm	556 x 422 x 568
Engine oil pan capacity	L	3.4/1.8 (Dipstick upper limit/lower limit)
Engine coolant capacity	L	1.0 (Engine only)
Standard cooling fan	mm	ø310 x 5 blade pusher-type *1
Crank V-pulley dia./ Fan V-pulley dia.	mm	ø100/ø90 *1
Top clearance	mm	0.708 ± 0.070 (consider oil clearance)

*1: May vary depending on the driven machine.



ESlAlaska.com

Accessories

Anchorage:

7780 Old Seward Hwy
Anchorage, AK 99518
(907) 341-2250 | (877) 341-2250

Fairbanks:

1919 Van Horn Road
Fairbanks, AK 99701
(907) 458-9049 | (888) 868-9049

Seattle:

17660 W. Valley Hwy
Tukwilla, WA 98188
(425) 251-6119

Williston:

5064 Bennett Loop
Williston, ND 58801
(701) 774-5312

Equipment Source, Inc.



THIS PAGE INTENTIONALLY LEFT BLANK

CAUTION

GASOLINE IS INVOLVED AND VAPORS WILL SETTLE IN LOW AREAS. WORK IN A WELL VENTILATED SPACE AWAY FROM SPARKS OR OPEN FLAME SUCH AS A PILOT LIGHT. HAVE A CLASS 'B' FIRE EXTINGUISHER CLOSE BY.

CAUTION**CAUTION**

TO ELIMINATE THE CHANCE OF FIRE OR PERSONAL INJURY, THE FUEL SYSTEM PRESSURE MUST BE RELIEVED BEFORE SERVICING ANY FUEL SYSTEM COMPONENT.

INSTALLATION INSTRUCTIONS FOR UNIVERSAL ELECTRIC FUEL PUMP

NOTE:

- Before replacing any electric fuel pump diagnose the cause of failure.
- Dirt is the major cause of pump failure, so the tank must be cleaned out or dirt may cause the replacement pump to fail as well.
- Exercise care so that no dirt falls into the tank during disassembly or reassembly.

-For safety reasons, it is recommended an Oil Pressure Safety Switch be installed. This will prevent engine damage and reduce the chance of fire in the case that the engine stops without the ignition switch in the "off" position.

- Installation of the replacement pump may require some of the mounting or electrical components be reused. Do not discard any parts.
- To prevent fuel pump failure, installation of a high quality fuel filter on the inlet side of the pump, is required.

A. FUEL PUMP INSTALLATION

1. Disconnect the negative battery cable.
2. Mount the fuel pump close to the existing fuel lines and tank, but away from any exhaust system component. Place the pump and bracket assembly as near to the bottom of the fuel tank as possible, but never more than 24 inches above the top of the tank.
3. Remove a section of fuel line where the pump is to be mounted. (A tube cutter is recommended when cutting fuel lines. Flush the fuel line to prevent metal chips from entering the fuel system.)
4. If pump has rubber hose fittings proceed to next step. If using a pump with threaded inlet/outlet fittings, assemble the (supplied) fuel fittings to the fuel pump (See Fig. A). (This pump is equipped with dry-seal fuel fittings. Do not use Teflon tape or pipe sealant on pipe fittings, or pump breakage will occur.)
5. Install mounting bracket onto vehicle's chassis/frame with self-tapping screw(s).
6. Install the fuel pump on the mounting bracket with the outlet towards the engine. Place ground (-) wire from pump under mounting screw or bolt.
7. Connect the fuel lines to the fuel pump, using supplied rubber fuel line and clamps provided. (To prevent fuel pump failure, installation of a high quality fuel filter on the inlet side of the pump, is required.) (See Fig. A.)
8. Using #14 or larger (lower gauge #) gauge wire, follow the wiring diagram (See Fig. A & B) and connect the pump to the vehicle's electrical system. If the vehicle has a pre-existing oil pressure safety switch which operates either a warning light or gauge, it is recommended that a T-adapter be installed into the engine block and both the O.E. and the Oil Pressure Safety Switch be used (See Fig. C). A 10-amp fuse should be installed between the pressure safety switch and the electric pump. (Route wires away from heat and road hazards, and anchor securely to prevent vibration and chafing. Full battery voltage must be available to the pump when the ignition switch is "on". Pump ground must be the same as the battery ground.)
9. If this pump is being used to replace a defective in tank pump, and it is not going to be removed, make sure the defective pump does not restrict the fuel supply.
10. If this pump is being used to replace a defective mechanical pump, the fuel lines should bypass the mechanical pump. Fuel pushed through a defective mechanical pump can cause severe engine damage. If mechanical pump is not removed from the engine, the mechanical pump inlet should be plugged.

WARNING

NOT FOR USE IN AIRCRAFT OR OTHER NON-AUTOMOTIVE USE. THE USE OF A PUMP FOR OTHER THAN THE APPLICATIONS LISTED WILL VOID THE WARRANTY AND COULD DO SEVERE ENGINE DAMAGE.

WARNING**WARNING**

Fig. A





Fig. B



120 Series

Fuel Filter/Water Separators



The Racor 120 Series fuel filter/water separators offer Racor proven protection in a small, compact package. The 120 Series offers reliable protection for smaller diesel and gasoline engines used in generator sets, pressure washers and small construction equipment. Their compact size fits tight mounting locations and multiple ports offer installation flexibility.



Contact Information:

Parker Hannifin Corporation
Racor Division
P.O. Box 3208
3400 Finch Road
Modesto, CA 95353
phone 800 344 3286
209 521 7860
fax 209 529 3278
racor@parker.com

www.parker.com/racorproducts

Product Features:

- Small compact size
- Cost effective pricing
- Aquabloc® II media
- Your choice of 2, 10, or 30 micron filtration
- Clear collection bowl
- Self venting drain
- 99% water removal efficiency
- Optional water-in-fuel sensor



ENGINEERING YOUR SUCCESS.

Product Information and Specifications

The Racor 120 Series features a two compact sizes to fit the most cramped engine compartments. Both units feature 1/4"-18 NPTF inlet and outlet fuel ports and a unitized mounting bracket.

Elements

Both 120 Series assemblies feature spin-on, high-capacity, Aquabloc®II replaceable filter elements which stop water, remove solid contamination, and are available in 2, 10, and 30 micron. Filtration needs should be based on application, fuel quality, operating climates, and maintenance schedules.

Clear Bowls

Both units feature spin-on contaminant collection bowls.

The clear bowls used with these models will not discolor from alcohol, additives, or UV light and have a leak-proof, positive seal drain for easy servicing. Water and contamination levels can be seen easily at a glance.

Options

120 Series optional accessories include: water detection kits, vacuum or compound gauges and metal bowls. Metal bowls should be specified when filtering fuels in hazardous locations where equipment is exposed to flying gravel and debris.



Specifications	120A	120B
Maximum Flow Rate	15 gph / 57 lph	20 gph / 76 lph
Port Size: (SAE J476)	1/4"-18 NPTF	1/4"-18 NPTF
Total Number of Ports: (total inlets) (total outlets)	4 2 2	4 2 2
Minimum Service Clearance	2.0" / 5.1 cm	2.0" / 5.1 cm
Center Threads	M18 x 1.5	M18 x 1.5
Height	6.5" / 16.5 cm	8.0" / 20.3 cm
Depth	3.2" / 8.1 cm	3.2" / 8.1 cm
Width	3.2" / 8.1 cm	3.2" / 8.1 cm
Weight (dry)	1.1 lb / 0.50 kg	1.1 lb / 0.50 kg
Clean Pressure Drop	0.15 psi / 0.01 bar	0.15 psi / 0.01 bar
Max. Allowable Pressure ¹	7.0 psi / 0.48 bar	7.0 psi / 0.48 bar
Available Options ² : (water sensor probe) (heater)	Yes No	Yes No
Water in Bowl Capacity	1.8 oz. / 52 ml	1.8 oz. / 52 ml
H ₂ O Removal Efficiency	99%	99%
Ambient Temperature Range	-40° to +255°F (-40° to +123°C)	

